Calibration, Use, and Maintenance of Mettler Toledo XA105DU Balance

1. SCOPE AND APPLICATION

1.1. This procedure is based on the Mettler Toledo Excellence Analytical Balances XA Models Operating Instructions. It can be used for determining the weight of items within the range (0.01 mg – 120 g) of the balance.

2. SUMMARY OF THE METHOD

2.1. The Mettler Toledo XA105DU balance has an automatic internal calibration that occurs when ambient conditions change. The balance is checked with R-weights prior to each use, with five S-weights monthly, and with all S-weights quarterly. After checking with R-weights, the balance is zeroed or tared as appropriate. Items to be weighed are placed on the instrument grid weighing pan. After the display stabilizes, the weight is recorded. When weighing is complete, the balance is turned off and cleaned.

2.2. Interferences

2.2.1. Drafts, moisture, direct sunlight, temperature change, contaminated R-weights or S-weights, and weighing dishes can cause measurements to be inaccurate. Make sure the position of the balance is stable, free from vibration, and horizontal as much as possible.

3. EQUIPMENT AND SUPPLIES

3.1. Calibration Check

3.1.1. XA105DU balance (S/N B314195659)

3.1.2. S-weights

Note: Do not touch any of the weights with bare skin. Oil from skin can cause the weights to be inaccurate. Only the forceps that are included with the weights should be used to handle them. Do not set the weights on ANY surface other than a clean weighing pan.

3.1.3. Dust brush

3.1.4. *Mettler XA105DU Calibration Log*

3.2. Weighing

3.2.1. XA105DU balance (S/N B314195659)

3.2.2. R-weights

3.2.2.1. R-weights have been compared to certified S-weights and are used for daily measurements. Use of the R-weights protects S-weights from contamination or damage that might be incurred by daily use.

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.

Note: Do not touch any of the weights with bare skin. Oil from skin can cause the weights to be inaccurate. Only the forceps that are included with the weights should be used to handle them. Do not set the weights on ANY surface other than a clean weighing pan.

3.2.3. Weighing container

3.2.4. Dust brush

3.2.5. *Mettler XA105DU Daily Use Log*

4. MANUAL CALIBRATION (PERFORM AS NECESSARY)

4.1. Ensure that the grid weighing pan is unloaded.

4.2. Clean the grid weighing pan gently with the dust brush and close the doors.

4.3. Check the level indicator to ensure the balance is level. If it is not, level the balance by turning the leveling feet underneath the back of the balance until the bubble is in the middle of the level glass which indicates that the balance is exactly horizontal. The balance must be leveled and adjusted each time it is moved to a new location. See Table 1 for more information on adjusting the leveling feet.

Table 1

Where is the air bubble?	**Turn feet in this direction**
12 o'clock	Both feet clockwise
3 o'clock	Left foot clockwise, right foot counterclockwise
6 o'clock	Both feet counterclockwise
9 o'clock	Left foot counterclockwise, right foot clockwise

4.4. Turn the balance on.

4.5. On the bottom right side of the display screen, touch the **Adjust .int** icon (). The balance will perform an automatic calibration. The balance will display "Adjustment done" when the calibration is complete. Touch **OK**. Record the calibration in the *Mettler XA105DU Calibration Log*.

5. WEIGHING

5.1. Two R-weights that bracket the sample mass (or range of masses) must be weighed prior to use.

5.2. Ensure that the grid weighing pan is unloaded.

5.3. Inspect and clean the grid weighing pan with the dust brush as necessary.

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.

5.4. Turn the balance on by pressing the **On/Off** key.

5.5. If the balance does not display "0.00000 g", ensure that the doors of the draft shield are all closed and press the **[→ 0 ←]** key. Always use the [→0←] zeroing keys before you start with weighing, especially before recording a tare weight (using the →T← key).

5.6. Place one R-weight on the balance and close the doors of the draft shield.

5.7. Wait for the stability detector icon ("**O**") located in the top left of the display to disappear before recording the weight. If the stability detector icon is still visible in the diagram, the weighing result is not stable.

5.8. Remove the weight from the grid weighing pan.

5.9. Repeat steps 5.5 – 5.8 for the second R-weight and record the weights in the *Mettler XA105DU Daily Use Log*. If the R-weights are not within the tolerances found in the *Mettler XA105DU Daily Use Log*, manually calibrate the balance as described in step 4.

5.10. Place a weighing container on the grid weighing pan. Ensure that the doors of the draft shield are all closed and press the **[→T←]** key to tare the balance. "0.00000 g" should be displayed.

Note: This balance has some ErgoClip attachments that can be used to make weighing easier. Turn off the balance and remove the grid weighing pan from the balance before snapping any ErgoClips onto the grid weighing pan. Gently hang the grid weighing pan back in the weighing chamber with the ErgoClip attached. Turn the balance back on.

5.11. Add the substance or object to be weighed to the weighing container. Closing the doors of the draft shield between any substance additions prevents drafts from skewing the weight.

5.12. Wait for the stability detector ("**O**") located in the top left of the display to disappear before recording the weight.

5.13. Remove the weighing container from the grid weighing pan.

5.14. Repeat steps 5.10 – 5.13 for all items to be weighed.

5.15. Turn the balance off by holding down the **On/Off** key until "OFF" appears on the display.

5.16. Clean any spilled substances from the balance. The grid weighing pan and drip tray can be removed from the balance for cleaning.

6. MAINTENANCE

6.1. The balance should be cleaned monthly with a mild cleaning agent as indicated in the *Micro QC Checklist*.

6.2. Disconnect the balance from the power supply.

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.

6.3. Slide the top glass panel partially back. Rotate the side and front glass panels of the draft shield down and away and the top glass panel up and away from the balance and pull them out of their fastenings.

Note: Grip the side and front glass panels at the top in the center. Grip the top glass panel at the front in the center.

6.4. Carefully raise the front of the grid weighing pan and lift it out of the guide.

6.5. Pull the drip tray up from the front and away from the balance.

6.6. Clean all components and reinstall in the reverse order.

7. QUALITY CONTROL

7.1. Monthly, weigh and record a minimum of five S-weights. Quarterly, weigh and record all S-weights. Notify a supervisor if the S-weights are not within the tolerances found in the *Mettler XA105DU Calibration Log*.

8. REFERENCES

8.1. Mettler Toledo Excellence Analytical Balances XA Models Operating Instructions

APPENDIX OF CHANGES

01/23/2015	Formatted for 508 compliance.
10/02/2019	The name of this SOP was changed from PCR-2.2-1.4 to BB-036-1.0
09/22/2020	Included more interferences of the Mettler Toledo XA105DU; desired stable Position for XA balances; corrected name of stable detector icon according to Mettler Toledo operating instructions.

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.