

Escambia County

Sampler's initials : KP

Page 1 of 1

Date/Time: 04/13/21 1517

Date/Time: 04/13/21 1517

Instructions: Fill in all fields except "Lab ID" on sample transport form completely. Each sample container must use a separate line. Place this form in a waterproof bag and place it with the samples for transport. If a field log or other chain of custody is attached, that information may be referenced on this form and the log or COC attached.

Comments: Sample Container lot# 1200204

Contact organization FDEP

Phone:

Sampler's name:

¹Matrix examples: SW = surface water, PW = pore water, GW = ground water, FW = Freshwater, MW = Marine Water, BW = Brackish Water, S = soil/sediment, Other X =

³ Recorded using IRT-2