Preparation of Artificial Seawater (ASW)

1. SCOPE AND APPLICATION

1.1. This method is based on EPA 821-R-02-012 *Methods for Measuring the Acute Toxicity of Effluents and Receiving Waters to Freshwater and Marine Organisms*, 5th Ed. October 2002. It can be used with well water, deionized water or a suitable surface freshwater.

2. SUMMARY OF METHOD

2.1. Artificial sea-salts are dissolved in well water. The salinity of the solution is measured and adjusted as needed. Batch information is recorded in the *Tox Record of Preparation* logbook.

2.2. Interferences:

2.2.1. Contaminants in the salts or water and water containing substances at or near saturation can interfere with the salts dissolving in the solution.

2.2.2. Contaminated containers can cause bacterial, fungal or algal slime growth in the solution and render it useless for bioassay testing.

3. EQUIPMENT AND SUPPLIES

3.1. Scrub brush

3.2. 1 L Wide-mouth glass, jar

3.3. 250 mL Beaker

3.4. 12 L Nalgene bucket

3.5. Large (10.16 cm) Air stone

3.6. 4.76 mm ID Air-line tubing, 2.44 m length

3.7. Labeling tape

3.8. Black laboratory water-proof marker

3.9. 113 L Nalgene drum with lid

3.10. Mettler Toledo SevenMulti® meter, calibrated per SOP TA-06.25.

3.11. Mettler Toledo PB403-S/FACT balance, calibrated per SOP TA-06.31.

4. REAGENTS AND STANDARDS

4.1. Deionized Water

4.2. Chlorine bleach

4.3. Sodium thiosulfate ($Na_2S_2O_3$), 0.025 N

4.4. Well water

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.

4.5. Commercial artificial sea-salt mix

4.5.1. This lab uses Forty Fathoms Biocrystals™ Marine Mix (Bioassay Laboratory Grade).

5. PREPARATION

5.1. Cleaning the Drum

5.1.1. If drum is **new**: wash with soap and water, acid rinse with 10% HCl and rinse with copious amounts of well water.

5.1.2. If drum is being **reused**: Empty remaining ASW from the Nalgene drum and rinse the drum with well water.

5.1.3. ASW can be emptied into the floor drain.

5.1.4. If needed, pour 20-30 mL chlorine bleach in the bottom of the drum and add about 1 L of DI water. Use the scrub brush to remove algae from the sides and bottom of the drum. (Wear a lab coat, gloves, and respirator. Turn the drum on its side to reach the bottom). After the drum has been cleaned of any algae, etc., empty the bleach water down the floor drain.

5.1.5. Rinse the drum several times with well water to remove the debris and most of the bleach. Empty the well water down the floor drain.

5.1.6. Add 100 mL of 0.025 N sodium thiosulfate to the drum. The sodium thiosulfate solution should cover all interior surfaces of the drum to neutralize any remaining chlorine bleach.

5.1.6.1. A pipette or beaker can aid in covering the entire interior surface of the drum with sodium thiosulfate. Pour the $Na_2S_2O_3$ from the beaker while tilting the drum.

5.1.7. Rinse the drum with copious amounts of well water and dispose of water down the floor drain.

5.2. Making the ASW

5.2.1. Place approximately three 1 L jars full of Forty Fathoms® bioassay grade artificial sea salt into the bottom of the drum. Add well water to the 100 L mark (approximately 10.2 cm from the top of the drum; this allows the addition of well water if needed to adjust salinity).

5.2.1.1. In lieu of using the 1 L jars, weigh out approximately 2100 g of sea salts on the Mettler Toledo PB403-S/FACT balance. Add these salts to the drum.

5.2.2. Place the air stone in the drum and adjust to a moderate level of aeration. Place the lid on the drum. (The aeration serves as a mixing aid.)

5.2.3. Make a label: “ASW,” “preparation date,” “expiration date” (30 ± 2 days from preparation date—i.e., one month from prep date), “batch number” and “preparer’s initials.” Place the label on the lid. Apply a “Do Not Use” label to the drum lid. Let stand 24 hours.

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.

5.2.3.1. Batch number is the date that the ASW is prepared. ASW can be used after the "expiration date" absent of any algal growth and/or other visible changes.

5.2.4. After 24 hours, measure the salinity of the water in the drum. If necessary, adjust the salinity to the required salinity of 20 ± 0.5 parts per thousand (ppth).

5.2.4.1. Measure salinity per SOP TA-06.25.

5.2.4.1.1. If the salinity is less than 19.5 ppth, add sea salts at the rate of approximately 100 g per desired 1 ppth increase in salinity.

If sea salts are added, mix (15-30 min) before measuring salinity.

When desired salinity is met, allow the ASW to sit for an additional 1-2 hours before use.

5.2.4.1.2. If the salinity is greater than 20.5 ppth, add well water at the rate of approximately 4 liters per desired 1 ppth decrease in salinity.

If well water is added, mix (4-5 minutes) before measuring salinity.

When desired salinity is met, the ASW can be used.

5.2.4.1.3. Continue aeration during salinity adjustments.

5.2.5. When the desired salinity is reached, remove the "Do Not Use" label from the drum lid.

5.2.6. Label the ASW drum with the final measured salinity. Salinity should also be checked prior to use of ASW.

6. DATA ARCHIVAL

6.1. Use a black, waterproof pen for all bench sheets and logbooks.

6.2. Record preparation in the *Tox Record of Preparation* logbook.

6.3. To correct raw data entries, place a single line through the incorrect or illegible entry. Write the corrected entry near the error, initial and date the correction. Do not overwrite entries.

6.3.1. The corrected entry is written as near its appropriate space as possible or else in the comment box on the appropriate bench sheet.

6.3.2. If the correction requires an explanation, write a comment and reference the error. Initial and date the explanation.

6.3.3. Use sequential alphabetical annotation to identify errors and corresponding comments (use A for first error and use A for corresponding explanatory comment; use B for second error, etc.).

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.

7. QUALITY CONTROL

7.1. Thoroughly clean and rinse the drum before making new ASW to prevent bacterial, fungal and algal slime contamination.

7.2. When adjusting the salinity with additional sea-salt or well water, mix the solution before re-checking the salinity.

8. SAFETY/HAZARDOUS WASTE MANAGEMENT

8.1. Proper laboratory protection, including lab hood or ventilation system, lab coat, gloves and safety glasses, is required when working with chemicals and unprocessed samples.

8.2. Refer to FDEP Laboratory Quality Manual for sample disposal.

8.3. Refer to the FDEP Laboratory Health and Safety Manual.

8.4. Read MSDS information for reagent handling and disposal.

9. REFERENCES

9.1. FDEP Laboratory Quality Manual
http://www.dep.state.fl.us/labs/library/lab_sops.htm

9.2. FDEP Laboratory Health and Safety Manual
https://www.fldepnet.org/content/dear/bureau-laboratories-safety-documents

9.3. FDEP SOP TA-06.25, Calibration and Use of Mettler Toledo SevenMulti for Measuring Conductivity, Salinity and TDS.

9.4. EPA 821-R-02-012 Methods for Measuring the Acute Toxicity of Effluents and Receiving Waters to Freshwater and Marine Organisms, 5th Ed. October 2002.

9.5. MSDS information sheets.

APPENDIX OF CHANGES

09/24/2008	Added Scope and Application, Summary of the Method, Interferences, References and Appendix of Changes
05/24/2013	Reformatted
02/09/2015	Formatted for 508 compliance.
03/28/2016	Updated links and references.

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.