Media Quality Control

1. GENERAL PROCEDURE

1.1. Test each new batch of prepared media and each new lot of commercially prepared ready to use media before first use with the following:

1.1.1. Positive control: Inoculate with a target organism that is known to produce a positive reaction in the media.

1.1.2. Negative control: Inoculate with a non-target organism which is known to be growth inhibited or produce a negative reaction in the media.

1.1.3. Sterility control: Along with positive and negative controls, incubate an additional tube/plate that has not been inoculated to check for sterility of media.

1.2. Inoculation of Media

1.2.1. For membrane filtration or pour plate media, use a sterile inoculating needle to add a small amount of the pure control culture to a 99 mL sterile phosphate buffered dilution water bottle, mix thoroughly and use for the following:

1.2.1.1. For membrane filtration media: Perform a membrane filtration (see DEP SOP MB-01.0, MB01.1, MB-01.14, MB-01.2, or MB-01.4) with at least 1 mL of the spiked water.

1.2.1.2. For pour plate media: Use 0.1 mL of spiked water for pour plate method (see DEP SOP MB-01.5).

1.2.2. For Quanti-Tray media, use a sterile inoculating needle to add a small amount of the pure control culture to 100 mL of sterile non-buffered water in an IDEXX mixing vessel. Follow the Quanti-Tray procedure (see DEP SOP MB-01.15).

1.2.3. For streak plate media and broth and agar culture tubes, media may be inoculated directly with a small amount of pure control culture.

1.2.4. Incubate controls at the temperature and duration specified for the media.

2. DATA ARCHIVAL

2.1. When adding media preparation in LIMS Standard Preparation Tracker, the Media Preparation window contains a section labeled “QC Testing”. Enter Date QC Test is set up, analyst, and preparation name. Once the preparation name is entered, the QC positive and negative control and expected results boxes are automatically populated with the bacteria that should be used for positive and negative controls. Add the serial number for the cultures used in these boxes after the “S#”.

2.2. After incubation, check that response to media matches the expected results given in the media preparation module of LIMS Standard Preparation Tracker. If all QC controls pass, enter the result in LIMS Standard Preparation Tracker. Select

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.

Media/Media QC Pass/Fail from the menu. Highlight appropriate media batches; enter date, analyst, sterility result and click **Pass**.

2.3. If controls do not produce appropriate responses, retest. If after retest, controls still fail follow step 2.2 to enter results, except click **Fail** instead of **Pass**. Discard media batch. Make a new batch of media and repeat the quality control process.

3. SAFETY/HAZARDOUS WASTE MANAGEMENT

3.1. Empty dehydrated culture media containers can be discarded in the trash.

3.2. Discard expired dehydrated media as hazardous waste.

3.3. Always autoclave any expired or used prepared media for 45 minutes in a hazardous waste autoclave bag before discarding in the trash.

3.4. Refer to the Laboratory Health and Safety Plan for personal protective equipment, use of laboratory hoods, and chemical storage policies.

3.5. Read MSDS information for reagent handling and disposal.

4. REFERENCES

4.1. Standard Methods Online Edition, Section 9020B (1997)

4.2. TNI Standard Module 5 Quality Systems for Microbiological Testing 2009 Rev 1.1

4.3. FDEP Laboratory Quality Manual
http://www.dep.state.fl.us/labs/library/lab_sops.htm

4.4. FDEP Laboratory Health and Safety Plan
http://www.fldepnet.org/content/dear/bureau-laboratories-safety-documents

4.5. DEP SOP MB-03.1 *Maintenance of Bacterial Cultures*

4.6. DEP SOP MB-02.33 *Preparation of Dehydrated Culture Media*

4.7. DEP SOP MB-01.0 *Membrane Filter Method for Total Coliforms*

4.8. DEP SOP MB01.1 *Membrane Filter Method for Fecal Coliforms*

4.9. DEP SOP MB-01.14 *Single Step Membrane Filtration Procedure for the Detection and Enumeration of Enterococci using mEI agar (based on EPA 1600)*

4.10. DEP SOP MB-01.15 *Quanti-Tray/2000 Colilert Method for E. Coli and Enterolert Method for Enterococci*

4.11. DEP SOP MB-01.2 *Membrane Filter Method for Fecal Streptococcus*

4.12. DEP SOP MB-01.4 *Membrane Filter Method for Excherichia coli (E. coli)*

4.13. DEP SOP MB-01.5 *Pour Plate Method for Heterotrophic Plate Count*

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.

APPENDIX OF CHANGES

03/18/2009	Updated SOP to new format and included section on documenting results.
03/12/2010	Added version of Standard Methods online being used.
03/17/2011	Updated reference to new version of safety manual.
01/31/2012	Updated reference to Bureau Quality Manual.
01/28/2013	Updated reference from NELAC to TNI Standard
01/13/2015	Added Quanti-Tray media QC and references to SOPs.
12/23/2016	Updated reference for Quanti-Tray SOP, the Quality Manual, and the Health and Safety Plan.

The OFFICIAL COPY is the on-line version. All other copies are considered unofficial and uncontrolled.