

Boldly "X" this box if there is qualified data on this page.

CONTINUING CALIBRATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Meter ID: YST 600 X11111 Datalogger ID: YST 6002-H5 Sept 2008 version

Date 10/25/14 Pre Sample Time: 9:30 Post Sample Time: 15:05
All Times Are: ETZ or CTZ (circle one)

Temperature (Monthly) Please Use "Monthly Temperature Verification Log"

Date of Last Temperature Verification 10/1/14

Pass or Fail

P F

Dissolved Oxygen

In Run Mode Pre Sample 8.82 mg/L @ Temp. 21.4 °C % DO 100.0 P F
nearest 100th nearest 10th nearest 10th
Post Sample 5.11 mg/L @ Temp. 26.2 °C % DO 100.1 P F
nearest 100th nearest 10th nearest 10th

Specific Conductance

	Exp. Date	Lot #	Standard	Initial Reading	
In Run Mode Pre Sample	<u>12/14</u>	<u>2307729</u>	<u>100</u>	<u>101</u>	<u>P</u> F
			µmhos/cm	µmhos/cm	
Post Sample	<u>4/15</u>	<u>140482B</u>	<u>1000</u>	<u>1005</u>	<u>P</u> F
			µmhos/cm	µmhos/cm	

pH

	Standard	Exp. Date	Lot #	Initial Reading	Temperature	
In Run Mode Pre Sample	<u>10</u> SU	<u>2/15</u>	<u>130972</u>	<u>10.0</u> SU	<u>21.0</u> °C	<u>P</u> F
				nearest 10 th	nearest 10 th	
Post Sample	<u>4</u> SU	<u>3/15</u>	<u>131596</u>	<u>4.0</u> SU	<u>30.4</u> °C	<u>P</u> F
				nearest 10 th	nearest 10 th	

Notes:



Z2-SL-8009

Z2SL1409 Z2-SL-8009

MSF MW #17
#13
#7

Maintenance: Specific Conductance Probe Cleaned? Y N
Dissolved Oxygen Membrane Changed? Y N M. A. ECK
Print name of person performing calibrations.

Acceptance Criteria: (D.O. ± 0.3 mg/l of theoretical value) (Specific Conductance ± 5%) (pH ± 0.2 SU) (Temperature ± 0.5 °C)