

Log-in Checklist

RQ- 2019-07-22-63

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 8/30/19 @ 10:18

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.4				6		9			1190 3160 9769

* HNO3 and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No ✓

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No ✓ If yes, is it intact? Yes No
 **Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No
 **Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes No ✓ Init: KH

Chlorine detected? (One container checked per Field ID) Yes No Init:

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: KH
 **W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA ✓ Init: KH
 Coolers Unpacked/Checked by: KK Date: 8/30/19 NCRs (Y/N)? N

Event ID: Algal Bloom Response - as needed
WQAP-2019-08-30-01 (BLOOM-RESP)
Date Received: 30-AUG-2019 10:18

NCR #

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_07_2018 EXP:12/28/19
pH Test Strips 0 – 6 Lot #	
pH Paper 0 – 3 Lot #	220416A EXP:7/30/20
pH Paper 0 – 13 Lot #	222516 EXP:9/15/19
Chlorine Test Strips Lot #	091417V EXP:9/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection
Central Laboratory Submittal Form

Algal Bloom Response - as needed

last revised Jan 25, 2018

Customer: WQAP

Requester: Cheryl A. Swanson

Field Report Prepared By: S Meyer

Project ID: BLOOM-RESP

Collected By: K Panzner + S Meyer

Sampling Agency: FDEP SW ROC

L F V	Site Name: Scott Lake - Bloom Response		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 08/29/2019 Time 11:15	☒ Eastern ☐ Central	Composite end Date _____ Time _____	Bottle Group(s) (See pg 2) A/B/C	
	Date: 08/29/2019		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen 8.13	☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)
	Temp (C) 30.1		pH 7.90		Sample Depth 0.3	☐ ft ☒ m		Sp. Conductance (umho/cm) 189.9
	Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) ☐ dd ☐ dms			Comments
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____	☐ Eastern ☐ Central	Composite end Date _____ Time _____	Bottle Group(s)		
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)		pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)	
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) ☐ dd ☐ dms		Comments		
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____	☐ Eastern ☐ Central	Composite end Date _____ Time _____	Bottle Group(s)		
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)		pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)	
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) ☐ dd ☐ dms		Comments		
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____	☐ Eastern ☐ Central	Composite end Date _____ Time _____	Bottle Group(s)		
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)		pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)	
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) ☐ dd ☐ dms		Comments		
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____	☐ Eastern ☐ Central	Composite end Date _____ Time _____	Bottle Group(s)		
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)		pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)	
Latitude ☐ dd ☐ dms		Longitude ☐ dd ☐ dms		Salinity (ppt) ☐ dd ☐ dms		Comments		

Relinquished By: <i>Sarah Meyer</i>	Date/Time: 08/29/2019 1700	Shipping Method: FedEx	Number of Coolers Shipped: 1	Received By: RK	Date/Time: 8-30-19 1018
-------------------------------------	----------------------------	------------------------	------------------------------	-----------------	-------------------------

Group: A	Bottle Type:	PT-50ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
BLOOM-ID							
Group: B	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
CHLSUITE-W							
Group: B	Bottle Type:	BG-250ML-WDMT H	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
W-MCYST-AA							
Group: B	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
W-NH3							
W-NO2NO3							
W-S-A-TP							
W-TKN							
Group: B	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
W-PO4-F							
Group: C	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	Lugols	Enter Number of Bottles Sent to Lab	1
DTY-QN-C							
PKD-QN-C							

Date of Request: 16-JUL-2019
 Created By: SWANSON_C On: 16-JUL-2019
 Modified By: WATTS_J On: 17-JUL-2019
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District:
 Sampling Event: Algal Bloom Response - as needed

Send Coolers To:

Phone: 813-470-5951
 DEP SW ROC
 13051 North Telecom Parkway
 Temple Terrace, FL 33637-0926
 Attn: Matthew Bearden

Program Module Number:

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 17-JUL-2019
 Biology Request Reviewed By: JASROTIA_P On: 16-JUL-2019
 Sampling Kit Required: YES Ship on: 19-JUL-2019
 Sampling Kit Shipped: YES On: 18-JUL-2019
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: YES
 Date to Receive Samples: 22-JUL-2019
 Received By: SHAIK_A On: 31-JUL-2019

Send Final Report To:

2600 Blair Stone Rd
 MS #3560
 Tallahassee, FL 32399-2400
 Attn: Julie Espy

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: 1 - case of sulfuric acid/2 sets of labels

Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Groups A/B - separate event, priority 1
 Bottle Group C - separate event, priority 12

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, and chlorophyll

Bottle Group C - Priority 12
 For algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Bottle Group A (Biological) With 2 Samples:

Bottle Type: PT-50ML	Number of Bottles: 2	Preserved With: ICE
BLOOM-ID	Template: DEFAULT	(SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 2 Samples:

Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: BG-250ML-WDMTH	Number of Bottles: 2	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-125ML Number of Bottles: 2 Preserved With: FILTER-ICE
W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 2 Samples:

Bottle Type: BP-1L Number of Bottles: 2 Preserved With: Lugols
DTY-QN-C Template: DEFAULT (SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C Template: DEFAULT (SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.