

Log-in Checklist

RQ- 2019-12-09-62

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 12/ 11 /19 @ 10:35

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.4				16 (6)		✓			1278 9009 3675

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ☐ No ☒

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐

**Caps on tight? Yes ☒ No ☐ **Containers intact? Yes ☒ No ☐

**Sufficient Sample Volume: Yes ☒ No ☐

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: KK

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init:

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: SH

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: KK

Coolers Unpacked/Checked by: KK/SH Date: 12/ 11 /19

NCRs (Y/N)? N

Event ID: Algal Bloom Response - SWD
WQAP-2019-12-11-03 (BLOOM-RESP)
 Date Received: 11-DEC-2019 10:35

NCR #

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle TestID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle TestID(s)

Bottles Not Intact

Field ID	Bottle TestID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle TestID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 EXP:11-5-20
pH Test Strips 0 – 6 Lot #	
pH Paper 0 – 3 Lot #	220416A EXP:7/30/20
pH Paper 0 – 13 Lot #	215517 EXP:6/1/20
Chlorine Test Strips Lot #	091417V EXP:9/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Cyanobacteria Bloom Response Field Data Sheet (2019-12-09 v4)

Contains: 1:1 H₂SO₄
Lot No.: SA9203100
Expires: 07/22/20
See Safety Data Sheet (SDS)

[illegible]

RQ-2019-12-09-62		Collected By: Matthew Bearden								
Customer: 21FLTPA		Field Report Prepared By: Matthew Bearden								
Project ID: Bloom Resp- SW		Sampling Agency: SW ROC								
Location: Tiger Lake - NW LOBE		Comments: Bloom observed throughout lake, heaviest concentration on western portion.								
WIN/Field ID: HAB-SW-0005		Coordinates: 27.90274009, -81.37335757								
Site Name: Tiger Lake - NW Lobe		Collection Equip: Bottles								
Matrix: Fresh		High Tide Time: / Low Tide Time: /								
Grab		Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A								
Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (mg/L)	D.O. (%)	Temp (°C)	pH (SU)	Sample Depth (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)	Secchi Disk (m)	Total Depth (m)
12/10/19	1040	13.06	1456	20.7	9.43	0.3	123.7	0.06	0.3	1.3
/	/	/	/	/	/	/	/	/	/	/
Bloom Observations										
Algal Bloom Observed?		☒ Yes ☐ No								
Water Surface		☒ Clear		☐ Scum		☐ Globs		☒ Slick		
Water Clarity		☐ Clear		☐ Slightly Turbid		☒ Turbid		☐ Opaque		
Bloom Color		☒ Green		☐ Red		☐ Brown		☐ Other: _____		
Algae Distribution		☒ Suspended in water column		☒ On surface		☐ Other: _____				
Water Odors		☒ Normal		☐ Sewage		☐ Petroleum		☐ Chemical		Other: _____
Parameter Suite		Parameter Methods				Preservation		pH Check	#Bottles Sent to Lab	Bottle Group
Bloom ID (PT-50mL)		☒ BLOOM-ID				☒ Ice			1	A
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	B
Toxins (BG-WD250)		☒ W-MCYST-AA				☒ Ice			1	B
Preserved Nutrients (500mL HDPE)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP				☒ Ice ☒ H2SO4		☒ <2	1	B
		Lot 9203100		Exp: 7/22/20				☐ <2		
Filtered Nutrients (P125mL)		☒ W-PO4-F		☒ Field Filtered 0.45µm Filter		☒ Ice			1	B
Quantitative Algae		☒ DTY-QN-C / PKD-QN-C				☒ Ice ☐ Lugols			1	C
Relinquished By: M. Bearden		Date/Time: 12/10/19 1600		Number of Coolers Shipped: 1		Received By: KB		Date/Time: 12.11.19 / 1035		

Ref :
Dep :

Date: 18Nov19
Wgt: 10.00 LBS

DV:

SHIPPING:
SPECIAL:
HANDLING:
0.00 TOTAL:

0.00
0.00
0.00
0.00

7vds: PRIORITY OVERNIGHT
TRCK: 1278 4008 3675

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID:

LE1a

RQ:

Project:

BLOOM ROSD

Notes: (1) Always wait for meter to stabilize before recording any readings.

(2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).

(3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification

11/12/19

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro- meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	M. Bearden	12/10	0649	21.9	783.5	8.8	8.81	100.5		1.01	P/F	L/F
ICV	✓	✓	0653	21.8	763.5	8.8	8.82	100.4			P/F	L/F
CCV	K. Parner	1	1315	24.2	795	8.4	8.53	101.6			P/F	L/F
CCV											P/F	L/F

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard μ hos/cm	Meter Reading μ hos/cm	Pass / Fail	Lab / Field
Calibr.	MB	12/10	0655	299939	8/21	1000	1000	P/F	L/F
ICV	✓	✓	0707	2908947	3/21	100	101.8	P/F	L/F
CCV		1	1320	2908947	07/21	100	98.2	P/F	L/F
CCV								P/F	L/F

Conductivity Acceptance criteria $\pm 5\%$

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	MB	12/10	0657	193150	5/21	7.01	22.5	7.01	-15.4	P/F	L/F
Calibr.			0700	193247	5/21	4.00	22.6	4.00	166.3	P/F	L/F
Calibr.			0702	192995	5/21	10.03	22.6	10.03	-187.5	P/F	L/F
ICV	✓	✓	0705	193150	5/21	7.01	22.7	6.90		P/F	L/F
CCV		1	1323	192995	5/21	10.00	23.2	10.08		P/F	L/F
CCV										P/F	L/F

pH Acceptance criteria ± 0.2 SU;

mV pH 7 Range 0 ± 50 ;

mV pH 4 Range $+180 \pm 50$;

mV pH 10 Range -180 ± 50 ;

If mV are recorded: slope from 7 to 10 174.1, slope from 4 to 7 179.7 (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water project)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification: 11/12/19

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: ; Date of last verification:

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass / Fail	Lab / Field
Pressure mode in air						P/F	L/F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria $\pm 5\%$ or ± 0.05 m, whichever is greater.

COMMENTS:

Date of Request: 09-DEC-2019
 Created By: BEARDEN_M On: 09-DEC-2019
 Modified By: JASROTIA_P On: 09-DEC-2019
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District:
 Sampling Event: Algal Bloom Response - SWD

Send Coolers To:

Phone: 813-470-5951
 13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden

Send Final Report To:

13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden

Program Module Number:

Priority: 1
 Event Status: A
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 09-DEC-2019
 Biology Request Reviewed By: JASROTIA_P On: 09-DEC-2019
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 09-DEC-2019
 Received By:

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Groups A/B - separate event, priority 1
 Bottle Group C - separate event, priority 12

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, and chlorophyll

Bottle Group C - Priority 12
 For algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Bottle Group A (Biological) With 1 Samples:

Bottle Type: PT-50ML Number of Bottles: 1 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 1 Samples:

Bottle Type: BP-1L Number of Bottles: 1 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: BG-250ML-WDMTH Number of Bottles: 1 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 1 Preserved With: ICE And H2SO4

W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L

W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L

W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L

W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 1 Preserved With: FILTER-ICE

W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.