

RQ-2020-03-02-59

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 9/9/2020 11:15

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.8				6		✓			1278 40199855

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☐

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☒Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 9/9/2020

Event contains NCRs (Y/N)? ☒

Event ID: Algal Bloom Response - CEROC
 WQAP-2020-09-09-01 (BLOOM-RESP)
 Date Received: 09-SEP-2020 11:15

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:11/5/20
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 exp: 11/1/22
Chlorine Test Strips	8261 exp: 07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

JKM 1144 9/9/20



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2020 - 03-02-59

Customer: FDEP/WQAP

Project ID: BLOOM-RESP

Location: IRL @ Pineda Causeway

Collected By:

Katie March, Victoria Schwartz

Field Report

Prepared By:

Katie March

Sampling Agency:

21FLCEN, CEROC

Comments:

Field ID:

HABCE 0040 - Indian River
(HABCE### Waterbody)

Coordinates: 28.20574, -80.66727

Collection Equip:

1329

WIN ID:

HABCE0040
(HABCE###)

High Tide Time:

402

Low Tide Time: 1908

Matrix:

Fresh Marine

Grab

Tide:

☒ Rising ☐ Falling ☐ Slack ☐ N/A

Water Quality

Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPT)
9/8/20	1430	214.7	14.06	32.4	8.71	0.300	0.6	0.2	31205	19.24

Bloom Observations

Algal Bloom Observed? ☒ Yes ☐ No

Water Surface ☒ Clear ☐ Scum ☐ Globes ☐ Slick

Water Clarity ☐ Clear ☒ Slightly Turbid ☒ Turbid ☐ Opaque

Bloom Color ☒ Green ☐ Red ☐ Brown ☐ Other: ☐ N/A

Algae Distribution ☒ Suspended in water column ☐ On surface ☐ Other: ☐ N/A

Water Odors ☒ Normal ☐ Sewage ☐ Petroleum ☐ Chemical ☐ Other:

Parameter Suite

Parameter Methods

Preservation

pH
Check

#Bottles
Sent to
Lab

Bottle
Group

Bloom ID (PT-50mL)

☒ BLOOM-ID

☐ Ice

Chlorophyll (BP-1L)

☒ CHLSUITE-W

☒ Ice

Toxins (BG-WD250)

☐ W-MCYST-AA

☒ Ice

Preserved Nutrients
(500mL HDPE)

☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP

☒ Ice

☐ H2SO4

☒ <2

Acid Lot:

H2SO4
LOT# SA8354050
EXP: 12/20/2020

Exp:

Filtered Nutrients
(P125mL)

☒ W-PO4-F

☒ Field Filtered 0.45µm Filter
Filter Lot #: 9149785

☒ Ice

Quantitative Algae

☒ DTY-QN-C / PKD-QN-C

☒ Ice

Lugols? ☒ Y ☐ N

Relinquished By:

Date/Time

Number of Coolers Shipped

Received By:

Date/Time

K March

9/8/20

1

IM

9/9/20 11:15

LIMS EVENT ID: WQAP-2020-

Enter Field Parameters, Verify Station ID in LIMS DMT:

QC Station ID, Field Parameters in LIMS DMT:

Scan/Save Field Sheets

Migrate Data to WIN:

Verify Data in WIN:

Printed: 9/9/2020 11:48:10 AM

Page 1 of 2

Date of Request: 13-FEB-2020
 Created By: AYALA_N On: 13-FEB-2020
 Modified By: JASROTIA_P On: 17-FEB-2020
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District: CEROC
 Event Description: Algal Bloom Response - CEROC

Send Coolers To:

Phone: 407-897-4180
 3319 Maguire Blvd
 Suite 232
 Orlando, FL 32803
 Attn: Natalie Ayala
 Cooler Ship EMail: Natalie.Ayala@FloridaDEP.gov

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 17-FEB-2020
 Biology Request Reviewed By: JASROTIA_P On: 17-FEB-2020
 Sampling Kit Required: YES Ship on: 21-FEB-2020
 Sampling Kit Shipped: YES On: 20-FEB-2020
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 02-MAR-2020
 Logged In By: KLUG_K On: 18-AUG-2020

Send Final Report To:

3319 Maguire Blvd
 Suite 232
 Orlando, FL 32806
 Attn: Natalie Ayala
 Report Notification EMail:
 natalie.ayala@dep.state.fl.us; kalina.warren@dep.state.fl.us;

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Groups A/B - separate event, priority 1
 Bottle Group C - separate event, priority 12

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, and chlorophyll

Bottle Group C - Priority 12
 For algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login.

Bottle Group A (Biological) With 2 Samples:

Bottle Type: PT-50ML Number of Bottles: 2 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 2 Samples:

Bottle Type: BP-1L Number of Bottles: 2 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: BG-250ML-WDMTH Number of Bottles: 2 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 2 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-125ML Number of Bottles: 2 Preserved With: FILTER-ICE
W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 2 Samples:

Bottle Type: BP-1L Number of Bottles: 2 Preserved With: Lugols
DTY-QN-C Template: DEFAULT (SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C Template: DEFAULT (SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.