

RQ-2020-10-09-60

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 11/3/2020 9:30

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.8				6		✓			92938006 8495

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes ☒ No _____

Containers intact? Yes _____ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No _____ NA _____ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 11/3/2020

Event contains NCRs (Y/N)? ☒

Event ID:

Algal Bloom Response - CEROC

WQAP-2020-11-03-02 (BLOOM-RESP)

Date Received: 03-NOV-2020 09:30

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/28/21
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 exp: 11/1/22
Chlorine Test Strips	8261 exp: 07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2020 - 10-05-60		Collected By: Natalie Ayala	
Customer:	FDEP/WQAP	Field Report Prepared By:	Natalie Ayala
Project ID:	BLOOM-RESP	Sampling Agency:	21FLCEN, CEROC
Location:		Comments:	

Field ID → HABCE0050_YalahaCanal
WIN → HABCE0050
Location: Yalaha Canal @ Lakeshore Dr

WIN ID:	(HABCE####)	Coordinates:	28.747394, -81.825659
Collection Equip:	Bottle	High Tide Time:	N/A
Low Tide Time:	N/A	Tide:	☐ Rising ☐ Falling ☐ Slack ☐ N/A
Matrix:	☒ Fresh ☐ Marine ☐ Grab		

Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPT)
11/2/2020	1500	127.1	10.92	22.9	8.22	0.3	0.6	0.6	275.5	0.13

Bloom Observations					
Algal Bloom Observed?	☒ Yes	☐ No			
Water Surface	☒ Clear	☐ Scum	☐ Globs	☐ Slick	
Water Clarity	☐ Clear	☒ Slightly Turbid	☐ Turbid	☐ Opaque	
Bloom Color	☒ Green	☐ Red	☐ Brown	☐ Other: _____	☐ N/A
Algae Distribution	☒ Suspended in water column	☐ On surface	☐ Other: _____	☐ N/A	
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum	☐ Chemical	☐ Other: _____

Parameter Suite	Parameter Methods	Preservation	pH Check	#Bottles Sent to Lab	Bottle Group
Bloom ID (PT-50mL)	☒ BLOOM-ID	☒ Ice		1	A
Chlorophyll (BP-1L)	☒ CHLSUITE-W	☒ Ice		1	B
Toxins (BG-WD250)	☒ W-MCYST-AA	☒ Ice		1	B
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP	☒ Ice ☒ H2SO4	☒ <2	1	B
Acid Lot:	SA 0037110	Exp:	02/07/21		
Filtered Nutrients (P125mL)	☒ W-PO4-F	☒ Field Filtered 0.45µm Filter	☒ Ice	1	B
Quantitative Algae	☒ DTY-QN-C / PKD-QN-C	☒ Ice	Lugols? Y/N	1	B

Relinquished By:	Date/Time	Number of Coolers Shipped	Received By:	Date/Time
<i>Natalie Ayala</i>	11/02/2020 1900	1	IM	11/3/20 9:30

* To match Bottles - IM 11/3/20

LIMS EVENT ID: WQAP-2020-

Enter Field Parameters, Verify Station ID in LIMS DMT: _____ QC Station ID, Field Parameters in LIMS DMT: _____
Scan/Save Field Sheets _____ Migrate Data to WIN: _____ Verify Data in WIN: _____

Date of Request: 21-SEP-2020
 Created By: AYALA_N On: 21-SEP-2020
 Modified By: JASROTIA_P On: 24-SEP-2020
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District: Central
 Event Description: Algal Bloom Response - CEROC

Send Coolers To:

Phone: 407-897-4178
 3319 Maguire Blvd Ste 232

 Orlando, FL 32803
 Attn: Natalie Ayala
 Cooler Ship Email: natalie.ayala@FloridaDep.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 24-SEP-2020
 Biology Request Reviewed By: JASROTIA_P On: 24-SEP-2020
 Sampling Kit Required: YES Ship on: 29-SEP-2020
 Sampling Kit Shipped: YES On: 28-SEP-2020
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 07-OCT-2020
 Logged In By:

Send Final Report To:

3319 Maguire Blvd Ste 232

 Orlando, FL 32803
 Attn: Natalie Ayala
 Report Notification Email: Natalie.Ayala@FloridaDEP.gov

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, chlorophyll, algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login

Bottle Group A (Biological) With 2 Samples:

Bottle Type: PT-50ML	Number of Bottles: 2	Preserved With: ICE
BLOOM-ID	Template: DEFAULT	(SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 2 Samples:

Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

Bottle Type: BG-250ML-WDMTH	Number of Bottles: 2	Preserved With: ICE
W-MCYST-AA	Template:	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.