

Login Checklist

RQ- 2020-10-19-58

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 11/ 13 /20 @ 9:40

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.4				19		✓			9293 8007 4950

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☒ No ☒ Init: [Signature]

Chlorine detected? (One container checked per Field ID)

Yes _____ No ☒ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No _____ NA _____ Init: _____

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ☒ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# 8514

Coolers Unpacked/Checked by: KK

Date: 11/ 13 /20

Event contains NCRs (Y/N)? Y

Event ID: Lake O Release SD
WQAP-2020-11-13-02 (LKORELEASE)

____ Date Received: 13-NOV-2020 09:40 _____

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	Temp Gun #5 EXP:10/28/2021
pH Test Strips 0 – 6	5/15/21 LOT#213316BV
pH Paper 0 – 3	
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ-2020-10-19-58		Collected By: FDEP SOROC GARY SINDRICK	
Customer: SO-DIST		Field Report Prepared By: JOHN BARRINGTON	
Project ID:		Sampling Agency: FDEP SOROC	
Location: S-77 LOC		Comments: PDY NOT FILTERED - PLEASE FILTER IN LAB	
Field ID: G3SD0171		Coordinates:	
		Collection Equip: BOTTLES	
WIN ID:		High Tide Time:	
Matrix: FRESH		Low Tide Time:	
Grab		Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A	

Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)
11/12/20	0955	45.7	3.7	25.1	6.98	0.3	1.9	0.5	250.6	0.12
11/12/20	0957	43.7	3.6	25.0	6.88	1.4	-	-	251.3	0.12

Bloom Observations					
Algal Bloom Observed? ☐ Yes ☒ No					
Water Surface	☒ Clear	☐ Scum	☐ Globs	☐ Slick	
Water Clarity	☐ Clear	☐ Slightly Turbid	☒ Turbid	☐ Opaque	
Bloom Color	☐ Green	☐ Red	☐ Brown	☐ Other: ☒ N/A	
Algae Distribution	☐ Suspended in water column		☐ On surface	☐ Other: ☒ N/A	
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum	☐ Chemical	☐ Other:

Parameter Suite	Parameter Methods	Preservation	pH Check	#Bottles Sent to Lab	Bottle Group
Bloom ID (PT-50mL)	☒ BLOOM-ID	☒ Ice		1	A
Chlorophyll (BP-1L)	☒ CHLSUITE-W	☒ Ice		1	C
Toxins (BG-WD250)	☒ W-MCYST-AA	☒ Ice		1	B
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP	☒ Ice ☒ H2SO4	☒ <2	1	B
	Acid Lot: SA9354050	Exp: 12/20/20			
Filtered Nutrients (P125mL)	☒ W-PO4-F	Field Filtered 0.45µm Filter	☒ Ice	1	B
Quantitative Algae	☒ DTY-QN-C / PKD-QN-C	☒ Ice	Lugols? Y (N)	1	B

Relinquished By: JOHN BARRINGTON	Date/Time: 11/12/20 1500	Number of Coolers Shipped: 1	Received By: KK	Date/Time: 11-13-20/0940
----------------------------------	--------------------------	------------------------------	-----------------	--------------------------

Date of Request: 15-OCT-2020
 Created By: RANKIN_A On: 15-OCT-2020
 Modified By: JASROTIA_P On: 15-OCT-2020
 Customer: WQAP
 Project: LKORELEASE
 Division:
 District:
 Event Description: Lake O Release SD

Send Coolers To:

Phone: 2393445719
 2295 Victoria Ave #364

 Ft. Myers, FL 33901
 Attn: Kirby Wolfe
 Cooler Ship Email: Kirby.Wolfe@FloridaDEP.gov

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 15-OCT-2020
 Biology Request Reviewed By: JASROTIA_P On: 15-OCT-2020
 Sampling Kit Required: YES Ship on: 16-OCT-2020
 Sampling Kit Shipped: YES On: 16-OCT-2020
 Sampling Kit Packed By: AYRES_J
 Preservatives Needed: NO
 Date to Receive Samples: 27-OCT-2020
 Logged In By: REYNOLDS_T On: 06-NOV-2020

Send Final Report To:

2600 Blair Stone Rd

 Tallahassee, FL 32399-2400
 Attn: Dave Whiting
 Report Notification Email: David.D.Whiting@FloridaDEP.gov

Comments: 4 locations, 1 bottle each: ALGAL-ID, toxins, nutrients, and full ID; 3 bottles each chlorophyll

All Bottle Groups - one event

Bottle Group A
 For algal dominant taxon

Bottle Group B
 For toxin texting, nutrients, full ID

Bottle Group C
 For chlorophyll

Please print two copies of algal job labels at login.

Bottle Group A (Biological) With 4 Samples:

Bottle Type: PT-50ML	Number of Bottles: 4	Preserved With: ICE
ALGAL_ID	Template: DEFAULT	(SOP-AB05) Qualitative assessment of algal taxa present without counts

Bottle Group B (Water) With 4 Samples:

Bottle Type: BP-1L	Number of Bottles: 4	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

Bottle Type: BG-250ML-WDMTH	Number of Bottles: 4	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML	Number of Bottles: 4	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 4	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 12 Samples:

Bottle Type: BP-1L	Number of Bottles: 12	Preserved With: ICE
--------------------	-----------------------	---------------------

Bottle Group C (Water) With 12 Samples:

Bottle Type: BP-1L

Number of Bottles: 12

Preserved With: ICE

CHLSUITE-W Template: DEFAULT

(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.