

Login Checklist

RQ- 2020-02-03-37

Login Station ID: #5

Shipping Method: FedEx | UPS (HD) | Greyhound

Date/Time of Receipt: 8/ 3 /20 @ 15:43

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
	YES	HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
3.3				6		✓			

***All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.**

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes _____ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ☒ Init: KK

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples:** pH < 2.0?

Yes _____ No _____ NA ☒ Init: KK

****W-1-4-DIOX** (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ☒ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK

Date: 8/ 3 /20

Event contains NCRs (Y/N)? N

Event ID:

Algal Bloom Response - NW ROC
WQAP-2020-08-03-02 (BLOOM-RESP)

Date Received: 03-AUG-2020 15:43

Login Checklist

Login Preservation Equipment

Infrared Thermometer ID:	IR TEMP GUN #5
pH Test Strips 0 – 6 Lot #	213316BV EXP:5-15-21
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	231019 EXP:11-1-22
Chlorine Test Strips Lot #	8261 EXP:07-2021

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

EV-06

RQ- 2020-02-03-37		Collected By:	M. King								
Customer:		Field Report Prepared By:	S. Slade								
Project ID:		Sampling Agency:	FDEP NW Roe								
Location:		Comments: 4140 Galiano Court Chipley 32428									
Field ID	HAB_BOAT_LAKE		Danielle Flickinger 850-832-4771 Ys2 prodlss 155077								
WIN ID	NWHAB0009		Coordinates:	30.53280 -85.60429							
Location: Boat Lake		Collection Equip:									
WIN ID:		High Tide Time:		Low Tide Time:							
Matrix:	Surface water	Grab	Tide:	☐ Rising ☐ Falling ☐ Slack ☒ N/A							
Water Quality											
Date	Time ☐ EST ☒ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)	
8/3	1150	111.2	807	32.2	5.71	0.3	25	1.5	11.9	0.00	
	1158	111.1	818	31.4	5.95	2.0	25	1.5	11.8	0.00	
Bloom Observations											
Algal Bloom Observed? ☐ Yes ☒ No											
Water Surface	☒ Clear	☐ Scum	☐ Globs	☐ Slick							
Water Clarity	☐ Clear	☒ Slightly Turbid	☐ Turbid	☐ Opaque							
Bloom Color	☐ Green	☐ Red	☐ Brown	☐ Other: _____	☐ N/A						
Algae Distribution	☐ Suspended in water column	☐ On surface	☐ Other: _____	☐ N/A							
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum	☐ Chemical	☐ Other: _____						
Parameter Suite	Parameter Methods		Preservation		pH Check	#Bottles Sent to Lab	Bottle Group				
Bloom ID (PT-50mL)	☒ BLOOM-ID		☒ Ice			1					
Chlorophyll (BP-1L)	☒ CHLSUITE-W		☒ Ice			1					
Toxins (BG-WD250)	☒ W-MCYST-AA		☒ Ice			1					
	☐ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP		☒ Ice ☒ H2SO4 ☒ <2								
Preserved Nutrients (500mL HDPE)	Acid Lot: 91354050		Exp: 12/20/20								
Filtered Nutrients (P125mL)	☒ W-PO4-F		☐ Field Filtered 0.45µm Filter		☐ Ice	1					
Quantitative Algae	☒ DTY-QN-C / PKD-QN-C		☒ Ice		Lugols? Y/(N)	1					
Relinquished By:	Date/Time	Number of Coolers Shipped		Received By:	Date/Time						
MIKE ECKLES	8/3	1		KH	8-3-20/1543						

Date of Request: 13-JAN-2020
 Created By: KING_M On: 13-JAN-2020
 Modified By: JASROTIA_P On: 13-JAN-2020
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District: Northwest
 Event Description: Algal Bloom Response - NW ROC

Send Coolers To:

Phone: 850-595-0605
 160 W Government St
 Suite 208
 Pensacola, FL 325602
 Attn: Michael King
 Cooler Ship EMail: michael.king@dep.state.fl.us

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 13-JAN-2020
 Biology Request Reviewed By: JASROTIA_P On: 13-JAN-2020
 Sampling Kit Required: YES Ship on: 24-JAN-2020
 Sampling Kit Shipped: YES On: 23-JAN-2020
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 03-FEB-2020
 Logged In By: SHAIK_A On: 28-JAN-2020

Send Final Report To:

2600 Blair Stone Rd
 MS #3560
 Tallahassee, FL 32399-2400
 Attn: Julie Espy
 Report Notification EMail:
 michael.king@dep.state.fl.us;cheryl.bunch@dep.state.fl.us;alicia.
 hogue@dep.state.fl.us;

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Groups A/B - separate event, priority 1
 Bottle Group C - separate event, priority 12

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, and chlorophyll

Bottle Group C - Priority 12
 For algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login.

Bottle Group A (Biological) With 4 Samples:

Bottle Type: PT-50ML Number of Bottles: 4 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 4 Samples:

Bottle Type: BP-1L Number of Bottles: 4 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: BG-250ML-WDMTH Number of Bottles: 4 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 4 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 4 Preserved With: FILTER-ICE

Bottle Group B (Water) With 4 Samples:

Bottle Type: P-125ML Number of Bottles: 4 Preserved With: FILTER-ICE
W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 4 Samples:

Bottle Type: BP-1L Number of Bottles: 4 Preserved With: Lugols
DTY-QN-C Template: DEFAULT (SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C Template: DEFAULT (SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.