

Login Checklist

RQ- **2020 - 02 - 10 - 30**

Login Station ID: **# 3**

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: **02-25-2020 / 16:37**

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
3.4C				6		X			

*All samples received on ice unless otherwise noted. If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), received without ice, or if Evidence Seal is damaged; identify the containers in the affected cooler(s) on back of this form. HNO3 and Formalin preserved samples do **NOT** have a temperature requirement. DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation; **An NCR still is required.**

Chain of Custody/ Field Sheet(s) Included? Yes **X No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No **X**

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

Evidence Tape on Bottles? Yes No **X If yes, is it intact? Yes No

Caps on tight? Yes **X No **Containers intact? Yes **X** No

Sufficient Sample Volume: Yes **X No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes No **X** Init: **ABS**

Chlorine detected? (One container checked per Field ID) Yes No Init: **ABS**

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

Acid Preserved Samples: pH ≤ 2.0? Yes **X No NA Init: **ABS**

W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA **X Init: **ABS**

Coolers Unpacked/Checked by: **ABS** / Date: **02-25-2020** NCRs (Y/N)? **N**

EventID: Algal Bloom Response - SWD NCR #
WQAP-2020-02-26-02 (BLOOM-RESP)

Samples with Incorrect pH Preservation

Field ID	Bottle TestID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle TestID(s)

Bottles Not Intact

Field ID	Bottle TestID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle TestID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	IR TG#3 EXP:11/05/2020
pH Test Strips 0 – 6 Lot #	2133AV EXP:05/15/2020
pH Paper 0 – 3 Lot #	220416A EXP:07/30/2020
pH Paper 0 – 13 Lot #	208717 EXP:03/31/2020
Chlorine Test Strips Lot #	8261 2021 / 07

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No x _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2020-02-10-30		Collected By:		M. Bearden						
Customer:	FDEP		Field Report Prepared By:	M. Bearden						
Project ID:	Bloom Response		Sampling Agency:	21FLTPA - SW ROC						
Location: WIN/Field ID			Comments:							
HAB-SW-0013 			Particulates suspended in water column							
Site Name: Lake Ariana - Near ramp			Coordinates:							
WIN ID:			Collection Equip: Bottles - Direct Grab							
Matrix: Fresh			High Tide Time: N/A Low Tide Time: N/A							
Grab			Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A							
Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPT)
2/25/20 1000	1000	100.4	9.21	19.6	7.85	0.3	2.5	0.5	229.8	0.11
2/25/20 1002	1002	97.1	8.93	19.4	7.81	2.0	2.5		230.1	0.11
Bloom Observations										
Algal Bloom Observed? ☒ Yes ☐ No										
Water Surface	☒ Clear	☐ Scum	☐ Globs	☐ Slick						
Water Clarity	☒ Clear	☐ Slightly Turbid	☐ Turbid	☐ Opaque						
Bloom Color	☒ Green	☐ Red	☐ Brown	☐ Other: _____	☐ N/A					
Algae Distribution	☒ Suspended in water column	☐ On surface	☐ Other: _____	☐ N/A						
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum	☐ Chemical	☐ Other: _____					
Parameter Suite	Parameter Methods		Preservation		pH Check	#Bottles Sent to Lab	Bottle Group			
Bloom ID (PT-50mL)	☒ BLOOM-ID		☒ Ice			1	A			
Chlorophyll (BP-1L)	☒ CHLSUITE-W		☒ Ice			1	B			
Toxins (BG-WD250)	☒ W-MCYST-AA		☒ Ice			1	B			
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP		☒ Ice	☒ H2SO4	☒ <2	1	B			
	Acid Lot:	SA 9301030	Exp:	10/28/20						
Filtered Nutrients (P125mL)	☒ W-PO4-F		☒ Field Filtered 0.45µm Filter		☒ Ice	1	B			
			Filter Lot #			1	C			
Quantitative Algae	☒ DTY-QN-C / PKD-QN-C		☒ Ice	Lugols? Y / N						
Relinquished By:	Date/Time	Number of Coolers Shipped		Received By:		Date/Time				
K. Parra	2/25/20 1637	1 - hand delivered		IM		2/25/20 16:37				

Jess Morse Bloom ID 2/25/2020 16:51

Date of Request: 21-JAN-2020
 Created By: BEARDEN_M On: 21-JAN-2020
 Modified By: JASROTIA_P On: 21-JAN-2020
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District:
 Sampling Event: Algal Bloom Response - SWD

Send Coolers To:

Phone: 813-470-5951
 13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden

Send Final Report To:

13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden

Program Module Number:
 Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 21-JAN-2020
 Biology Request Reviewed By: JASROTIA_P On: 21-JAN-2020
 Sampling Kit Required: YES Ship on: 31-JAN-2020
 Sampling Kit Shipped: YES On: 28-JAN-2020
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 10-FEB-2020
 Received By: SHAIK_A On: 26-FEB-2020

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Groups A/B - separate event, priority 1
 Bottle Group C - separate event, priority 12

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, and chlorophyll

Bottle Group C - Priority 12
 For algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Bottle Group A (Biological) With 8 Samples:

Bottle Type: PT-50ML Number of Bottles: 8 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 8 Samples:

Bottle Type: BP-1L Number of Bottles: 8 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: BG-250ML-WDMTH Number of Bottles: 8 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 8 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 8 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 8 Samples:

Bottle Type: BP-1L	Number of Bottles: 8	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.