

Login Checklist

RQ- 2020 - 03 - 30 - 08

Login Station ID: # 3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 06-11-2020 / 10:10

*Cooler Temperature	Samples Frozen?	* All Samples In Cooler Preserved with		Number of Sample Containers In Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.8C				5		X			1278 4014 3754

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: ABS/

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: ABS/

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes X No _____ NA _____ Init: ABS/

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA X Init: ABS/

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: ABS/

Date: 06-11-2020

Event contains NCRs (Y/N)? N

Event ID:

WQAP - 2020 - 06 - 11 - 014

Login Checklist

Login Preservation Equipment

Infrared Thermometer ID:	IRTG # 3 EXP:11/05/2020
pH Test Strips 0 – 6 Lot #	2133AV EXP:05/15/2020 ^{2021/AS/6/18/20}
pH Paper 0 – 3 Lot #	220416A EXP:07/31/2020
pH Paper 0 – 13 Lot #	231019 EXP:11/01/2022
Chlorine Test Strips Lot #	8261 2020/07

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2020-03-30-08		Collected By:	Francisco Farra							
Customer:	FDEP	Field Report Prepared By:	Kelley Callahan							
Project ID:	Bloom Response	Sampling Agency:	21FLTPA - SW ROC							
Location: WIN/Field ID HAB-SW-0016 		Comments:								
Site Name: Tiger Lake - Near Ramp		Coordinates:								
		Collection Equip:	Bottles - Direct Grab							
WIN ID:	-	High Tide Time:	←	Low Tide Time: -						
Matrix:	fresh	Grab	Tide:	☐ Rising ☐ Falling ☐ Slack ☒ N/A						
Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)
06-10-20	0940	132.3	9.99	29.8	9.13	0.3	1.3	0.3	134.0	0000
					SULFURIC ACID <51% Contains 1.1 H2SO4 May be corrosive to metals. Causes severe skin burns and eye damage. Do not breathe fumes/mist/vapors. Wash thoroughly after handling. Use only outdoors or in a well-ventilated area. Wear protective gloves/protective clothing/protective eyewear. Avoid contact with skin. Do not get inside clothing. If swallowed, do not induce vomiting. If on skin, do not rub. Remove contaminated clothing and shoes. If in eyes, flush cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Once rinsed or flushed, seek medical attention. Contains a constant temp line.					
Bloom Observations										
Algal Bloom Observed?		☒ Yes ☐ No								
Water Surface	☒ Clear	☐ Scum	☐ Globes	☐ Slick						
Water Clarity	☐ Clear	☐ Slightly Turbid	☒ Turbid	☐ Opaque						
Bloom Color	☒ Green	☐ Red	☐ Brown	☐ Other: _____	☐ N/A					
Algae Distribution	☒ Suspended in water column	☐ On surface	☐ Other: _____	☐ N/A						
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum	☐ Chemical	☐ Other: _____					
Parameter Suite	Parameter Methods		Preservation		pH Check	#Bottles Sent to Lab	Bottle Group			
Bloom ID (PT-50mL)	☒ BLOOM-ID		☒ Ice			1	A			
Chlorophyll (BP-1L)	☒ CHLSUITE-W		☒ Ice			1	B			
Toxins (BG-WD250)	☒ W-MCYST-AA		☒ Ice			1	B			
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP		☒ Ice ☒ H2SO4		☒ <2	1	B			
Acid Lot:		SA9354050		Exp:		12-20-20				
Filtered Nutrients (P125mL)	☒ W-PO4-F		☒ Field Filtered 0.45µm Filter		☒ Ice	1	B			
Filter Lot #										
Quantitative Algae	☒ DTY-QN-C / PKD-QN-C		☒ Ice		Lugols? Y / N	1	C			
Relinquished By:	Date/Time	Number of Coolers Shipped		Received By:	Date/Time					
M. Bearden	6/19/20 1500	1								

Date of Request: 18-FEB-2020
 Created By: BEARDEN_M On: 18-FEB-2020
 Modified By: JASROTIA_P On: 03-MAR-2020
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District:
 Sampling Event: Algal Bloom Response - SWD

Send Coolers To:

Phone: 813-470-5951
 13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden

Send Final Report To:

13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden

Program Module Number:
 Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 18-FEB-2020
 Biology Request Reviewed By: JASROTIA_P On: 03-MAR-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 30-MAR-2020
 Received By: SHAIK_A On: 11-JUN-2020

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Groups A/B - separate event, priority 1
 Bottle Group C - separate event, priority 12

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, and chlorophyll

Bottle Group C - Priority 12
 For algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Bottle Group A (Biological) With 4 Samples:

Bottle Type: PT-50ML Number of Bottles: 4 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 4 Samples:

Bottle Type: BP-1L Number of Bottles: 4 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: BG-250ML-WDMTH Number of Bottles: 4 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 4 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 4 Preserved With: FILTER-ICE
 W-PQ4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 4 Samples:

Bottle Type: BP-1L	Number of Bottles: 4	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.