

RQ- 2020-03-30-08

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | GreyhoundDate/Time of Receipt: 7/15/2020 11:20

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.8				6		✓			12784014 7749

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 °C (above 10.0 °C for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No _____ NA _____ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IMDate: 7/15/2020Event contains NCRs (Y/N)? N

Event ID: Algal Bloom Response - SWD
WQAP-2020-07-15-01 (BLOOM-RESP)
 Page 1 of 2, 0 Date Received: 15-JUL-2020 11:20

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:11/5/20
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	231019 exp: 11/1/22
Chlorine Test Strips	8261 exp: 07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2020-03-30-08		Collected By:	Kelby Callahan Sarah Meyer							
Customer:	FDEP	Field Report Prepared By:	Sarah Meyer							
Project ID:	Bloom Response	Sampling Agency:	21FLTPA - SW ROC							
WIN/Field ID		Comments:								
HAB-SW-0020										
Site Name: Lake Garfield - @ Ramp		Coordinates:								
		Collection Equip: Bottles - Direct Grab								
WIN ID: HAB-SW-0020		High Tide Time:		Low Tide Time:						
Matrix:	Fresh Water	Grab	Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A							
Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)
07/14/2020	1025	104.7	7.68	31.8	7.38	0.3	0.6	0.3	136.0	0.06
Bloom Observations										
Algal Bloom Observed?		☒ Yes ☐ No								
Water Surface	☒ Clear	☐ Scum	☐ Globbs		☐ Slick					
Water Clarity	☐ Clear	☒ Slightly Turbid	☐ Turbid		☐ Opaque					
Bloom Color	☐ Green	☐ Red	☒ Brown		☐ Other: _____		☐ N/A			
Algae Distribution	☒ Suspended in water column		☐ On surface		☐ Other: _____		☐ N/A			
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum		☐ Chemical		☐ Other: _____			
Parameter Suite	Parameter Methods				Preservation		pH Check	#Bottles Sent to Lab	Bottle Group	
Bloom ID (PT-50mL)	☒ BLOOM-ID				☒ Ice			1	A	
Chlorophyll (BP-1L)	☒ CHLSUITE-W				☒ Ice			1	B	
Toxins (BG-WD250)	☒ W-MCYST-AA				☒ Ice			1	B	
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP				☒ Ice	☒ H2SO4	☒ <2	1	B	
	Acid Lot: SA9354050		Exp: 12/20/20							
Filtered Nutrients (P125mL)	☒ W-PO4-F		☒ Field Filtered 0.45µm Filter		☒ Ice			1	B	
Quantitative Algae	☒ DTY-QN-C / PKD-QN-C				☒ Ice		Lugols? Y/N	1	C	
Relinquished By:	Date/Time		Number of Coolers Shipped		Received By:		Date/Time			
Sarah Meyer	07/14/2020 1600		1		IM		7/15/20 11:20			

Contains: 1:1 H2SO4
Lot No.: SA9354050
Expires: 12/20/20
See Safety Data Sheet (SDS)

THANKO FISHER SCIENTIFIC
520 NORTH MAIN STREET
MADEIRA, CA 94554
415-665-2711
773-144
SULFURIC
ACID <51%
H2SO4
They are extremely corrosive. Causes severe skin burns and eye damage. Do not breathe vapors or dusts. May cause respiratory irritation. May cause dizziness or headache. May cause nausea and vomiting. Do not get inside clothing. Wash contaminated clothing before reuse. Avoid contact with skin and eyes. If contact occurs, flush with water for 15 minutes. If contact occurs with eyes, flush with water for 15 minutes. If contact occurs with clothing, remove clothing immediately. If contact occurs with skin, wash with soap and water. If contact occurs with eyes, flush with water for 15 minutes. If contact occurs with clothing, remove clothing immediately. If contact occurs with skin, wash with soap and water. If contact occurs with eyes, flush with water for 15 minutes.

Date of Request: 18-FEB-2020
 Created By: BEARDEN_M On: 18-FEB-2020
 Modified By: JASROTIA_P On: 03-MAR-2020
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District:
 Event Description: Algal Bloom Response - SWD

Send Coolers To:

Phone: 813-470-5951
 13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden
 Cooler Ship EMail: matthew.bearden@dep.state.fl.us

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 18-FEB-2020
 Biology Request Reviewed By: JASROTIA_P On: 03-MAR-2020
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 30-MAR-2020
 Logged In By: SHAIK_A On: 10-JUL-2020

Send Final Report To:

13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden
 Report Notification EMail:
 matthew.bearden@dep.state.fl.us; kalina.warren@dep.state.fl.us;

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Groups A/B - separate event, priority 1
 Bottle Group C - separate event, priority 12

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, and chlorophyll

Bottle Group C - Priority 12
 For algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Bottle Group A (Biological) With 4 Samples:

Bottle Type: PT-50ML	Number of Bottles: 4	Preserved With: ICE
BLOOM-ID	Template: DEFAULT	(SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 4 Samples:

Bottle Type: BP-1L	Number of Bottles: 4	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: BG-250ML-WDMTH	Number of Bottles: 4	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 4	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 4	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 4 Samples:

Bottle Type: BP-1L	Number of Bottles: 4	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.