

RQ-2020-03-23-45

Login Checklist

Login Station ID: #4

Shipping Method: FedEx UPS | HD | GreyhoundDate/Time of Receipt: 12/30/2020 @ 9:50

*Cooler Temperature	Samples Frozen?	* All Samples In Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
6.0°C				6					9293 8008 8188

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: Tyler

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: Tyler**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: Tyler

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: TylerDate: 12/30/2020Event contains NCRs (Y/N)? NA

Event ID: _____

Algal Bloom Response - SE ROC
 WQAP-2020-12-30-02 (BLOOM-RESP)
 Date Received: 30-DEC-2020 09:50
 Federal Emergency Response Team

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:10/28/2021
pH Test Strips 0 – 6	N/A
pH Paper 0 – 3	N/A
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: WQAP

Project ID: BLOOM-RESP

Requester: Jordan Skaggs

Collected By: Alex Miranda

Field Report Prepared By: Alex Miranda

Sampling Agency: 21 FLWBB

Location <u>Lake Melva</u>		☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>12/28/20</u> Time <u>1550</u>		☒ Eastern ☐ Central	Composite end Date _____ Time _____		Bottle Group(s) (See pg 2) <u>A,B,C</u>
Field ID <u>Lake Melva</u>		Matrix (type, e.g., Salt, Fresh, etc) <u>Fresh</u>		Diss. Oxygen <u>7.74</u>	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C) <u>20.8</u>	pH <u>8.04</u>	Sample Depth <u>0.3</u>	☐ ft ☒ m	Sp. Conductance (umho/cm) <u>282.0</u>		
Latitude <u>26.147923</u>	☒ dd ☐ dms	Longitude <u>-80.120165</u>	☒ dd ☐ dms	Salinity (ppt) <u>0.13</u>	Comments			

Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____		☐ Eastern ☐ Central	Composite end Date _____ Time _____		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			

Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____		☐ Eastern ☐ Central	Composite end Date _____ Time _____		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			

Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date _____ Time _____		☐ Eastern ☐ Central	Composite end Date _____ Time _____		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			

Relinquished By: <u>Alex Miranda</u>	Date/Time <u>12/28/20 17:30</u>	Shipping Method <u>FedEx</u>	Number of Coolers Shipped: <u>1</u>	Received By: <u>Tyler Reynolds</u>	Date/Time <u>12/30/2020</u>
---	------------------------------------	---------------------------------	--	---------------------------------------	--------------------------------

9.56

Group: A	Bottle Type:	PT-50ML	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
BLOOM-ID							
Group: B	Bottle Type:	BP-1L	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
CHLSUITE-W							
Group: B	Bottle Type:	BG-250ML-WDMT H	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
W-MCYST-AA							
Group: B	Bottle Type:	P-500ML	# of Bottles: 4	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
W-NH3							
W-NO2NO3							
W-S-A-TP							
W-TKN							
Group: B	Bottle Type:	P-125ML	# of Bottles: 4	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
W-PO4-F							
Group: C	Bottle Type:	BP-1L	# of Bottles: 4	Preservative:	Lugols	Enter Number of Bottles Sent to Lab	1
DTY-QN-C							
PKD-QN-C							