

RQ-2021-07-26-26

Login Checklist

Login Station ID: #2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 8/11/2021 9:10

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
0.1				5					929380156163

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☐Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: IM

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No ☐ NA ☐ Init: IM

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes ☐ No ☐ NA ☒ Init: IM

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: IM

Date: 8/11/2021

Event contains NCRs (Y/N)? ☒

Event ID: Algal Bloom Response- NEROC
 WQAP-2021-08-11-01 (BLOOM-RESP)
 Date Received: 11-AUG-2021 09:10

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #2 exp:10/28/21
pH Test Strips 0 – 6	
pH Paper 0 – 3	
pH Paper 0 – 13	219019 exp: 7/1/22
Chlorine Test Strips	0129 exp: 03/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Cyanobacteria Bloom Response Field Data Sheet

2021 RQ-2019-07-26-26		Collected By:	B. Davis, J. Lee
Customer	WQMP	Field Report Prepared By:	B. Davis
Project ID:	BLOOM_RESP	Sampling Agency:	FDEP

WIN ID/Field ID:



20030518

GOODBYS CR @ SR-13

Comments:

Collection Equipment:

0-HO #3

Matrix:

SW

Grab

Coordinates:

30.2159, -81.6161

Tide:

☐ Rising

☒ Falling

☐ Slack

☐ N/A

High Tide Time:

1340

Low Tide Time:

Water Quality

Date	Time	D.O. (mg/L)	D.O. (%)	Temp °C	pH (SU)	Sample Depth (m)	Cond. (umho/cm)	Salinity (PPT)	Secchi Disk (m)	Total Depth (m)
8/10/21	1500	6.36	84.8	31.0	7.29	0.3	428.4	0.20	0.7	1.398 1.420

Bloom Observations

Algal Bloom Observed? ☐ Yes ☒ No

Water Surface ☒ Clear ☐ Scum ☐ Globbs ☐ Slick
 Water Clarity ☒ Clear ☐ Slightly Turbid ☐ Turbid ☐ Opaque
 Bloom Color ☐ Green ☐ Red ☐ Brown ☐ Other: _____
 Algae Distribution ☐ Suspended in water column ☐ On surface ☐ Other: _____
 Water Odors ☒ Normal ☐ Sewage ☐ Petroleum ☐ Chemical ☐ Other: _____

Parameter Suite	Parameter Methods	Preservation	pH Check	#Bottles Sent to Lab	Bottle Group
Bloom ID (PT-50ML)	☒ BLOOM-ID	☒ Ice		1	A
Chlorophyll (BP-1L)	☒ CHLSUITE-W	☒ Ice		1	B
Toxins (BG-WD250)	☒ W-MCYST-AA	☒ Ice		1	B
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP	☒ Ice ☒ H2SO4	☒ <2	1	B
	Lot SA0353110	Exp: 1/11/22	☒ 32		
Filtered Nutrients (P125mL)	☒ W-PO4-F ☒ Field Filtered 0.45um Filter	☒ Ice		1	B
Quantitative Algae	☐ DTY-QN-C / PKD-QN-C	☐ Ice ☐ Lugols			

Relinquished By:

Date/Time

Number of Coolers Shipped

Received By:

Date/Time

B. Davis 1600 8/10/21

1

IM 8/11/21

CALIBRATION AND VERIFICATION LOG (FDEP SOP FT 1000-FT 1500, FD 1000-FD 4000)

Boldly "X" this box if there are qualified data on this page.

Meter ID: Desi RQ- 2021-08-02-YY Project: SMP Greenville

- Notes: (1) Always wait for meter to stabilize before recording any readings.
 (2) Report all digits displayed. Do not round before reporting measurements. (See special instructions for depth).
 (3) For Calibrations, record calibrated meter reading. Do not record initial meter reading before calibration.

Temperature (Quarterly) FT 1400

Date of Last Temperature Verification 7/8/21

DO DEP SOP FT 1500	Name	Date	Time CT-ET	Temp °C	Baro- meter mmHg	D.O. Chart mg/L	Meter D.O. mg/L	% DO	Probe Charge	Probe Gain	Pass / Fail	Lab / Field
Calibr.	Brian Davis	8/10/21	807	22.1	765.1	8.8	8.8	100.7	/	1.07	P/F	L/F
ICV			811	21.9	765.1	8.8	8.83	100.7	/	1.07	P/F	L/F
CCV	J. Lee		1603	24.7	7638	8.4	8.37	100.7	-	1.07	P/F	L/F
CCV											P/F	L/F

DO Acceptance criteria from Table ± 0.3 mg/L.

Rapid-Pulse Sensors: DO Gain Range 0.7 to 1.4; DO Charge Range 25-75.

Optical: DO gain range 0.85 to 1.15 (Pro DSS 0.75 to 1.50); DO charge N/A. Steady-state & Galvanic Sensors: DO Gain & Charge N/A.

Spec. Cond. FT 1200	Name	Date	Time CT-ET	Lot #	Expir. Date	Standard μ hos/cm	Meter Reading μ hos/cm	Pass / Fail	Lab / Field
Calibr.	Brian Davis	8/10/21	801	210426B	5/22	1000	1000	P/F	L/F
ICV			803	210426A	5/22	100	102.6	P/F	L/F
CCV	J. Lee		1606	210426C	5/22	1413	1407	P/F	L/F
CCV								P/F	L/F

Conductivity Acceptance criteria $\pm 5\%$

pH DEP SOP FT 1100	Name	Date	Time CT-ET	Lot #	Expir. Date	pH Buffer SU	Temp °C	Meter reading SU	mV	Pass / Fail	Lab / Field
Calibr.	Brian Davis	8/10/21	816	2012E39	12/22	7.02	22.4	7.01	-16.1	P/F	L/F
Calibr.			822	2103659	3/23	4.00	22.8	4.00	162.6	P/F	L/F
Calibr.			825	2107A04	12/22	10.02	22.8	10.03	198.2	P/F	L/F
ICV			829	2104E81	4/23	7.01	22.7	7.02	-19.4	P/F	L/F
CCV	J. Lee		1609	2107A04	12/22	10.02	22.7	10.11	-19.0	P/F	L/F
CCV										P/F	L/F

pH Acceptance criteria ± 0.2 SU; mV pH 7 Range 0 ± 50 ;

mV pH 4 Range $+180 \pm 50$;

mV pH 10 Range -180 ± 50 ;

If mV are recorded: slope from 7 to 10 172.1, slope from 4 to 7 178.2 (both must be between 165 and 180 mV)

Does meter have a depth sensor that will be used to measure total depth & sample depth? YES / NO / NA (not surf. water project)

If YES, complete daily Calibr. & ICV below and list date of last quarterly depth verification: 5/18/21

If NO, what will be used? (circle one) Secchi Disk Line / Sonar Unique ID: _____; Date of last verification: _____

Depth Sensor (Daily Calibration & ICV)	Name	Date	Time CT-ET	Calibrated Value (0.00 or Offset), meters	ICV Value, meters	Pass / Fail	Lab / Field
Pressure mode in air	Brian Davis	8/10/21	833	0.00	0.00	P/F	L/F

Report two decimal places. Round numbers ≤ 4 down, ≥ 5 up. ICV acceptance criteria $\pm 5\%$ or ± 0.05 m, whichever is greater.

COMMENTS:

Date of Request: 25-JUN-2021
 Created By: PARRISH_J On: 25-JUN-2021
 Modified By: JASROTIA_P On: 02-JUL-2021
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District:
 Event Description: Algal Bloom Response- NERO

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way West

 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Cooler Ship EMail: Jeremy.M.Parrish@dep.state.fl.us

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 30-JUN-2021
 Biology Request Reviewed By: JASROTIA_P On: 02-JUL-2021
 Sampling Kit Required: YES Ship on: 16-JUL-2021
 Sampling Kit Shipped: YES On: 14-JUL-2021
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 26-JUL-2021
 Logged In By: REYNOLDS_T On: 10-AUG-2021

Send Final Report To:

8800 Baymeadows Way West

 Jacksonville, FL 32256
 Attn: Jeremy Parrish
 Report Notification EMail:
 Jeremy.M.Parrish@dep.state.fl.us; Alicia.Hogue@dep.state.fl.us;
 Amelia.Rankin@dep.state.fl.us

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, and chlorophyll

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login.

Bottle Group A (Biological) With 4 Samples:

Bottle Type: PT-50ML	Number of Bottles: 4	Preserved With: ICE
BLOOM-ID	Template: DEFAULT	(SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 4 Samples:

Bottle Type: BP-1L	Number of Bottles: 4	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: BG-250ML-WDMTH	Number of Bottles: 4	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 4	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 4	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.