

Chemical Analysis Report

WQAP-2021-08-13-02

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780


Event Description: **Algal Bloom Response - CEROC**
Request ID: **RQ-2021-06-21-09**
Customer: **WQAP**
Project ID: **BLOOM-RESP**

Send Reports to:
FL Dept. of Environmental Protection
3319 Maguire Blvd Ste 232
Orlando, FL 32803
Attn: Leif Boman

For additional information please contact
Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Colin Wright, Program Administrator

Date Certified: 08-SEP-2021 08:48

A handwritten signature in black ink, appearing to read "Colin Wright", is displayed on a light gray rectangular background.

Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Kissimmee River - 650m S of US 60

Collection Date/Time: 08/12/2021 12:50

Field ID: HABCE0090_KissimmeeRiver

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2269399	EPA 8321B	Anatoxin-a	0.25	U	ug/L	P402452	
		Cylindrospermopsin	0.10	U	ug/L	P402452	
		Desmethyl microcystin LR	0.25	U	ug/L	P402452	
		Microcystin HIR**	0.25	U	ug/L	P402452	
		Microcystin HtyR**	0.25	U	ug/L	P402452	
		Microcystin LA	0.10	U	ug/L	P402452	
		Microcystin LF	0.10	U	ug/L	P402452	
		Microcystin LR	0.30	I	ug/L	P402452	
		Microcystin LW	0.25	U	ug/L	P402452	
		Microcystin LY	0.10	U	ug/L	P402452	
		Microcystin RR	0.10	U	ug/L	P402452	
		Microcystin WR	0.50	U	ug/L	P402452	
		Microcystin YR	0.25	U	ug/L	P402452	
		Nodularin-R**	0.10	U	ug/L	P402452	
2269400	EPA 350.1 Rev. 2.0	Ammonia-N	0.008		mg N/L	P402707	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	1.0		mg N/L	P403019	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.004	U	mg N/L	P402630	
	EPA 365.1 Rev. 2.0	Total-P	0.072		mg P/L	P402562	
2269401	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.004	U	mg P/L	P402471	MS

Ref. Method and Comment:

EPA 351.2 Rev. 2.0: Batch matrix spike recoveries are unavailable because of high analyte concentration in the QC sample.

Quality Assurance Report Method Blank Results

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P402707

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P403019

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P402630

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P402562

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P402471

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8321B
Batch ID: P402452

Component	Result	Code	Units
Anatoxin-a	0.25	U	ug/L
Cylindrospermopsin	0.10	U	ug/L
Desmethyl microcystin LR	0.25	U	ug/L
Microcystin HlIR	0.25	U	ug/L
Microcystin HtyR	0.25	U	ug/L
Microcystin LA	0.10	U	ug/L
Microcystin LF	0.10	U	ug/L
Microcystin LR	0.25	U	ug/L
Microcystin LW	0.25	U	ug/L
Microcystin LY	0.10	U	ug/L
Microcystin RR	0.10	U	ug/L
Microcystin WR	0.50	U	ug/L
Microcystin YR	0.25	U	ug/L
Nodularin-R	0.10	U	ug/L

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P402707

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	98.6		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P403019

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	103		P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P402630

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	100		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P402562

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	108		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P402471

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	99.4		P	90 - 110

Reference Method: EPA 8321B
Batch ID: P402452

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Anatoxin-a	101		P	40 - 150
Cylindrospermopsin	94.1		P	40 - 150
Desmethyl microcystin LR	115		P	40 - 150
Microcystin HIR	117		P	40 - 150
Microcystin HtyR	118		P	40 - 150
Microcystin LA	135		P	40 - 150
Microcystin LF	118		P	40 - 150
Microcystin LR	108		P	40 - 150
Microcystin LW	110		P	40 - 150
Microcystin LY	107		P	40 - 150
Microcystin RR	107		P	40 - 150
Microcystin WR	120		P	40 - 150
Microcystin YR	110		P	40 - 150
Nodularin-R	109		P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 350.1 Rev. 2.0

Batch ID: P402707

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2269295	Ammonia-N	97.2	97.4	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0

Batch ID: P402630

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2269337	NO2NO3-N	98.0	99.0	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P402562

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2269418	Total-P	115	111	F/F	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Batch ID: P402471

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2269477	O-Phosphate-P	99.0	98.4	P/P	90 - 110

Reference Method: EPA 8321B

Batch ID: P402452

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2269369	Anatoxin-a	108	106	P/P	40 - 150
2269369	Cylindrospermopsin	101	102	P/P	40 - 150
2269369	Desmethyl microcystin LR	132	121	P/P	40 - 150
2269369	Microcystin HilR	126	123	P/P	40 - 150
2269369	Microcystin HtyR	125	121	P/P	40 - 150
2269369	Microcystin LA	138	115	P/P	40 - 150
2269369	Microcystin LF	121	106	P/P	40 - 150
2269369	Microcystin LR	108	117	P/P	40 - 150
2269369	Microcystin LW	119	118	P/P	40 - 150
2269369	Microcystin LY	117	104	P/P	40 - 150
2269369	Microcystin RR	107	104	P/P	40 - 150
2269369	Microcystin WR	130	122	P/P	40 - 150
2269369	Microcystin YR	116	117	P/P	40 - 150
2269369	Nodularin-R	110	107	P/P	40 - 150

Quality Assurance Report Precision

Reference Method: EPA 350.1 Rev. 2.0

Batch ID: P402707

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2269295	Ammonia-N	0.206	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0

Batch ID: P403019

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2269342	Kjeldahl Nitrogen	4.88	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0

Batch ID: P402630

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2269337	NO2NO3-N	1.02	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P402562

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2269418	Total-P	2.81	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Batch ID: P402471

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2269477	O-Phosphate-P	0.608	Spike	P	0 - 20

Reference Method: EPA 8321B

Batch ID: P402452

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2269369	Anatoxin-a	1.54	Spike	P	0 - 30
2269369	Cylindrospermopsin	0.634	Spike	P	0 - 30
2269369	Desmethyl microcystin LR	8.24	Spike	P	0 - 30
2269369	Microcystin H1LR	2.68	Spike	P	0 - 30
2269369	Microcystin HtyR	2.91	Spike	P	0 - 30
2269369	Microcystin LA	18.3	Spike	P	0 - 30
2269369	Microcystin LF	12.9	Spike	P	0 - 30
2269369	Microcystin LR	7.66	Spike	P	0 - 30
2269369	Microcystin LW	0.685	Spike	P	0 - 30
2269369	Microcystin LY	11.0	Spike	P	0 - 30
2269369	Microcystin RR	2.57	Spike	P	0 - 30
2269369	Microcystin WR	6.59	Spike	P	0 - 30
2269369	Microcystin YR	1.53	Spike	P	0 - 30
2269369	Nodularin-R	2.95	Spike	P	0 - 30

Quality Assurance Report Precision

* Sample, spike and/or laboratory control sample precision (LCS) is reported.

Quality Assurance Report Surrogates

Lab Sample ID: 2269399

Field Sample ID: HABCE0090_KissimmeeRiver

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	Microcystin LR-d7	109	P	30 - 160
EPA 8321B	Microcystin LR ethyl-d5	79.6	P	30 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A107247

Included Lab Sample IDs: 2269401

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	99.2	98.3	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A107299

Included Lab Sample IDs: 2269399

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Anatoxin-a	99.2	101	P/P	50 - 160
Cylindrospermopsin	98.7	100	P/P	60 - 160
Desmethyl microcystin LR	113	119	P/P	60 - 160
Microcystin HIR	115	115	P/P	60 - 160
Microcystin HtyR	112	122	P/P	60 - 160
Microcystin LA	108	126	P/P	50 - 160
Microcystin LF	99.6	113	P/P	60 - 160
Microcystin LR	109	115	P/P	60 - 160
Microcystin LW	115	105	P/P	60 - 160
Microcystin LY	110	129	P/P	60 - 160
Microcystin RR	103	106	P/P	60 - 160
Microcystin WR	113	115	P/P	60 - 160
Microcystin YR	102	106	P/P	60 - 160
Nodularin-R	105	108	P/P	60 - 160

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A107311

Included Lab Sample IDs: 2269400

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	101	100	P/P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A107342

Included Lab Sample IDs: 2269400

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	98.9	98.7	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A107424

Included Lab Sample IDs: 2269400

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	107	105	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A107508

Included Lab Sample IDs: 2269400

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	96.1	96.3	P/P	90 - 110

Quality Assurance Report

Calibration Verification

* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.

Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		LCS	Precision	MS
						SMP	
EPA 350.1 Rev. 2.0	Ammonia-N	98.6	97.2	97.4			0.206
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	103					4.88
EPA 353.2 Rev. 2.0	NO ₂ NO ₃ -N	100	98.0	99.0			1.02
EPA 365.1 Rev. 2.0	Total-P	108	115	111			2.81
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	99.4	99.0	98.4			0.608
EPA 8321B	Anatoxin-a	101	108	106			1.54
	Cylindrospermopsin	94.1	101	102			0.634
	Desmethyl microcystin LR	115	132	121			8.24
	Microcystin HiLR	117	126	123			2.68
	Microcystin HtyR	118	125	121			2.91
	Microcystin LA	135	138	115			18.3
	Microcystin LF	118	121	106			12.9
	Microcystin LR	108	108	117			7.66
	Microcystin LW	110	119	118			0.685
	Microcystin LY	107	117	104			11.0
	Microcystin RR	107	107	104			2.57
	Microcystin WR	120	130	122			6.59
	Microcystin YR	110	116	117			1.53
	Nodularin-R	109	110	107			2.95

Reference Method Descriptions

Method	Description	<u>Associated Samples</u>
EPA 350.1 Rev. 2.0	Ammonia in aqueous matrices as mg N/L	2269400
EPA 351.2 Rev. 2.0	Total Kjeldahl Nitrogen in aqueous matrices	2269400
EPA 353.2 Rev. 2.0	Nitrite/Nitrate in aqueous matrices as mg N/L	2269400
EPA 365.1 Rev. 2.0	Total Phosphorus in aqueous matrices as mg P/L	2269400
EPA 365.1 Rev. 2.0 dissolved	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	2269401
EPA 8321B	Microcystins in water matrices by HPLC/MS/MS	2269399

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 350.1 Rev. 2.0	08/13/2021			08/19/2021 13:39	Roberta Tatti	2269400
EPA 351.2 Rev. 2.0	08/13/2021	08/26/2021 13:43	Benjamin T. Nordmann	08/27/2021 10:51	Virginia P. Brown	2269400
EPA 353.2 Rev. 2.0	08/13/2021			08/18/2021 13:01	Beverly Y. Sanders	2269400
EPA 365.1 Rev. 2.0	08/13/2021	08/17/2021 14:55	Simonne.V. Calhoun	08/24/2021 11:18	Lipi Saha	2269400
EPA 365.1 Rev. 2.0 dissolved	08/13/2021			08/13/2021 15:10	Blanca Fach	2269401
EPA 8321B	08/13/2021	08/17/2021 11:00	Pramila Ghimire	08/17/2021 15:02	Pramila Ghimire	2269399