

RQ-2021-01-25-21

Login Checklist

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | GreyhoundDate/Time of Receipt: 01/28/2021 @ 11:15

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.6°C				6		X			9293 8008 4940

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes X No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: Jylyup

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ✓ No _____ NA _____ Init: Jylyup

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA X Init: Jylyup

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: Jylyup ReynoldsDate: 01/28/2021Event contains NCRs (Y/N)? none

Event ID:

Algal Bloom Response - CERUC
WQAP-2021-01-28-01 (BLOOM-RESP)

Date Received: 28-JAN-2021 10:15

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	#4 Temp Gun EXP:10/28/2021
pH Test Strips 0 – 6	N/A
pH Paper 0 – 3	N/A
pH Paper 0 – 13	231019 EXP:11/01/2022
Chlorine Test Strips	8261 EXP:07/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2020-01-25-21	Collected By: Mike Linger, Orange Co. EPD
Customer: WQAP	Field Report Prepared By:
Project ID: BLOOM-RESP	Sampling Agency: 21FLCEN - CEROC

SULFURIC ACID >51%
DANGER
7584-99-9
7732-18-5
THERMO FISHER SCIENTIFIC
200 NORTH MAIN STREET
MAINE, ME 04101
1-800-455-2711
Contains: Conc. H2SO4
May be hazardous to health. Causes severe skin burns and eye damage. Do not breathe dusts, fumes, mists, vapors, or gases. Do not get in eyes, on clothing, or on skin. If in eyes, flush with plenty of water for at least 15 minutes. If on clothing, remove contaminated clothing. Wash contaminated skin thoroughly with water. If swallowed, drink water. Do not induce vomiting. IF ON SKIN (or hair): Remove/Take off all contaminated clothing. Rinse skin with water. If inhaled: Remove victim to fresh air and rest. If breathing is difficult, use oxygen. If breathing has stopped, use artificial respiration. If contact lenses, if present and easy to do, continue to wear. Store locked up. Store in corrosion resistant container with a resistant inner liner.

Contains: Conc. H2SO4
Lot No.: SA0293040
Expires: 10/19/21
See Safety Data Sheet (SDS)

Field ID: HABCE0031_Cypress1
Win ID: HABCE0031
Cypress Lake Boat Ramp at NW Shore

Comments:	Coordinates: 28.481590, -81.569041	
Collection Equip:	Water Bottle	
High Tide Time:	Low Tide Time:	
Matrix: SW	Grab	Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A

Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPT)
1/27/21	1125	89.1	8.1	19.9	7.2	0.5	1.5	1.1	292	

Bloom Observations					
Algal Bloom Observed?	☒ Yes	☐ No			
Water Surface	☐ Clear	☐ Scum	☒ Globs	☐ Slick	
Water Clarity	☒ Clear	☐ Slightly Turbid	☐ Turbid	☐ Opaque	
Bloom Color	☒ Green	☐ Red	☐ Brown	☐ Other:	☐ N/A
Algae Distribution	☒ Suspended in water column	☒ On surface	☐ Other:		☐ N/A
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum	☐ Chemical	☐ Other:

Parameter Suite	Parameter Methods	Preservation	pH Check	#Bottles Sent to Lab	Bottle Group
Bloom ID (PT-50mL)	☒ BLOOM-ID	☒ Ice		1	A
Chlorophyll (BP-1L)	☐ CHLSUITE-W	☐ Ice		1	B
Toxins (BG-WD250)	☐ W-MCYST-AA	☐ Ice		1	B
Preserved Nutrients (500mL HDPE)	☐ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP	☐ Ice ☐ H2SO4	☒ <2	1	B
Filtered Nutrients (P125mL)	☒ W-PO4-F	☒ Field Filtered 0.45µm Filter		1	B
Quantitative Algae	☒ DTY-QN-C / PKD-QN-C	☒ Ice		1	B
Relinquished By:	Date/Time	Number of Coolers Shipped	Received By:	Date/Time	
Mike Linger (OC)	1/27/21 1600	1			

Date of Request: 04-JAN-2021
 Created By: BOMAN_L On: 04-JAN-2021
 Modified By: JASROTIA_P On: 11-JAN-2021
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District: Central
 Event Description: Algal Bloom Response - CEROC

Send Coolers To:

Phone: 407-897-4178
 3319 Maguire Blvd Ste 232

 Orlando, FL 32803
 Attn: Natalie Ayala
 Cooler Ship EMail: natalie.ayala@FloridaDep.gov

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 11-JAN-2021
 Biology Request Reviewed By: JASROTIA_P On: 11-JAN-2021
 Sampling Kit Required: YES Ship on: 15-JAN-2021
 Sampling Kit Shipped: YES On: 12-JAN-2021
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 25-JAN-2021
 Logged In By: KLUG_K On: 19-JAN-2021

Send Final Report To:

3319 Maguire Blvd Ste 232

 Orlando, FL 32803
 Attn: Natalie Ayala
 Report Notification EMail: Natalie.Ayala@FloridaDEP.gov

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, chlorophyll, algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login

Bottle Group A (Biological) With 2 Samples:

Bottle Type: PT-50ML Number of Bottles: 2 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample
 *Dominant sample taxon

Bottle Group B (Water) With 2 Samples:

Bottle Type: BP-1L Number of Bottles: 2 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
 Chlorophyll-a, Corrected
 Chlorophyll-a, Uncorrected
 Phaeophytin-a

Bottle Type: BP-1L Number of Bottles: 2 Preserved With: Lugols
 DTY-QN-C Template: DEFAULT (SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
 *Phytoplankton-Quantitative-#Diatom Taxa
 PKD-QN-C Template: DEFAULT (SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.
 *Phytoplankton-Quantitative-# Wet Taxa

Bottle Type: BG-250ML-WDMTH Number of Bottles: 2 Preserved With: ICE
 W-MCYST-AA Template: (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
 *Anatoxin-a
 *Cylindrospermopsin

Bottle Group B (Water) With 2 Samples:

Bottle Type: BG-250ML-WDMTH Number of Bottles: 2 Preserved With: ICE
 W-MCYST-AA Template: (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

*Desmethyl microcystin LR
 *Microcystin LA
 *Microcystin LF
 *Microcystin LR
 *Microcystin LW
 *Microcystin LY
 *Microcystin RR
 *Microcystin WR
 *Microcystin YR

Bottle Type: P-500ML Number of Bottles: 2 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 Ammonia-N
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 NO2NO3-N
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 Total-P
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
 Kjeldahl Nitrogen

Bottle Type: P-125ML Number of Bottles: 2 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
 O-Phosphate-P

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.