

Login Checklist

RQ- 2021-05-17-67

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 12/ 17 /21 @ 10:00

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.1				15		✓			5225 5542 0126

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ✓

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ✓

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes ✓ No _____

Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ✓ Init: kh

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ✓ No _____ NA _____ Init: kh

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ✓ Init: kh

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: kh

Date: 12/ 17 /21

Event contains NCRs (Y/N)? N

Event ID: Algal Bloom Response -SOROC
WQAP-2021-12-17-01 (BLOOM-RESP)

Date Received: 17-DEC-2021 10:00

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 EXP:10-19-22
pH Test Strips 0 – 6	Lot#210620 EXP:4-15-23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 EXP:4-15-23
Chlorine Test Strips	Lot#0070 EXP:2-23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2021-05-17-67		Collected By: KIRBY WOLFE	
Customer: SODIST	Field Report Prepared By: JOHN BARRINGTON		
Project ID: BLOOM - RESP	Sampling Agency: SURDOC FDEP		
Location: CALOFSANATCHEE RIVER - RIVER FOREST KOYAK LAUNCH		Comments: NO APPARENT BLOOM AT TIME OF VISIT. WINDBLOWN SURFACE PROTEIN AT RAMP, SAMPLE TAKEN.	
Field ID: HAB-SD-12162021001		Coordinates: 26.7155, -81.734	
		Collection Equip: PRO MOVE	
WIN ID: HAB-SD-12162021001		High Tide Time: 0058	Low Tide Time: 0930
Matrix: FRESH	Grab	Tide: ☐ Rising ☐ Falling ☒ Slack ☐ N/A	

Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)
12/16/21	0903	51.3	4.42	22.7	7.52	0.15	0.3	0.3" S" VOB	420.4	0.20

Bloom Observations						
Algal Bloom Observed? ☐ Yes ☒ No						
Water Surface	☒ Clear	☐ Scum	☐ Globbs	☐ Slick		
Water Clarity	☐ Clear	☒ Slightly Turbid	☐ Turbid	☐ Opaque		
Bloom Color	☐ Green	☐ Red	☐ Brown	☐ Other: _____	☒ N/A	
Algae Distribution	☐ Suspended in water column		☐ On surface	☐ Other: _____	☒ N/A	
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum	☐ Chemical	☐ Other: _____	

Parameter Suite	Parameter Methods	Preservation	pH Check	#Bottles Sent to Lab	Bottle Group
Bloom ID (PT-50mL)	☒ BLOOM-ID	☒ Ice		1	A
Chlorophyll (BP-1L)	☒ CHLSUITE-W	☒ Ice		1	B
Toxins (BG-WD250)	☒ W-MCYST-AA	☒ Ice		1	B
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP	☒ Ice ☒ H2SO4	☒ <2	1	B
	Acid Lot: SA1105060	Exp: 4/30/22			
Filtered Nutrients (P125mL)	☒ W-PO4-F	☒ Field Filtered 0.45µm Filter	☒ Ice		B
	Filter Lot #: 17232873				
Quantitative Algae	☐ DTY-QN-C / PKD-QN-C	☐ Ice	Lugols? Y / N		

Relinquished By: JOHN BARRINGTON	Date/Time: 12/16/21 1600	Number of Coolers Shipped: 1	Received By: KK	Date/Time: 12-17-21/1000
----------------------------------	--------------------------	------------------------------	-----------------	--------------------------

Date of Request: 12-MAY-2021
 Created By: WOLFE_K On: 12-MAY-2021
 Modified By: JASROTIA_P On: 17-MAY-2021
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District: SROC
 Event Description: Algal Bloom Response -SOROC

Send Coolers To:

Phone: 850-245-8416
 2295 Victoria AVE
 Suite 364
 Fort Myers, FL 33901
 Attn: Kirby Wolfe
 Cooler Ship EMail: kirby.wolfe@dep.state.fl.us

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 17-MAY-2021
 Biology Request Reviewed By: JASROTIA_P On: 17-MAY-2021
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 17-MAY-2021
 Logged In By: REYNOLDS_T On: 27-MAY-2021

Send Final Report To:

2295 Victoria AVE
 Suite 364
 Fort Myers, FL 33901
 Attn: Kirby Wolfe
 Report Notification EMail:
 kirby.wolfe@floridadep.gov;kalina.warren@dep.state.fl.us;Cheryl.
 Swanson@dep.state.fl.us;Nicole.Reistad@floridadep.gov;John.B
 arrington@floridadep.gov

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxins, nutrients, chlorophyll, algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login

Bottle Group A (Biological) With 2 Samples:

Bottle Type: PT-50ML Number of Bottles: 2 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 2 Samples:

Bottle Type: BP-1L Number of Bottles: 2 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: BP-1L Number of Bottles: 2 Preserved With: Lugols
 DTY-QN-C Template: DEFAULT (SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
 PKD-QN-C Template: DEFAULT (SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

Bottle Type: BG-250ML-WDMTH Number of Bottles: 2 Preserved With: ICE
 W-MCYST-AA Template: (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 2 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 2 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.