

RQ- 2021-07-19-52

Login Checklist

Login Station ID: #5Shipping Method: FedEx | UPS | HD | GreyhoundDate/Time of Receipt: 12/ 2 /21 @ 10:45

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
<u>2.2</u>				<u>2</u>		☒			<u>9293 8015 5650</u>

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# 9142

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ☒ Init: HK

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ☒ No _____ NA ☒ Init: HK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ☒ Init: HK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: HKDate: 12/ 2 /21Event contains NCRs (Y/N)? YEvent ID: SFWMD Bloom Response
SFWMD-2021-12-02-01 (BLOOM-RESP)
Date Received: 02-DEC-2021 10:45

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 EXP:10-19-22
pH Test Strips 0 – 6	Lot#210620 EXP:4-15-23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 EXP:4-15-23
Chlorine Test Strips	Lot#0070 EXP:2-23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Request Number: ^{*} ^{HK} RQ- 2021-07-19-52

SFWMD Bloom Response (West Palm Beach)

Florida Department of Environmental Protection
Central Laboratory Submittal Form

Page 1 of 2

last revised Jan 25, 2018

Customer: SFWMD

Requester: Amelia G. Rankin

Field Report Prepared By:

Danielle Jurwick

Project ID: BLOOM-RESP

Collected By: Danielle Jurwick

Sampling Agency:

SFWMD

Location Pahokee Marina		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 11/30/2021 Time 1042		☒ Eastern ☐ Central		Composite end Date Time		Bottle Group(s) (See pg 2)	
Field ID Boat Ramp		Matrix (type, e.g., Salt, Fresh, etc) Freshwater		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		A	
WIN/STORET #		Temp (C)		pH		Sample Depth 0.3		☐ ft ☒ m		Sp. Conductance (umho/cm)	
Latitude 26.825°N		☒ dd ☐ dms		Longitude 80.668°W		☒ dd ☐ dms		Salinity (ppt)		Comments Visible BGA spread throughout marina. Bright green in color, heavy density, fine clumps dispersed throughout water column.	
Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		☐ Eastern ☐ Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		☐ ft ☐ m		Sp. Conductance (umho/cm)	
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments	
Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		☐ Eastern ☐ Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		☐ ft ☐ m		Sp. Conductance (umho/cm)	
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments	
Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		☐ Eastern ☐ Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		☐ ft ☐ m		Sp. Conductance (umho/cm)	
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments	
Location		☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		☐ Eastern ☐ Central		Composite end Date Time		Bottle Group(s)	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
WIN/STORET #		Temp (C)		pH		Sample Depth		☐ ft ☐ m		Sp. Conductance (umho/cm)	
Latitude		☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments	

Relinquished By: Danielle Jurwick	Date/Time 11/30/2021 1600	Shipping Method FedEx Overnight	Number of Coolers Shipped: 1	Received By: HK	Date/Time 12-2-21 1045
--------------------------------------	------------------------------	------------------------------------	---------------------------------	--------------------	---------------------------

* RQ# taken from bottles

Date of Request: 15-JUL-2021
Created By: RANKIN_A On: 15-JUL-2021
Modified By: JASROTIA_P On: 16-JUL-2021
Customer: SFWMD
Project: BLOOM-RESP
Division:
District: Not Applicable
Event Description: SFWMD Bloom Response

Send Coolers To:

Phone: 863-462-5280 ext. 3199
SFWMD
1000 NE 40th Ave.
Okeechobee, FL 34972
Attn: James Doak
Cooler Ship Email: jdoak@sfwmd.gov

Priority: 1
Event Status: R
Criminal Investigation: NO
Chemistry Request Reviewed By: WATTS_J On: 16-JUL-2021
Biology Request Reviewed By: JASROTIA_P On: 16-JUL-2021
Sampling Kit Required: YES Ship on: 23-JUL-2021
Sampling Kit Shipped: YES On: 22-JUL-2021
Sampling Kit Packed By: SHAIK_A
Preservatives Needed: NO
Date to Receive Samples: 19-JUL-2021
Logged In By: KLUG_K On: 02-DEC-2021

Send Final Report To:

SFWMD
8894 Belvedere Rd. B374
West Palm Beach, FL 33411
Attn: Mickael Tompkins
Report Notification Email:
mtompkin@sfwmd.gov; Kirby.Wolfe@FloridaDEP.gov; Jordan.Skagggs@FloridaDEP.gov

Comments: Please pack in 10 coolers.

Bottle Groups A/B: same event - Priority 1

Bottle Group A - Priority 1
For algal dominant taxon.

Bottle Group B - Priority 1
For toxin testing.

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login.

Bottle Group A (Biological) With 20 Samples:

Bottle Type: PT-50ML	Number of Bottles: 20	Preserved With: ICE
BLOOM-ID	Template: DEFAULT	(SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 20 Samples:

Bottle Type: BG-250ML-WDMTH	Number of Bottles: 20	Preserved With: ICE
W-MCYST-AA	Template:	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.