

Login Checklist

RQ- ~~2020~~ ¹⁰⁸ 07 - 27 - 32

Login Station ID: # 3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 02/23/2021 / 10:15

Date/Time of Receipt: 02/23/2021 / 10:15

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.5c				6		x			9293 8009 3967

COOLER CHECK

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes x No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No x

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA x

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes x No _____

Caps on tight?

Yes x No _____

Sufficient Sample Volume:

Yes x No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No x Init: ABS/

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: ABS/

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes x No _____ NA _____ Init: ABS/

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA x Init: ABS/

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: ABS/

Date: 02/23/2021 Event contains NCRs (Y/N)? N

Event ID:

WQAP - 2021 - 02 - 23 - 02

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	IRTG # 3 EXP:10/28/2021
pH Test Strips 0 – 6	213316 BV EXP:05/15/21
pH Paper 0 – 3	N/A
pH Paper 0 – 13	231019 EXP:11/01/2021
Chlorine Test Strips	0261 2023 / 05

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2020-07-27-32		Collected By:	N. Abdo / M. Bearden							
Customer:	FDEP	Field Report Prepared By:	N. Abdo							
Project ID:	Bloom Response	Sampling Agency:	21FLTPA - SW ROC							
Location: WIN/Field ID		Comments:								
HAB-SW-0028										
Site Name: Thomas Lake - Center		Coordinates:								
Collection Equip:		Bottles - Direct Grab								
WIN ID:	High Tide Time:	Low Tide Time:								
Matrix: Fresh	Grab	Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A								
Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)
02/22/2021	10:35	93.8	8.61	19.5	7.51	0.3	10.5 MB 3.0	0.4	168.3	0.08
	1037	90.3	8.31	19.4	7.29	2.5			168.8 163.3 MB	0.08
Bloom Observations										
Algal Bloom Observed? ☒ Yes ☐ No										
Water Surface	☒ Clear	☐ Scum	☐ Globs	☐ Slick						
Water Clarity	☐ Clear	☐ Slightly Turbid	☒ Turbid	☐ Opaque						
Bloom Color	☒ Green	☐ Red	☐ Brown	☐ Other: _____	☐ N/A					
Algae Distribution	☒ Suspended in water column	☐ On surface	☐ Other: _____	☐ N/A						
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum	☐ Chemical	☐ Other: _____					
Parameter Suite	Parameter Methods			Preservation		pH Check	#Bottles Sent to Lab	Bottle Group		
Bloom ID (PT-50mL)	☒ BLOOM-ID			☒ Ice			1	A		
Chlorophyll (BP-1L)	☒ CHLSUITE-W			☒ Ice			1	B		
Toxins (BG-WD250)	☒ W-MCYST-AA			☒ Ice			1	B		
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP			☒ Ice	☒ H2SO4	☒ <2	1	B		
	Acid Lot: 0293040		Exp: 10/19/21							
Filtered Nutrients (P125mL)	☒ W-PO4-F		☒ Field Filtered 0.45µm Filter		☒ Ice		1	B		
Quantitative Algae	☒ DTY-QN-C / PKD-QN-C			☒ Ice	Lugols? Y/N		1	C		
Relinquished By:	Date/Time	Number of Coolers Shipped		Received By:		Date/Time				
M. Bearden	2/22/21 1600	1		ABD		02-23-21/10:15				

1870

1871

1872

1873

1874

1875

1876

1877

Date of Request: 09-JUL-2020
 Created By: BEARDEN_M On: 09-JUL-2020
 Modified By: JASROTIA_P On: 10-JUL-2020
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District:
 Event Description: Algal Bloom Response - SWD

Send Coolers To:

Phone: 813-470-5951
 13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden
 Cooler Ship EMail: matthew.bearden@dep.state.fl.us

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 10-JUL-2020
 Biology Request Reviewed By: JASROTIA_P On: 10-JUL-2020
 Sampling Kit Required: YES Ship on: 17-JUL-2020
 Sampling Kit Shipped: YES On: 15-JUL-2020
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 27-JUL-2020
 Logged In By: SHAIK_A On: 23-FEB-2021

Send Final Report To:

13051 N. Telecom Parkway

 Temple Terrace, FL 33637
 Attn: Matthew Bearden
 Report Notification EMail:
 matthew.bearden@dep.state.fl.us;kalina.warren@dep.state.fl.us;

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Groups A/B - separate event, priority 1
 Bottle Group C - separate event, priority 12

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, and chlorophyll

Bottle Group C - Priority 12
 For algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Bottle Group A (Biological) With 8 Samples:

Bottle Type: PT-50ML Number of Bottles: 8 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB05) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 8 Samples:

Bottle Type: BP-1L Number of Bottles: 8 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: BG-250ML-WDMTH Number of Bottles: 8 Preserved With: ICE
 W-MCYST-AA Template: (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 8 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 8 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 8 Samples:

Bottle Type: BP-1L	Number of Bottles: 8	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.