

RQ-2023-07-24-49

Login Checklist

Login Station ID: #4

Shipping Method: ~~FedEx~~ | UPS | HD | Greyhound

Date/Time of Receipt: 08/ 8 /2023@10:00

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.0				10		X			648484567010

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____ Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: TL

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes X No _____ NA _____ Init: TL

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA X Init: TL

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: TLDate: 08/ 8 /2023Event contains NCRs (Y/N)? NEvent ID: NE-DIST-2023-08-08-01

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #4 Exp:10/17/2023
pH Test Strips 0 – 6	LOT# 223819AV Exp: AUG 30, 2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT# 207621 Exp: March 15, 2024
Chlorine Test Strips	LOT# 1196 Exp: Feb. 2024

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____



Cyanobacteria Bloom Response Field Data Sheet (2023-06-12 v1)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2023-07-24-49		Collected By:		Katrin Villinger						
Customer:	NE-DIST	Field Report Prepared By:		KVILLINGER						
Project ID:	BLOOM_RESP	Sampling Agency:		NEROC						
Location: Georges Lake - Boat Ramp			Comments: BLANK- 4 bottles, Group D- (W-MCYST-AA, W-SAXTN-MS, W-COLOR, W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP, W-PO4-F) acid lot and filter lot are same as listed below. All were placed on ice w/i 15 min of sample. PH <2.							
Blank: Field Blank- Georges Lake - Boat Ramp										
Field ID: NEHAB0099			Coordinates: 29.80221, -81.84552							
BLANK ID: FB_08072023										
WIN Secondary Resource Type: Lake			Collection Equip: WaterBottle							
WIN ID: NEHAB0099			High Tide Time: Low Tide Time:							
Matrix:	Fresh	Grab	Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A							
Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)
08/07/2023	11:15	78.4	5.83	31.1	5.96	0.3	0.756	0.756	55.4	0.02
Bloom Observations										
Algal Bloom Observed? ☒ Yes ☐ No										
Water Clarity		☐ Clear	☒ Slightly Turbid	☐ Turbid	☐ Opaque					
Bloom Color		☒ Green	☐ Red	☐ Brown	☐ Other:					
Algae Type		☒ Planktonic	☐ Filamentous	☐ Other:						
Algae Accumulation		☐ Mat	☒ Specks	☐ Scum	☒ Glob					
Algae Distribution		☐ Surface-Entire	☐ Surf-Localized	☐ Surf-Windblown	☒ Suspended	☐ Benthic	☐ Epiphytic			
Parameter Suite		Parameter Methods			Preservation		pH Check	#Bottles Sent to Lab	Bottle Group	
Algae (PT-50mL)		☐ ALGAL-ID ☒ BLOOM-ID			☒ Ice			1	A	
Chlorophyll (BP-1L)		☒ CHLSUITE-W			☒ Ice			1	B	
Toxins (P-125/BG-250)		☒ W-MCYST-AA ☐ W-SAXTN-MS ☐ OV-TOXN			☒ Ice			1	B	
Physical/Aggregate		☒ W-COLOR			☒ Ice			1	B	
Preserved Nutrients (500mL HDPE)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP			☒ Ice ☒ H2SO4		☒ <2	1	B	
		SA3013020			1/25/24					
		Acid Lot:			Exp:					
Filtered Nutrients (P125mL)		☒ W-PO4-F			☒ Field Filtered 0.45um Filter		☒ Ice	1	B	
		Filter Lot # R1EB01329								
Quantitative Algae		☐ DTY-QN-C / PKD-QN-C			☐ Ice ☐ Lugols					
Relinquished By:		Date/Time		Number of Coolers Shipped		Received By:		Date/Time		
KVILLINGER		08/07/2023 16:30		1		TL		8/8/23 @ 10:00		

Date of Request: 18-JUL-2023
 Created By: VILLINGE_K On: 18-JUL-2023
 Modified By: AYRES_J On: 31-JUL-2023
 Customer: NE-DIST
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Event Description: Algae Bloom Response NERO- as needed

Send Coolers To:

Phone: 904-807-3300
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Katin Villinger
 Cooler Ship EMail: Katrin.villinger@floridadep.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 18-JUL-2023
 Biology Request Reviewed By: SWANSON_C On: 21-JUL-2023
 Sampling Kit Required: YES Ship on: 01-AUG-2023
 Sampling Kit Shipped: YES On: 27-JUL-2023
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: NO
 Date to Receive Samples: 24-JUL-2023
 Logged In By: LEBRUN_T On: 08-AUG-2023

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Katin Villinger
 Report Notification EMail: Katrin.Villinger@floridadep.gov

Comments:

Bottle Group A - Priority 1
 For Bloom ID dominant taxon.

Bottle Group B - Priority 1
 For toxin testing Nutrients, Chlorophyll, Toxin.

Bottle Group C - Priority 1
 For toxin testing Nutrients, Chlorophyll, Toxin w/ SAX.

Bottle Group D - Priority 1
 Field Blank for QC on Nutrients and Toxin.

Bottle Group A (Biological) With 12 Samples:

Bottle Type: PT-50ML Number of Bottles: 12 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB18) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 6 Samples:

Bottle Type: BP-1L Number of Bottles: 6 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-250ML Number of Bottles: 6 Preserved With: ICE
 W-COLOR Template: DEFAULT (DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
 Color (true)

Bottle Type: P-125ML Number of Bottles: 6 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 6 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 6 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 6 Samples:

Bottle Type: P-500ML	Number of Bottles: 6	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 6	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BP-1L	Number of Bottles: 6	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML	Number of Bottles: 6	Preserved With: ICE
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
Bottle Type: P-125ML	Number of Bottles: 6	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
W-SAXTN-MS	Template: DEFAULT	(EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-250ML	Number of Bottles: 1	Preserved With: ICE
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
W-SAXTN-MS	Template: DEFAULT	(EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.