

Login Checklist

RQ- 2023 - 03 - 27 - 49

Login Station ID: # 2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 03/31/23 19:30

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.7C				5		X			5859 4733 9173

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____ Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: **ABS** /

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: **ABS** /

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes X No _____ NA _____ Init: **ABS** /

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes _____ No _____ NA X Init: **ABS** /

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: **ABS** /

Date: **03/31/2023**

Event contains NCRs (Y/N)? **N**

Event ID:

WQAP - 2023 - 03 - 31 - 01

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTG # 2 EXP:10/17/2023
pH Test Strips 0 – 6	LOT#223819AV EXP:8/30/23
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT#207621 EXP:3/15/2024
Chlorine Test Strips	0129 03 / abs/03/01/2023 0070 / 2023 / 01/

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Track # 5859 4733 9173



Cyanobacteria Bloom Response Field Data Sheet (2019-12-16 v4)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ-2023-03-27-49		Collected By: <u>RENK</u>	
Customer: <u>WQAP</u>	Field Report Prepared By: <u>RENK</u>		
Project ID: <u>BLOOM-RESP</u>	Sampling Agency: <u>Orange EPD</u>		

Win ID: HABOC0016 Lake Ola - NE Shore Field ID: HABOC0016_LakeOla	Comments:	
	<u>Syringe: 2298556</u>	
	Coordinates:	<u>28.75517, -81.62585</u>
	Collection Equip:	<u>Sample bottles, syringe</u>

WIN ID: <u>HABOC0016</u>	High Tide Time: <u>—</u>	Low Tide Time: <u>—</u>
Matrix: <u>Fresh</u>	☐ Rising ☐ Falling ☐ Slack ☒ N/A	

Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPT)
<u>3/30/23</u>	<u>0930</u>	<u>98.8</u>	<u>8.3</u>	<u>23.9</u>	<u>7.6</u>	<u>0.3</u>	<u>3.9</u>	<u>2.7</u>	<u>221</u>	

Bloom Observations						
Algal Bloom Observed? ☐ Yes ☒ No						
Water Surface	☒ Clear	☐ Scum	☐ Globs	☐ Slick		
Water Clarity	☒ Clear	☐ Slightly Turbid	☐ Turbid	☐ Opaque		
Bloom Color	☐ Green	☐ Red	☐ Brown	☐ Other: _____	☒ N/A	
Algae Distribution	☒ Suspended in water column	☐ On surface	☐ Other: _____	☐ N/A		
Water Odors	☒ Normal	☐ Sewage	☐ Petroleum	☐ Chemical	☐ Other: _____	

Parameter Suite	Parameter Methods	Preservation	pH Check	#Bottles Sent to Lab	Bottle Group
Bloom ID (PT-50mL)	☒ BLOOM-ID	☒ Ice		<u>1</u>	<u>A</u>
Chlorophyll (BP-1L)	☒ CHLSUITE-W	☒ Ice		<u>1</u>	<u>B</u>
Toxins (BG-WD250)	☒ W-MCYST-AA <u>☒ W-SAXTN-MS</u>	☒ Ice		<u>1</u>	<u>B</u>
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP	☒ Ice ☒ H2SO4 ☐ <2		<u>1</u>	<u>B</u>
	Acid Lot: <u>SA3013020</u> Exp: <u>1/25/24</u>				
Filtered Nutrients (P125mL)	☒ W-PO4-F ☒ Field Filtered 0.45µm Filter	☒ Ice		<u>1</u>	<u>B</u>
Quantitative Algae	☐ DTY-QN-C / PKD-QN-C	☐ Ice Lugols? Y / N			

Relinquished By: _____	Date/Time: _____	Number of Coolers Shipped: <u>1</u>	Received By: <u>AFS</u>	Date/Time: <u>03.31.23 19:30</u>
------------------------	------------------	-------------------------------------	-------------------------	----------------------------------

1

Date of Request: 20-MAR-2023
 Created By: BEARDEN_M On: 20-MAR-2023
 Modified By: JASROTIA_P On: 20-MAR-2023
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District:
 Event Description: Algal Bloom Response - Orange Co

Send Coolers To:

Phone: 407-897-4123
 3319 Maguire Blvd

 Orlando, FL 32803
 Attn: Matthew Bearden - FDEP
 Cooler Ship EMail: matthew.bearden@dep.state.fl.us

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 20-MAR-2023
 Biology Request Reviewed By: JASROTIA_P On: 20-MAR-2023
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 31-MAR-2023
 Logged In By: SHAIK_A On: 31-MAR-2023

Send Final Report To:

3319 Maguire Blvd

 Orlando, FL 32083
 Attn: Matthew Bearden
 Report Notification EMail:
 matthew.bearden@dep.state.fl.us;jessie.atchison@floridadep.go
 v

Comments: Bottle Group A – Priority 1
 For algal dominant taxon

Bottle Group B – Priority 1
 For toxin testing, nutrients, chlorophyll

Bottle Group C | Priority 1
 HAB Blank - Nutrients and toxin testing

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login.

Bottle Group A (Biological) With 1 Samples:

Bottle Type: PT-50ML	Number of Bottles: 1	Preserved With: ICE
BLOOM-ID	Template: DEFAULT	(SOP-AB18) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 1 Samples:

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
W-SAXTN-MS	Template: DEFAULT	(EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

