

Login Checklist

RQ- 2023 - 07 - 03 - 20

Login Station ID: # 2

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 07/18/2023 / 09:45

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.2C				6		X			6484 8456 5006

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ FieldSheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____ Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: ABS /

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: ABS /

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes X No _____ NA _____ Init: ABS /

**W-1-4-DIOX (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA X Init: ABS /

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: ABS /

Date: 07/18/2023

Event contains NCRs(Y/N)? N

EventID:

CEN - DIST - 2023 - 07 - 18 - 0

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTG # 2 EXP:10/17/2023
pH Test Strips 0 – 6	LOT#223819AV EXP:8/30/23
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT#207621 EXP:3/15/2024
Chlorine Test Strips	LOT#207621 EXP:3/15/2024

1196/2024/02 abs/04/03/23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____



Cyanobacteria Bloom Response Field Data Sheet (2023-06-12 v1)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2023-07-03-20		Collected By:		Terry Riordan, Denver Bourassa						
Customer: CEN-DIST		Field Report Prepared By:		Terry Riordan						
Project ID: BLOOM_RESP		Sampling Agency:		CEROC						
Location: Lake Weston - Kingswood Manor Park Dock				Comments: 80s partly cloudy						
Field ID: HABCE0205_LakeWeston				Coordinates: 28.61613, -81.40694						
WIN Secondary Resource Type: Lake				Collection Equip: WaterBottle						
WIN ID: HABCE0205				High Tide Time: Low Tide Time:						
Matrix: Fresh		Grab		Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A						
Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPT)
07/17/2023	09:56	92.6	6.94	30.5	6.88	0.3	1.7	1.5	159.1	0.07
	09:57	88.6	6.65	30.3	7	1.2			159.2	0.07
Bloom Observations										
Algal Bloom Observed? ☒ Yes ☐ No										
Water Clarity		☒ Clear		☐ Slightly Turbid		☐ Turbid		☐ Opaque		
Bloom Color		☒ Green		☐ Red		☐ Brown		☐ Other:		
Algae Type		☒ Planktonic		☐ Filamentous		☐ Other:				
Algae Accumulation		☐ Mat		☒ Specks		☐ Scum		☐ Glob		
Algae Distribution		☐ Surface-Entire		☐ Surf-Localized		☐ Surf-Windblown		☒ Suspended ☐ Benthic ☐ Epiphytic		
Parameter Suite		Parameter Methods				Preservation		pH Check	#Bottles Sent to Lab	Bottle Group
Algae (PT-50mL)		☐ ALGAL-ID ☒ BLOOM-ID				☒ Ice			1	A
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	B
Toxins (P-125/BG-250)		☒ W-MCYST-AA ☒ W-SAXTN-MS ☐ OV-TOXN				☒ Ice			1	B
Physical/Aggregate		☒ W-COLOR				☒ Ice			1	B
Preserved Nutrients (500mL HDPE)		☒ W-NH3 / ☒ W-NO2NO3 / ☒ W-TKN / ☒ W-S-A-TP				☒ Ice ☒ H2SO4		☒ <2	1	B
		SA3013020		Acid Lot:		Exp:		01/25/2024		
Filtered Nutrients (P125mL)		☒ W-PO4-F		☒ Field Filtered 0.45um Filter		☒ Ice			1	B
				Filter Lot # 17769663						
Quantitative Algae		☐ DTY-QN-C / PKD-QN-C				☐ Ice ☐ Lugols				
Relinquished By:		Date/Time		Number of Coolers Shipped		Received By:		Date/Time		
Terry Riordan		07/17/2023 16:00		1		A.SHAIK		07/18/2023 / 09:45		

Date of Request: 31-MAY-2023
 Created By: BOMAN_L On: 31-MAY-2023
 Modified By: JASROTIA_P On: 14-JUN-2023
 Customer: CEN-DIST
 Project: BLOOM-RESP
 Division:
 District: Central District
 Event Description: Algal Bloom Response - CEROC

Send Coolers To:

Phone: 407-894-7555 SC 325-1011
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Leif Boman
 Cooler Ship EMail: Leif.Boman@FloridaDep.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 13-JUN-2023
 Biology Request Reviewed By: JASROTIA_P On: 14-JUN-2023
 Sampling Kit Required: YES Ship on: 23-JUN-2023
 Sampling Kit Shipped: YES On: 16-JUN-2023
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: NO
 Date to Receive Samples: 03-JUL-2023
 Logged In By: SHAIK_A On: 18-JUL-2023

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Jessie Atchison
 Report Notification EMail: Jessie.Atchison@FloridaDEP.gov

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxin testing, nutrients, chlorophyll, algal full ID

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login

Bottle Group A (Biological) With 6 Samples:

Bottle Type: PT-50ML Number of Bottles: 6 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB18) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 6 Samples:

Bottle Type: BP-1L Number of Bottles: 6 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-250ML Number of Bottles: 6 Preserved With: ICE
 W-COLOR Template: DEFAULT (DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
 Color (true)

Bottle Type: P-125ML Number of Bottles: 6 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
 W-SAXTN-MS Template: DEFAULT (EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 6 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 6 Preserved With: FILTER-ICE

Bottle Group B (Water) With 6 Samples:

Bottle Type: P-125ML	Number of Bottles: 6	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.