

Chemical Analysis Report

WQAP-2023-06-02-01

Florida DEP Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780

Event Description: **Algal Bloom Response - CEROC**
Request ID: **RQ-2023-04-17-05**
Customer: **WQAP**
Project ID: **BLOOM-RESP**

Send Reports to:
FL Dept. of Environmental Protection
3319 Maguire Blvd. Suite 232
Orlando, FL 32803
Attn: Jessie Atchison

For additional information please contact
Colin Wright, Ph.D.
Chris Bowen, B.S.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Chris Bowen, Environmental Administrator

Date Certified: 14-JUN-2023 14:49



Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Tiger Lake - Center

Collection Date/Time: 06/01/2023 10:46

Field ID: HABCE0185_TigerLake2

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2414069	EPA 8321B	Anatoxin-a	0.25	U	ug/L	P430713	
		Cylindrospermopsin	0.10	U	ug/L	P430712	
		Desmethyl microcystin LR	0.25	U	ug/L	P430712	
		Microcystin HILR	0.25	U	ug/L	P430712	
		Microcystin HtyR	0.25	U	ug/L	P430712	
		Microcystin LA	0.44		ug/L	P430712	
		Microcystin LF	0.24	I	ug/L	P430712	
		Microcystin LR	1.7		ug/L	P430712	
		Microcystin LW	0.25	U	ug/L	P430712	
		Microcystin LY	0.29	I	ug/L	P430712	
		Microcystin RR	0.28	I	ug/L	P430712	
		Microcystin WR	0.50	U	ug/L	P430712	
		Neosaxitoxin	0.50	U	ug/L	P430713	
		Microcystin YR	0.25	U	ug/L	P430712	
		Saxitoxin	0.50	U	ug/L	P430713	
		Nodularin-R	0.10	U	ug/L	P430712	
2414071	EPA 350.1 Rev. 2.0	Ammonia-N	0.010		mg N/L	P430848	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	2.3		mg N/L	P430981	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.004	U	mg N/L	P430985	
	EPA 365.1 Rev. 2.0	Total-P	0.14		mg P/L	P430794	
2414072	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.008	I	mg P/L	P430739	

Sample Location: Tiger Lake - Center

Collection Date/Time: 06/01/2023 11:10

Field ID: FB_06012023

Matrix: W-FIELD-BK

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2414070	EPA 8321B	Anatoxin-a	0.50	U	ug/L	P430713	
		Cylindrospermopsin	0.10	U	ug/L	P430712	
		Desmethyl microcystin LR	0.25	U	ug/L	P430712	
		Microcystin HILR	0.25	U	ug/L	P430712	
		Microcystin HtyR	0.25	U	ug/L	P430712	
		Microcystin LA	0.10	U	ug/L	P430712	
		Microcystin LF	0.10	U	ug/L	P430712	
		Microcystin LR	0.25	U	ug/L	P430712	
		Microcystin LW	0.25	U	ug/L	P430712	
		Microcystin LY	0.10	U	ug/L	P430712	
		Microcystin RR	0.10	U	ug/L	P430712	
		Microcystin WR	0.50	U	ug/L	P430712	
		Neosaxitoxin	1.0	U	ug/L	P430713	
		Microcystin YR	0.25	U	ug/L	P430712	
		Saxitoxin	1.0	U	ug/L	P430713	
		Nodularin-R	0.10	U	ug/L	P430712	
2414073	EPA 350.1 Rev. 2.0	Ammonia-N	0.002	U	mg N/L	P430849	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.080	U	mg N/L	P430981	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.004	U	mg N/L	P430985	
	EPA 365.1 Rev. 2.0	Total-P	0.002	U	mg P/L	P430794	
2414074	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.004	U	mg P/L	P430739	

Ref. Method and Comment:

EPA 8321B: MDLs are elevated due to required dilution of sample matrix.

Quality Assurance Report

Method Blank Results

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430848

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430849

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P430981

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P430985

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P430794

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P430739

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8321B
Batch ID: P430712

Component	Result	Code	Units
Cylindrospermopsin	0.10	U	ug/L
Desmethyl microcystin LR	0.25	U	ug/L
Microcystin H1LR	0.25	U	ug/L
Microcystin HtyR	0.25	U	ug/L
Microcystin LA	0.10	U	ug/L
Microcystin LF	0.10	U	ug/L
Microcystin LR	0.25	U	ug/L
Microcystin LW	0.25	U	ug/L
Microcystin LY	0.10	U	ug/L
Microcystin RR	0.10	U	ug/L
Microcystin WR	0.50	U	ug/L
Microcystin YR	0.25	U	ug/L
Nodularin-R	0.10	U	ug/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8321B
Batch ID: P430713

Component	Result	Code	Units
Anatoxin-a	0.25	U	ug/L
Neosaxitoxin	0.50	U	ug/L
Saxitoxin	0.50	U	ug/L

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430848

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	100		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430849

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	97.4		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P430981

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	108		P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P430985

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	104		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P430794

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	100		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P430739

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	97.9		P	90 - 110

Reference Method: EPA 8321B
Batch ID: P430712

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Cylindrospermopsin	90.0		P	40 - 150
Desmethyl microcystin LR	94.5		P	40 - 150
Microcystin H1R	106		P	40 - 150
Microcystin HtyR	97.0		P	40 - 150
Microcystin LA	97.3		P	40 - 150
Microcystin LF	120		P	40 - 150
Microcystin LR	104		P	40 - 150
Microcystin LW	125		P	40 - 150
Microcystin LY	103		P	40 - 150
Microcystin RR	98.8		P	40 - 150
Microcystin WR	110		P	40 - 150
Microcystin YR	105		P	40 - 150
Nodularin-R	90.9		P	40 - 150

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 8321B
Batch ID: P430713

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Anatoxin-a	98.0		P	40 - 150
Neosaxitoxin	99.0		P	40 - 150
Saxitoxin	89.4		P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430848

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2413903	Ammonia-N	96.4	98.2	P/P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430849

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2414080	Ammonia-N	96.6	93.4	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P430981

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2413937	Kjeldahl Nitrogen	104	98.3	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P430985

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2412299	NO2NO3-N	97.2		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P430794

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2414071	Total-P	95.7	97.3	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P430739

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2414072	O-Phosphate-P	97.5	97.0	P/P	90 - 110

Reference Method: EPA 8321B
Batch ID: P430712

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2414069	Cylindrospermopsin	89.1	92.4	P/P	40 - 150
2414069	Desmethyl microcystin LR	112	119	P/P	40 - 150
2414069	Microcystin HilR	127	125	P/P	40 - 150
2414069	Microcystin HtyR	113	107	P/P	40 - 150
2414069	Microcystin LA	89.1	102	P/P	40 - 150
2414069	Microcystin LF	110	108	P/P	40 - 150
2414069	Microcystin LR	125	123	P/P	40 - 150
2414069	Microcystin LW	115	103	P/P	40 - 150
2414069	Microcystin LY	109	96.9	P/P	40 - 150
2414069	Microcystin RR	100	100	P/P	40 - 150
2414069	Microcystin WR	132	137	P/P	40 - 150
2414069	Microcystin YR	136	139	P/P	40 - 150
2414069	Nodularin-R	103	100	P/P	40 - 150

Quality Assurance Report

Matrix Spike Accuracy

Reference Method: EPA 8321B
Batch ID: P430713

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2414069	Anatoxin-a	107	107	P/P	40 - 150
2414069	Neosaxitoxin	79.6	74.3	P/P	40 - 150
2414069	Saxitoxin	75.0	82.0	P/P	40 - 150

Quality Assurance Report Precision

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430848

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2413903	Ammonia-N	1.60	Spike	P	0 - 20

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P430849

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2414080	Ammonia-N	2.88	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P430981

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2413937	Kjeldahl Nitrogen	2.83	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P430985

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2412299	NO2NO3-N	0.202	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P430794

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2414071	Total-P	1.22	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P430739

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2414072	O-Phosphate-P	0.477	Spike	P	0 - 20

Reference Method: EPA 8321B
Batch ID: P430712

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2414069	Cylindrospermopsin	3.64	Spike	P	0 - 30
2414069	Desmethyl microcystin LR	6.33	Spike	P	0 - 30
2414069	Microcystin HtIR	1.48	Spike	P	0 - 30
2414069	Microcystin HtyR	5.34	Spike	P	0 - 30
2414069	Microcystin LA	13.2	Spike	P	0 - 30
2414069	Microcystin LF	2.15	Spike	P	0 - 30
2414069	Microcystin LR	1.78	Spike	P	0 - 30
2414069	Microcystin LW	11.1	Spike	P	0 - 30
2414069	Microcystin LY	11.0	Spike	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8321B
Batch ID: P430712

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2414069	Microcystin RR	0.324	Spike	P	0 - 30
2414069	Microcystin WR	3.65	Spike	P	0 - 30
2414069	Microcystin YR	2.66	Spike	P	0 - 30
2414069	Nodularin-R	3.15	Spike	P	0 - 30

Reference Method: EPA 8321B
Batch ID: P430713

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2414069	Anatoxin-a	0.209	Spike	P	0 - 30
2414069	Neosaxitoxin	6.83	Spike	P	0 - 30
2414069	Saxitoxin	8.88	Spike	P	0 - 30

* Sample, spike and/or laboratory control sample precision (LCS) is reported.

Quality Assurance Report Surrogates

Lab Sample ID: 2414069

Field Sample ID: HABCE0185_TigerLake2

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	Microcystin LR ethyl-d5	136	P	30 - 160
EPA 8321B	Saxitoxin-15N7	82.1	P	30 - 160

Lab Sample ID: 2414070

Field Sample ID: FB_06012023

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	Microcystin LR ethyl-d5	87.9	P	30 - 160
EPA 8321B	Saxitoxin-15N7	91.0	P	30 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A119549

Included Lab Sample IDs: 2414072, 2414074

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	98.2	98.2	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A119563

Included Lab Sample IDs: 2414069, 2414070

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Anatoxin-a	94.1	91.2	P/P	50 - 160
Anatoxin-a	99.9	97.2	P/P	50 - 160
Neosaxitoxin	91.4	92.4	P/P	50 - 160
Neosaxitoxin	94.4	92.0	P/P	50 - 160
Saxitoxin	86.2	87.8	P/P	50 - 160
Saxitoxin	89.8	91.0	P/P	50 - 160

Reference Method: EPA 8321B

Run ID: A119564

Included Lab Sample IDs: 2414069, 2414070

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Cylindrospermopsin	84.1	87.7	P/P	50 - 160
Desmethyl microcystin LR	85.4	93.8	P/P	50 - 160
Microcystin HIR	97.6	103	P/P	50 - 160
Microcystin HtyR	87.6	88.8	P/P	50 - 160
Microcystin LA	88.7	99.4	P/P	50 - 160
Microcystin LF	108	80.3	P/P	50 - 160
Microcystin LR	89.6	95.8	P/P	50 - 160
Microcystin LW	103	111	P/P	50 - 160
Microcystin LY	77.4	88.9	P/P	50 - 160
Microcystin RR	87.7	90.8	P/P	50 - 160
Microcystin WR	95.8	105	P/P	50 - 160
Microcystin YR	98.2	102	P/P	50 - 160
Nodularin-R	81.7	90.9	P/P	50 - 160

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A119595

Included Lab Sample IDs: 2414071

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	102	101	P/P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A119602

Included Lab Sample IDs: 2414071, 2414073

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	98.0	98.6	P/P	90 - 110
Ammonia-N	98.6	97.9	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A119636

Included Lab Sample IDs: 2414073

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	99.5	97.8	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A119661

Included Lab Sample IDs: 2414071, 2414073

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	105	105	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A119704

Included Lab Sample IDs: 2414071, 2414073

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	104	99.9	P/P	90 - 110

* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.

Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		LCS	Precision	MS
						SMP	
EPA 350.1 Rev. 2.0	Ammonia-N	100	96.4	98.2			1.60
	Ammonia-N	97.4	96.6	93.4			2.88
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	108	104	98.3			2.83
EPA 353.2 Rev. 2.0	NO2NO3-N	104	97.2				0.202
EPA 365.1 Rev. 2.0	Total-P	100	95.7	97.3			1.22
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	97.9	97.5	97.0			0.477
EPA 8321B	Anatoxin-a	98.0	107	107			0.209
	Cylindrospermopsin	90.0	89.1	92.4			3.64
	Desmethyl microcystin LR	94.5	112	119			6.33
	Microcystin HILR	106	127	125			1.48
	Microcystin HtyR	97.0	113	107			5.34
	Microcystin LA	97.3	89.1	102			13.2
	Microcystin LF	120	110	108			2.15
	Microcystin LR	104	125	123			1.78
	Microcystin LW	125	115	103			11.1
	Microcystin LY	103	109	96.9			11.0
	Microcystin RR	98.8	100	100			0.324
	Microcystin WR	110	132	137			3.65
	Microcystin YR	105	136	139			2.66
	Neosaxitoxin	99.0	79.6	74.3			6.83
	Nodularin-R	90.9	103	100			3.15
	Saxitoxin	89.4	75.0	82.0			8.88

Reference Method Descriptions

Method	Description	Associated Samples
EPA 350.1 Rev. 2.0	Ammonia in aqueous matrices as mg N/L	2414071, 2414073
EPA 351.2 Rev. 2.0	Total Kjeldahl Nitrogen in aqueous matrices	2414071, 2414073
EPA 353.2 Rev. 2.0	Nitrite/Nitrate in aqueous matrices as mg N/L	2414071, 2414073
EPA 365.1 Rev. 2.0	Total Phosphorus in aqueous matrices as mg P/L	2414071, 2414073
EPA 365.1 Rev. 2.0 dissolved	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	2414072, 2414074
EPA 8321B	Microcystins in water matrices by HPLC/MS/MS	2414069, 2414070
EPA 8321B	Saxitoxin in water matrices by HPLC/MS/MS	2414069, 2414070

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 350.1 Rev. 2.0	06/02/2023			06/06/2023 11:50	Khloe J Berg	2414071
	06/02/2023			06/06/2023 12:06	Khloe J Berg	2414073
EPA 351.2 Rev. 2.0	06/02/2023	06/08/2023 11:16	Dana G. Hughes	06/09/2023 13:11	Samantha L Bates	2414071
	06/02/2023	06/08/2023 11:16	Dana G. Hughes	06/09/2023 13:12	Samantha L Bates	2414073
EPA 353.2 Rev. 2.0	06/02/2023			06/08/2023 10:24	Beverly Y. Sanders	2414071
	06/02/2023			06/08/2023 10:25	Beverly Y. Sanders	2414073
EPA 365.1 Rev. 2.0	06/02/2023	06/05/2023 14:34	Adam P Silver	06/06/2023 10:16	James L Waggerby	2414071
	06/02/2023	06/05/2023 14:34	Adam P Silver	06/07/2023 14:05	James L Waggerby	2414073
EPA 365.1 Rev. 2.0 dissolved	06/02/2023			06/02/2023 15:15	Elise M. Gillis	2414072
	06/02/2023			06/02/2023 15:17	Elise M. Gillis	2414074
EPA 8321B	06/02/2023	06/02/2023 12:00	Touraj Touran	06/02/2023 16:24	Touraj Touran	2414069
	06/02/2023	06/02/2023 12:00	Touraj Touran	06/02/2023 16:40	Touraj Touran	2414070
	06/02/2023	06/02/2023 12:00	Touraj Touran	06/03/2023 00:46	Touraj Touran	2414069
	06/02/2023	06/02/2023 12:00	Touraj Touran	06/03/2023 04:42	Touraj Touran	2414070