

Login Checklist

RQ- 2023-07-17-60

Login Station ID: 5

Shipping Method: FedEx UPS | HD | Greyhound

Date/Time of Receipt: 8/16 / 23 @ 4:21

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		YES	HNO ₃		Formalin	Present?	*Intact?		
					Yes	No	Yes	No	
1-4				5		X			589474.0488

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No ☐

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes ☐ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes ☐ No ☐ NA ☒ Evidence Tape intact? Yes ☐ No ☐

If Criminal, photographs taken?

Yes ☐ No ☒

Containers intact? Yes ☒ No ☐

Caps on tight?

Yes ☒ No ☐

Sufficient Sample Volume:

Yes ☒ No ☐

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes ☐ No ☒ Init: C.P.

Chlorine detected? (One container checked per Field ID)

Yes ☐ No ☐ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH< 2.0?

Yes ☒ No ☐ NA ☐ Init: C.P.

**W-1-4-DIOX (Green dot on container) preserved to pH< 4.0?

Yes ☐ No ☐ NA ☒ Init: G.P.

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C.P.

Date: 8/16 /23

Event contains NCRs (Y/N)? N

EventID: SO-DIST-2023-08-16-01 (BLOOM-RESP)

Date Received: 16-AUG-2023 09:26

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	221426058 10/17/23
pH Test Strips 0 – 6	207621 03/15/2024
pH Paper 0 – 3	NA
pH Paper 0 – 13	20762103 03/15/2024
Chlorine Test Strips	1196 02/2024

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____



Cyanobacteria Bloom Response Field Data Sheet (2023-06-12 v1)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - RQ-2023-07-17-60		Collected By:	John Barrington							
Customer:	SO-DIST	Field Report Prepared By:	John Barrington							
Project ID:	BLOOM_RESP	Sampling Agency:	SOROC							
Location: Caloosahatchee River - Jaycee park		Comments: Dusting of BGA on surface near rocks.								
Field ID: HAB-SD-081523-1245		Coordinates:	26.57359, -81.93061							
WIN Secondary Resource Type: Estuary		Collection Equip:	WaterBottle							
WIN ID: HAB-SD-0150		High Tide Time:		Low Tide Time:						
Matrix:	Marine	Grab	Tide: ☐ Rising ☐ Falling ☐ Slack ☐ N/A							
Water Quality										
Date	Time ☐ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)
08/15/2023	12:45	77.2	5.46	32.4	6.65	0.3	0.7	0.7	8663	4.77
Bloom Observations										
Algal Bloom Observed? ☒ Yes ☐ No										
Water Clarity	☐ Clear	☒ Slightly Turbid	☐ Turbid	☐ Opaque						
Bloom Color	☒ Green	☐ Red	☐ Brown	☐ Other:						
Algae Type	☒ Planktonic	☐ Filamentous	☐ Other:							
Algae Accumulation	☐ Mat	☒ Specks	☐ Scum	☐ Glob						
Algae Distribution	☐ Surface-Entire	☒ Surf-Localized	☐ Surf-Windblown	☐ Suspended	☐ Benthic	☐ Epiphytic				
Parameter Suite	Parameter Methods		Preservation	pH Check	#Bottles Sent to Lab	Bottle Group				
Algae (PT-50mL)	☐ ALGAL-ID ☒ BLOOM-ID		☒ Ice		1	A				
Chlorophyll (BP-1L)	☒ CHLSUITE-W		☒ Ice		1	B				
Toxins (P-125/BG-250)	☒ W-MCYST-AA ☒ W-SAXTN-MS ☐ OV-TOXN		☒ Ice		1	B				
Physical/Aggregate	☒ W-COLOR		☒ Ice		1	B				
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP		☒ Ice ☒ H2SO4	☒ <2	1	B				
	SA3013020		1/25/24							
	Acid Lot:		Exp:							
Filtered Nutrients (P125mL)	☒ W-PO4-F ☒ Field Filtered 0.45µm Filter		☒ Ice		1	B				
	Filter Lot # 17589311									
Quantitative Algae	☐ DTY-QN-C / PKD-QN-C		☐ Ice ☐ Lugols							
Relinquished By:	Date/Time	Number of Coolers Shipped		Received By:	Date/Time					
John Barrington	08/15/2023 13:00	2		C. P	8-16-23 / 9:21					

Date of Request: 06-JUL-2023
 Created By: BARRINGT_J On: 06-JUL-2023
 Modified By: JASROTIA_P On: 06-JUL-2023
 Customer: SO-DIST
 Project: BLOOM-RESP
 Division:
 District: South District
 Event Description: Algal Bloom Response -SOROC

Send Coolers To:

Phone: 239-332-6975 SC 748-6975
 FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: John Barrington
 Cooler Ship EMail: john.barrington@floridadep.gov

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 06-JUL-2023
 Biology Request Reviewed By: JASROTIA_P On: 06-JUL-2023
 Sampling Kit Required: YES Ship on: 12-JUL-2023
 Sampling Kit Shipped: YES On: 10-JUL-2023
 Sampling Kit Packed By: LEBRUN_T
 Preservatives Needed: YES
 Date to Receive Samples: 17-JUL-2023
 Logged In By: PENDLETO_C On: 04-AUG-2023

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: John Barrington
 Report Notification EMail:
 Cheryl.Swanson@dep.state.fl.us;Nicole.Reistad@floridadep.gov;
 John.Barrington@floridadep.gov;Gary.Snorek@dep.state.fl.us;Th
 omas.Baker@floridadep.gov

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxins, nutrients, chlorophyll, color

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please ship with minimum of 2 coolers

Bottle Group A (Biological) With 8 Samples:

Bottle Type: PT-50ML Number of Bottles: 8 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB18) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 8 Samples:

Bottle Type: BP-1L Number of Bottles: 8 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-250ML Number of Bottles: 8 Preserved With: ICE
 W-COLOR Template: DEFAULT (DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
 Color (true)

Bottle Type: P-125ML Number of Bottles: 8 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
 W-SAXTN-MS Template: DEFAULT (EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 8 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 8 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.