

RQ- 2023-07-24-40

Login Checklist

Login Station ID: 5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 12/19/23 @ 9:08

*Cooler Temperature	Samples Frozen? YES	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
		HNO ₃	Formalin		Present?		*Intact?		
					Yes	No	Yes	No	
1.5				6		X			648184564823

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No XContainers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: C-P

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes X No _____ NA _____ Init: C-P

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA X Init: C-P

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C-P

Date: 12/19/23

Event contains NCRs (Y/N)? N

Event ID:

SO-DIST-2023-12-19-01 (BLOOM-RESP)

Date Received: 19-DEC-2023 09:08

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 10/16/24
pH Test Strips 0 – 6	223819av 03/15/2024
pH Paper 0 – 3	NA
pH Paper 0 – 13	210820 3/15/2024
Chlorine Test Strips	0070 02/2023

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____



Cyanobacteria Bloom Response Field Data Sheet (2023-06-12 v1)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2023-07-24-40		Collected By:		Sam Eriksen						
Customer:		Field Report Prepared By:								
Project ID: BLOOM_RESP		Sampling Agency:		County						
Location: Lake Glenada- Boat Ramp			Comments: Clear sunny sky. SE winds 10-15 mph. Lake waters a light chop. Bright green clumps of BGA suspended in water column and on surface.							
Field ID: HAB-HC-121823-1145			Coordinates: 27.56341, -81.51165							
WIN Secondary Resource Type: Lake			Collection Equip: WaterBottle							
WIN ID:			High Tide Time:		Low Tide Time:					
Matrix: Fresh		Grab		Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A						
Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)
12/18/2023	11:45	98	8.98	19.6	7.52	0.3	1.2	0.6	191.5	0.09
Bloom Observations										
Algal Bloom Observed? ☒ Yes ☐ No										
Water Clarity		☐ Clear		☐ Slightly Turbid		☒ Turbid		☐ Opaque		
Bloom Color		☒ Green		☐ Red		☐ Brown		☐ Other:		
Algae Type		☒ Planktonic		☐ Filamentous		☐ Other:				
Algae Accumulation		☐ Mat		☒ Specks		☐ Scum		☒ Glob		
Algae Distribution		☒ Surface-Entire		☐ Surf-Localized		☐ Surf-Windblown		☐ Suspended		☐ Benthic ☐ Epiphytic
Parameter Suite		Parameter Methods				Preservation		pH Check	#Bottles Sent to Lab	Bottle Group
Algae (PT-50mL)		☐ ALGAL-ID ☒ BLOOM-ID				☒ Ice			1	A
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	B
Toxins (P-125/BG-250)		☒ W-MCYST-AA ☒ W-SAXTN-MS ☐ OV-TOXN				☒ Ice			1	B
Physical/Aggregate		☐ W-COLOR				☐ Ice				
Preserved Nutrients (500mL HDPE)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP				☒ Ice ☒ H2SO4		☒ <2	1	B
		SA3013020		Acid Lot:		Exp:		01/25/24		
Filtered Nutrients (P125mL)		☒ W-PO4-F		☒ Field Filtered 0.45µm Filter		☒ Ice			1	B
				Filter Lot # 17441866						
Quantitative Algae		☐ DTY-QN-C / PKD-QN-C				☐ Ice ☐ Lugols				
Relinquished By:		Date/Time		Number of Coolers Shipped		Received By:		Date/Time		
						C-8		12-19-23 / 9:08		

Date of Request: 10-JUL-2023
 Created By: BARRINGT_J On: 10-JUL-2023
 Modified By: AYRES_J On: 10-JUL-2023
 Customer: SO-DIST
 Project: BLOOM-RESP
 Division:
 District: South District
 Event Description: Algal Bloom Response -SOROC

Send Coolers To:

Phone: 239-332-6975 SC 748-6975
 FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: John Barrington
 Cooler Ship EMail: john.barrington@floridadep.gov

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 10-JUL-2023
 Biology Request Reviewed By: AYRES_J On: 10-JUL-2023
 Sampling Kit Required: YES Ship on: 17-JUL-2023
 Sampling Kit Shipped: YES On: 14-JUL-2023
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: YES
 Date to Receive Samples: 24-JUL-2023
 Logged In By: LEBRUN_T On: 08-DEC-2023

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 314
 Fort Myers, FL 33901-3381
 Attn: John Barrington
 Report Notification EMail:
 Cheryl.Swanson@dep.state.fl.us;Nicole.Reistad@floridadep.gov;
 John.Barrington@floridadep.gov;Gary.Snorek@dep.state.fl.us;Th
 omas.Baker@floridadep.gov

Comments: Unless peak algal bloom season, may analyze toxin after consultation with Biology's Taxonomy Manager.

Bottle Group A - Priority 1
 For algal dominant taxon.

Bottle Group B - Priority 1
 For toxins, nutrients, chlorophyll, color

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please ship with minimum of 2 coolers

Bottle Group A (Biological) With 8 Samples:

Bottle Type: PT-50ML Number of Bottles: 8 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB18) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 8 Samples:

Bottle Type: BP-1L Number of Bottles: 8 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-250ML Number of Bottles: 8 Preserved With: ICE
 W-COLOR Template: DEFAULT (DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
 Color (true)

Bottle Type: P-125ML Number of Bottles: 8 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

W-SAXTN-MS Template: DEFAULT (EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 8 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 8 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.