

Login Checklist

RQ- 2023-07-24-49

Login Station ID: #4

Shipping Method: ~~FedEx~~ | UPS | HD | Greyhound

Date/Time of Receipt: 07/ 28 /2023@08:53

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.4				6		X			585947374337

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA X

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes X No _____

Caps on tight?

Yes X No _____

Sufficient Sample Volume:

Yes X No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: TL

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes X No _____ NA _____ Init: TL

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA X Init: TL

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: TL

Date: 07/ 28 /2023

Event contains NCRs (Y/N)? N

Event ID: WQAP-2023-07-28-02

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #4 Exp:10/17/2023
pH Test Strips 0 – 6	LOT# 223819AV Exp: AUG 30, 2023
pH Paper 0 – 3	N/A
pH Paper 0 – 13	LOT# 207621 Exp: March 15, 2024
Chlorine Test Strips	LOT# 1196 Exp: Feb. 2024

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____



Cyanobacteria Bloom Response Field Data Sheet (2023-06-12 v1)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2023-07-24-49		Collected By:		Katrin Villinger, Jeremy Parrish	
Customer:	NE-DIST	Field Report Prepared By:		KVILLINGER	
Project ID:	BLOOM_RESP	Sampling Agency:		NEROC	
Location: Doctors Lake - end of Lawrence Rd			Comments:		
Field ID: NEHAB0073			Coordinates: 30.12992, -81.75203		
WIN Secondary Resource Type: Lake			Collection Equip: WaterBottle		
WIN ID: NEHAB0073			High Tide Time:		19:48
			Low Tide Time:		12:45
Matrix:	Fresh	Grab	Tide: ☒ Rising ☐ Falling ☐ Slack ☐ N/A		
Water Quality					
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)
07/27/2023	13:45	112.6	8.16	32.1	7.96
Bloom Observations					
Algal Bloom Observed? ☒ Yes ☐ No					
Water Clarity	☐ Clear	☐ Slightly Turbid	☒ Turbid	☐ Opaque	
Bloom Color	☒ Green	☐ Red	☐ Brown	☐ Other:	
Algae Type	☒ Planktonic	☐ Filamentous	☐ Other:		
Algae Accumulation	☐ Mat	☒ Specks	☐ Scum	☐ Glob	
Algae Distribution	☐ Surface-Entire	☒ Surf-Localized	☐ Surf-Windblown	☒ Suspended	☐ Benthic ☐ Epiphytic
Parameter Suite	Parameter Methods		Preservation	pH Check	#Bottles Sent to Lab
Algae (PT-50mL)	☐ ALGAL-ID ☒ BLOOM-ID		☒ Ice		1
Chlorophyll (BP-1L)	☒ CHLSUITE-W		☒ Ice		1
Toxins (P-125/BG-250)	☒ W-MCYST-AA ☒ W-SAXTN-MS ☐ OV-TOXN		☒ Ice		1
Physical/Aggregate	☒ W-COLOR		☒ Ice		1
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / ☒ W-NO2NO3 / ☒ W-TKN / ☒ W-S-A-TP		☒ Ice ☒ H2SO4	☒ <2	1
	SA2229010		8/30/23		
	Acid Lot:		Exp:		
Filtered Nutrients (P125mL)	☒ W-PO4-F		☒ Field Filtered 0.45um Filter		1
			Filter Lot # 175533		C
Quantitative Algae	☐ DTY-QN-C / PKD-QN-C		☐ Ice	☐ Lugols	
Relinquished By:	Date/Time	Number of Coolers Shipped		Received By:	Date/Time
KVILLINGER	07/27/2023 16:30	1		TL	7/28/23 @ 08:53

Date of Request: 18-JUL-2023
 Created By: VILLINGE_K On: 18-JUL-2023
 Modified By: SWANSON_C On: 21-JUL-2023
 Customer: WQAP
 Project: BLOOM-RESP
 Division: Division of Environmental Assessment and Restoration
 District:
 Event Description: Algae Bloom Response NEROC-as needed

Send Coolers To:

Phone: 9042561541
 8800 Baymeadows Way W
 Suite 100
 Jacksonville, FL 32256
 Attn: Katrin Villinger
 Cooler Ship EMail: Katrin.villinger@floridadep.gov

Priority: 1
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: AYRES_J On: 18-JUL-2023
 Biology Request Reviewed By: SWANSON_C On: 21-JUL-2023
 Sampling Kit Required: YES Ship on: 01-AUG-2023
 Sampling Kit Shipped: YES On: 27-JUL-2023
 Sampling Kit Packed By: PENDLETO_C
 Preservatives Needed: NO
 Date to Receive Samples: 24-JUL-2023
 Logged In By: LEBRUN_T On: 28-JUL-2023

Send Final Report To:

8800 Baymeadows Way W
 Suite 100
 Jacksonville, FL 32256
 Attn: Katrin Villinger
 Report Notification EMail: Katrin.Villinger@floridadep.gov

Comments:

Bottle Group A - Priority 1
 For Bloom ID dominant taxon.

Bottle Group B - Priority 1
 For toxin testing Nurtients, Chlorophyl, Toxin.

Bottle Group C - Priority 1
 For toxin testing Nurtients, Chlorophyl, Toxin w/ SAX.

Bottle Group D - Priority 1
 Field Blank for QC on Nurtients and Toxin.

Bottle Group A (Biological) With 12 Samples:

Bottle Type: PT-50ML Number of Bottles: 12 Preserved With: ICE
 BLOOM-ID Template: DEFAULT (SOP-AB18) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 6 Samples:

Bottle Type: BP-1L Number of Bottles: 6 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-250ML Number of Bottles: 6 Preserved With: ICE
 W-COLOR Template: DEFAULT (DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
 Color (true)

Bottle Type: P-125ML Number of Bottles: 6 Preserved With: ICE
 W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS

Bottle Type: P-500ML Number of Bottles: 6 Preserved With: ICE And H2SO4
 W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
 W-NO2NO3 Template: DEFAULT (EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
 W-S-A-TP Template: DEFAULT (EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
 W-TKN Template: DEFAULT (EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML Number of Bottles: 6 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 6 Samples:

Bottle Type: P-500ML	Number of Bottles: 6	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 6	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BP-1L	Number of Bottles: 6	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML	Number of Bottles: 6	Preserved With: ICE
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
Bottle Type: P-125ML	Number of Bottles: 6	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
W-SAXTN-MS	Template: DEFAULT	(EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-250ML	Number of Bottles: 1	Preserved With: ICE
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
W-SAXTN-MS	Template: DEFAULT	(EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.