

Login Checklist

RQ- 2024-04-22-56

Login Station ID: 5

Shipping Method: FedEx UPS | HD | Greyhound

Date/Time of Receipt: 5/3 124 @ 9.08

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
					Yes	No	Yes	No	
2.7				6		X			728166288528

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes X No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No X

CONTAINER CHECK

Evidence Tape on Bottles? Yes _____ No _____ NA X Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken? Yes _____ No X Containers intact? Yes X No _____

Caps on tight? Yes X No _____

Sufficient Sample Volume: Yes X No _____

If NO is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No X Init: C.P

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0? Yes X No _____ NA _____ Init: C.P

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes _____ No _____ NA X Init: C.P

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: C.P Date: 5/3 124 Event contains NCRs (Y/N)? N

Event ID: SE-DIST-2024-05-03-01 (BLOOM-RESP)

Date Received: 03-MAY-2024 09:08

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 10/16/24
pH Test Strips 0 – 6	223819av 03/15/2024
pH Paper 0 – 3	NA
pH Paper 0 – 13	210820 3/15/2024
Chlorine Test Strips	2313 07/2025

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____



Cyanobacteria Bloom Response Field Data Sheet (2023-06-12 v1)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2024-04-22-56		Collected By:		Natalie Howard, Drew Liddick						
Customer:		Field Report Prepared By:		Natalie Howard						
Project ID: BLOOM_RESP		Sampling Agency:		SEROC						
Location: Desoto Lakes - Lake Shore Drive		Comments:								
Field ID: SEHAB0118		Coordinates:		25.97956, -80.17224						
WIN Secondary Resource Type: Lake		Collection Equip:		WaterBottle						
WIN ID: SEHAB0118		High Tide Time:		Low Tide Time:						
Matrix: Fresh		Grab		Tide: ☐ Rising ☐ Falling ☐ Slack ☒ N/A						
Water Quality										
Date	Time ☒ EST ☐ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPT)
05/02/2024	14:00	120.8	9.63	27.3	8.73	0.3	1.2	1.2	177.9	0.08
Bloom Observations										
Algal Bloom Observed? ☐ Yes ☒ No										
Water Clarity		☐ Clear		☒ Slightly Turbid		☐ Turbid		☐ Opaque		
Bloom Color		☐ Green		☐ Red		☐ Brown		☐ Other:		
Algae Type		☐ Planktonic		☐ Filamentous		☐ Other:				
Algae Accumulation		☐ Mat		☐ Specks		☐ Scum		☐ Glob		
Algae Distribution		☐ Surface-Entire		☐ Surf-Localized		☐ Surf-Windblown		☐ Suspended		☐ Benthic ☐ Epiphytic
Parameter Suite		Parameter Methods				Preservation		pH Check	#Bottles Sent to Lab	Bottle Group
Algae (PT-50mL)		☐ ALGAL-ID ☒ BLOOM-ID				☒ Ice			1	A
Chlorophyll (BP-1L)		☒ CHLSUITE-W				☒ Ice			1	C
Toxins (P-125/BG-250)		☒ W-MCYST-AA ☒ W-SAXTN-MS ☐ OV-TOXN				☒ Ice			1	B
Physical/Aggregate		☒ W-COLOR				☒ Ice			1	C
Preserved Nutrients (500mL HDPE)		☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP				☒ Ice ☒ H2SO4		☒ <2	1	C
		SA3340020				12/11/2024				
		Acid Lot:		Exp:						
Filtered Nutrients (P125mL)		☒ W-PO4-F		☒ Field Filtered 0.45µm Filter		☒ Ice			1	C
				Filter Lot # 17347262						
Quantitative Algae		☐ DTY-QN-C / PKD-QN-C				☐ Ice ☐ Lugols				
Relinquished By:		Date/Time		Number of Coolers Shipped		Received By:		Date/Time		
		05/02/2024 14:40		1		C P		5.3.24 / 4:08		

Date of Request: 08-APR-2024
Created By: SKAGGS_J On: 08-APR-2024
Modified By: JASROTIA_P On: 09-APR-2024
Customer: SE-DIST
Project: BLOOM-RESP
Division:
District: Southeast District
Event Description: Algal Bloom Response - SE ROC

Send Coolers To:

Phone: (772) 380-5572
FL Dept. of Environmental Protection
2199 South Rock Road
Fort Pierce, FL 34945
Attn: Jordan Skaggs
Cooler Ship EMail: jordan.skaggs@floridadep.gov

Priority: 1
Event Status: R
Criminal Investigation: NO
Chemistry Request Reviewed By: AYRES_J On: 09-APR-2024
Biology Request Reviewed By: JASROTIA_P On: 09-APR-2024
Sampling Kit Required: YES Ship on: 15-APR-2024
Sampling Kit Shipped: YES On: 15-APR-2024
Sampling Kit Packed By: PENDLETO_C
Preservatives Needed: YES
Date to Receive Samples: 26-APR-2024
Logged In By: KLUG_K On: 30-APR-2024

Send Final Report To:

FL Dept. of Environmental Protection
2199 South Rock Road
Fort Pierce, FL 34945
Attn: Andrew Luering
Report Notification EMail:
jordan.skaggs@floridadep.gov;andrew.luering@floridadep.gov

Comments: **Please send:
-4 full-size coolers
-4 extra Fedex labels
-2 boxes Nitric acid
-2 boxes Sulfuric acid

LOG-IN STAFF: Please print two copies of algal job labels at login.

Bottle Group A - Priority 1 for algal dominant taxon.
Bottle Group B - Priority 1 for toxin testing.

Bottle Group C - Priority 3 (nutrients); Priority 4 (chlorophyll)

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Bottle Group A (Biological) With 15 Samples:

Bottle Type: PT-50ML Number of Bottles: 15 Preserved With: ICE
BLOOM-ID Template: DEFAULT (SOP-AB18) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 15 Samples:

Bottle Type: P-125ML Number of Bottles: 15 Preserved With: ICE
W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
W-SAXTN-MS Template: DEFAULT (EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS

Bottle Group C (Water) With 15 Samples:

Bottle Type: BP-1L Number of Bottles: 15 Preserved With: ICE
CHLSUITE-W Template: DEFAULT (SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML Number of Bottles: 15 Preserved With: ICE
W-COLOR Template: DEFAULT (DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)
Bottle Type: P-500ML Number of Bottles: 15 Preserved With: ICE And H2SO4
W-NH3 Template: DEFAULT (EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L

Bottle Group C (Water) With 15 Samples:

Bottle Type: P-500ML	Number of Bottles: 15	Preserved With: ICE And H2SO4
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 15	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.