

Login Checklist

RQ- 2024-05-27-31

Login Station ID: #1

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 05/ 29 /24 @ 8:45

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.7				4		✓			7281 6631 3603
		</							

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ☒ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ☒

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ☒

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ☒ No _____

Caps on tight?

Yes ☒ No _____

Sufficient Sample Volume:

Yes ☒ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ☒ Init: kh

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes _____ No _____ NA ☒ Init: kh

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ☒ Init: kh

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: kh

Date: 05/ 29 /24

Event contains NCRs(Y/N)? N

EventID: Algal Bloom Response - NW ROC
NW-DIST-2024-05-29-01 (BLOOM-RESP)

Date Received: 29-MAY-2024 08:45

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Infrared Thermometer ID:	IR TEMP GUN #1 Exp:10/16/2024
pH Test Strips 0 – 6	Lot#223819BV Exp:8/15/24
pH Paper 0 – 3	
pH Paper 0 – 13	Lot# 228323 Exp:10/01/26
Chlorine Test Strips	Lot#3180A Exp:4/26

Additional Comments:

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____



Cyanobacteria Bloom Response Field Data Sheet (2023-06-12 v1)

Email scanned submittal forms to lab.receiving@FloridaDEP.gov

RQ - 2024-05-27-31		Collected By:	Nathan Mulkey, Frank Butera							
Customer:	NWROC	Field Report Prepared By:	Nathan Mulkey							
Project ID:	BLOOM_RESP	Sampling Agency:	NWROC							
Location: Lake Cassidy		Comments: Central lab not accepting ortho phos or color at time of sampling								
Field ID: NWHAB0019		Coordinates:	30.81621, -86.03108							
WIN Secondary Resource Type: Lake		Collection Equip:	WaterBottle							
WIN ID: NWHAB0019		High Tide Time:	Low Tide Time:							
Matrix:	Fresh	Grab	Tide: ☐ Rising ☐ Falling ☐ Slack ☐ N/A							
Water Quality										
Date	Time ☐ EST ☒ CEN	D.O. (%)	D.O. (mg/L)	Temp (°C)	pH (SU)	Sample Depth (m)	Total Depth (m)	Secchi Disk (m)	Sp. Cond. (µmho/cm)	Salinity (PPTH)
05/28/2024	10:30	114.2	8.81	28.9	6.13	0.3	10.2	1.8	14.9	0.01
Bloom Observations										
Algal Bloom Observed? ☐ Yes ☒ No										
Water Clarity	☐ Clear	☐ Slightly Turbid	☒ Turbid	☐ Opaque						
Bloom Color	☐ Green	☐ Red	☐ Brown	☐ Other:						
Algae Type	☐ Planktonic	☐ Filamentous	☐ Other:							
Algae Accumulation	☐ Mat	☐ Specks	☐ Scum	☐ Glob						
Algae Distribution	☐ Surface-Entire	☐ Surf-Localized	☐ Surf-Windblown	☐ Suspended	☐ Benthic	☐ Epiphytic				
Parameter Suite	Parameter Methods		Preservation		pH Check	#Bottles Sent to Lab	Bottle Group			
Algae (PT-50mL)	☐ ALGAL-ID ☒ BLOOM-ID		☒ Ice			1	A			
Chlorophyll (BP-1L)	☒ CHLSUITE-W		☒ Ice			1	C			
Toxins (P-125/BG-250)	☒ W-MCYST-AA ☒ W-SAXTN-MS ☐ OV-TOXN		☒ Ice			1	B			
Physical/Aggregate	☐ W-COLOR		☐ Ice							
Preserved Nutrients (500mL HDPE)	☒ W-NH3 / W-NO2NO3 / W-TKN / W-S-A-TP		☒ Ice ☒ H2SO4		☐ <2	1	C			
		3193140	07/31/2024							
Filtered Nutrients (P125mL)	☐ W-PO4-F		☐ Field Filtered 0.45µm Filter		☐ Ice					
		Filter Lot #								
Quantitative Algae	☐ DTY-QN-C / PKD-QN-C		☐ Ice ☐ Lugols							
Relinquished By:	Date/Time	Number of Coolers Shipped		Received By:	Date/Time					
Nathan Mulkey	05/28/2024 16:00	1		NK	5.29.24/08:45					

Date of Request: 06-MAY-2024
Created By: SLADE_C On: 06-MAY-2024
Modified By: JASROTIA_P On: 08-MAY-2024
Customer: NW-DIST
Project: BLOOM-RESP
Division:
District: Northwest District
Event Description: Algal Bloom Response - NW ROC

Send Coolers To:

Phone: 850-595-8300
160 Government Center
Suite 308
Pensacola, FL 32502-5794
Attn: Stopher Slade
Cooler Ship EMail: Christopher.slade@dep.state.fl.us

Priority: 1
Event Status: S
Criminal Investigation: NO
Chemistry Request Reviewed By: AYRES_J On: 08-MAY-2024
Biology Request Reviewed By: JASROTIA_P On: 08-MAY-2024
Sampling Kit Required: YES Ship on: 24-MAY-2024
Sampling Kit Shipped: YES On: 21-MAY-2024
Sampling Kit Packed By: SHAIK_A
Preservatives Needed: NO
Date to Receive Samples: 06-JUN-2024
Logged In By:

Send Final Report To:

160 Government Center
Suite 308
Pensacola, FL 32502-5794
Attn: Myranda Butler
Report Notification EMail:
christopher.slade@dep.state.fl.us;michael.king@dep.state.fl.us;
myranda.k.butler@dep.state.fl.us;alicia.hogue@dep.state.fl.us;m
ary.c.rice@floridadep.gov;david.d.whiting@floridadep.gov;amelia.
rankin@floridadep.gov;cheryl.swanson@floridadep.gov

Comments:
Bottle Groups A/B - separate event, priority 1.
Bottle Group C/D - separate event, priority 3.

#####

Bottle Group A - Priority 1 for algal dominant taxon.

Bottle Group B - Priority 1 for toxin testing,

Bottle Group C - Priority 3 (nutrients & chlorophyll)

Bottle Group D - Priority 1 (Field blank: toxins)

Bottle Group E - Priority 3 (Field blank: nutrients)

There are multiple bottles per Group in case multiple sample targets or sample locations are needed. Samplers use best professional judgement to decide which samples are appropriate to collect for a particular response. All sets of bottles do not have to be filled at one time.

Please print two copies of algal job labels at login

#####

Bottle Group A (Biological) With 2 Samples:

Bottle Type: PT-50ML Number of Bottles: 2 Preserved With: ICE
BLOOM-ID Template: DEFAULT (SOP-AB18) Assessment of dominant algal taxa in bloom or mat sample

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-125ML Number of Bottles: 2 Preserved With: ICE
W-MCYST-AA Template: DEFAULT (EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
W-SAXTN-MS Template: DEFAULT (EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS

Bottle Group C (Water) With 2 Samples:

Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10150 B) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML	Number of Bottles: 2	Preserved With: ICE
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE
W-MCYST-AA	Template: DEFAULT	(EPA 8321B) Microcystins in water matrices by HPLC/MS/MS
W-SAXTN-MS	Template: DEFAULT	(EPA 8321B) Saxitoxin in water matrices by HPLC/MS/MS

Bottle Group E (Water) With 1 Samples:

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-250ML	Number of Bottles: 1	Preserved With: ICE
W-COLOR	Template: DEFAULT	(DEP SOP: NU-094-1) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.