

Login Checklist

RQ- **2021 - 08 - 02 - 51**

Login Station ID: **# 3**

Shipping Method: **FedEx** | UPS | HD | Greyhound

Date/Time of Receipt: **09-29-2021 / 09:45**

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2.2c				8		X			9293 8015 5498

COOLER CHECK

***All samples received on ice unless otherwise noted. HNO3 and Formalin preserved samples do NOT have a temperature requirement.**

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. **NCR#** _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. **NCR#** _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. **NCR#** _____
- If coolers or samples are received late; identify the affected samples in an NCR. **NCR#** _____

Chain of Custody/ Field Sheet(s) Included?

Yes **X** No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No **X**

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA **X**

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes **X** No _____

Caps on tight?

Yes **X** No _____

Sufficient Sample Volume:

Yes **X** No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. **NCR#** _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No **X** Init: **ABS /**

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: **ABS /**

If chlorine is detected, generate an NCR listing affected sample IDs . **NCR#** _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples:** pH< 2.0?

Yes **X** No _____ NA _____ Init: **ABS /**

****W-1-4-DIOX** (Green dot on container) preserved to pH<4.0?

Yes _____ No _____ NA **X** Init: **ABS /**

If samples were not preserved correctly, generate an NCR listing affected sample IDs . **NCR#** _____

Coolers Unpacked/Checked by: **ABS /**

Date: **09-29-2021**

Event contains NCRs (Y/N)? **n**

Event ID:

CEN - DIST - 2021 - 09 - 29 - 04

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IRTB # 3 EXP:10/28/2021
pH Test Strips 0 – 6	Lot # 232518V EXP:NOV 30 2021
pH Paper 0 – 3	N/A
pH Paper 0 – 13	Lot # 231019 EXP:NOV 1 2022
Chlorine Test Strips	0261 2023 / 05

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: ABS

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

FLORIDA DEPARTMENT OF ENVIRONMENTAL PROTECTION
CHAIN OF CUSTODY FORM

Date: 9/28/2021
Customer: CEN-DIST
RQ: RQ-2021-08-02-51
Collected By: Elizabeth Bates, Victoria Schwartz
Sampling: FDEP
Agency:
Project ID: BMAP

PLEASE RETURN THE ORIGINAL OF THIS FORM WITH SAMPLE SUBMITTAL
FORMS AND THE COOLER PACKING WORKSHEET TO THE LAB

Number of Coolers Shipped: 1

Delivery Method: FedEx

FIELD ID (Labels) submitted under this RQ for this collection date.

Site Location	Field ID/WIN ID
Long Branch @ 0.7 mi DS OF CR 13	 G2CE0036

RELINQUISHED BY(SIGNATURE):



DATE/TIME: 9/28/2021
1600 EST

THIS SECTION TO BE COMPLETED BY LABORATORY

Rec'd/Inspected By: A.SHAIK

Rec'd/Inspected
Date: 09-29-2021

Qty: 1
Bottle Group A
BOD-UNIN

*sent to Test America in separate cooler.



RQ-2021-08-02-51	Collected By: Elizabeth Bates, Victoria Schwartz
Customer: FDEP	Field Report Prepared by: Elizabeth Bates, Victoria Schwartz
Project ID: SMP	Sampling Agency: FDEP
WIN ID/Field ID:  WIN ID/Field ID: G2CE0036	Comments: 1 BOD-UNIN SENT TO TEST AMERICA BOTTLE GROUP A

Location:

Location: Long Branch @ 0.7 mi DS OF CR 13

Matrix: Fresh

(Check One)

☒ Grab☐ Composite

Date and Time {EST}	DO (mg/L)	DO (%SAT)	Temp. °C	pH	Sample Depth (m)	Secchi Depth	Total Depth (m)	Sp COND (µmhos /cm)	Salinity (PPT)
9/28/2021 1005	6.04	71.3	23.6	6.82	0.3	0.5	0.7	197.7	0.09

Parameter Suite	Parameter Methods				Preservation		pH Check		# Bottles sent to Lab	Bottle Group				
Preserved Nutrients (P-500ML)	X	W-NH3 / W-NO2NO3 / W-TKN / W-TOC / W-S-A-TP			X	Ice	X	H2SO4*	X	<2	1	A		
		Lot #	SA1105060		Exp:	4/30/22								
Metals (P-500ML)	X	W-ICPMS		X	W-ICP	W-HARD	X	Ice		HNO3*		<2	1	A
		Lot #	NA0344060		Exp:	1/4/22								
Filtered Nutrients (P125ML)	X	W-PO4-F		X	Field Filtered 0.45 µm Filter			X	Ice			1	A	
		Filter Lot #	17135566											
		Syringe Lot #	1112035											
Chlorophyll (BP-1L)	X	CHLSUITE-W				X	Ice					1	A	
Physical/Aggregate (Fresh) (P-1L)	X	Alkalinity / W-F / W-TSS / TURBIDITY / W-CHC / W-COLOR / W-SO4-IC / W-TDS				X	Ice					1	A	
Physical/Aggregate (Marine) (P-1L)		Alkalinity / W-BR-IC / W-F / W-TSS / TURBIDITY					Ice							
Macroinvertebrates (PJ-2L)		MI-FW-QLDC	Formalin Lot #				Formalin							
Periphyton (PT-50ML)		ALGAE-ID					Ice							
Microbiology (Contract Lab Bottle)	X	E Coli		F Coli		Enterococci	X	Ice				2	A	
		Contract Lab												
Molecular (QPCR-P-500ML)		PCR-HF183		PCR-BacR		PCR-DG3		Ice						
		PCR-GULL2		PCR-GFD										
Tracers / Sucralose- 2-BG-40mL (BG-500ML) No Acid		W-E8321-DI		W-E8321-MS	X	W-SUC-AA-R	X	Ice				2	A	
		W-E8321-DI		W-E8321-MS		W-PSNP-TQ		Ice						
Pesticides (BG-500ML) (BG-1L)		W-PCL-TQ-R		W-CARB-AA (5 ml of MCAA** Buffer Solution)		W-CT-CL-R								
Phytoplankton		DTY-QN-C		PKD-QN-BV				Ice						

Date of Request: 14-JUL-2021
 Created By: BOMAN_L On: 14-JUL-2021
 Modified By: JASROTIA_P On: 15-JUL-2021
 Customer: CEN-DIST
 Project: BMAP
 Division:
 District: Central District
 Event Description: Long Branch

Send Coolers To:

Phone: 407-897-4181
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Leif Boman
 Cooler Ship EMail: Leif.Boman@FloridaDEP.gov

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 15-JUL-2021
 Biology Request Reviewed By: JASROTIA_P On: 15-JUL-2021
 Sampling Kit Required: YES Ship on: 23-JUL-2021
 Sampling Kit Shipped: YES On: 22-JUL-2021
 Sampling Kit Packed By: MCCOY_I
 Preservatives Needed: NO
 Date to Receive Samples: 02-AUG-2021
 Logged In By: SHAIK_A On: 29-SEP-2021

Send Final Report To:

3319 Maguire Blvd. Suite 232

 Orlando, FL 32803-3767
 Attn: Matt Bearden
 Report Notification EMail: Matthew.Bearden@FloridaDEP.gov

Comments: ****OVERFLOW BOD Eurofins/TestAmerica-Tampa****
 Send additional:
 - documentation
 - small cooler/liner/zip tie
 - temp bottle
 - overnight shipping/handle tag to TA-Tampa
 - Task Assignment needs to be complete before samples arrive at Tampa lab

Eurofins/Testamerica
 Attn: Sample Receiving
 6712 Benjamin Rd.
 Suite 100
 Tampa, FL 33634
 (813) 885-7427

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 B Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
OV-BOD-UN	Template: DEFAULT	(SM 5210 B) BOD, NOT nitrogen-inhibited at Eurofins Testamerica-Tampa
Bottle Type: 2-BG-40ML NO ACID	Number of Bottles: 1	Preserved With: ICE
W-E8321-21	Template: DEFAULT	(EPA 8321B) Water soluble organic compounds by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Chromium		
Iron		
Magnesium		
Nickel		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Cadmium		
Copper		
Lead		
Silver		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L