

Login Checklist

RQ- 2021-08-16-17

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 9/ 2 /21 @ 16:20

*Cooler Temperature	Samples Frozen?	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Waybill Tracking #
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
0.5				6		✓			

COOLER CHECK

*All samples received on ice unless otherwise noted. HNO₃ and Formalin preserved samples do NOT have a temperature requirement.

- If the temperature of a cooler exceeds 6.0 oC (above 10.0 oC for W-1-4-DIOX and microbiology) or received without ice, identify affected samples in an NCR. NCR# _____
- DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C for W-1-4-DIOX) without login confirmation from customer for samples requiring ice preservation; identify affected samples in an NCR. NCR# _____
- If cooler or samples are received with a damaged Evidence Seal; identify the affected samples in an NCR. NCR# _____
- If coolers or samples are received late; identify the affected samples in an NCR. NCR# _____

Chain of Custody/ Field Sheet(s) Included?

Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included?

Yes _____ No ✓

CONTAINER CHECK

Evidence Tape on Bottles?

Yes _____ No _____ NA ✓

Evidence Tape intact? Yes _____ No _____

If Criminal, photographs taken?

Yes _____ No _____

Containers intact? Yes ✓ No _____

Caps on tight?

Yes ✓ No _____

Sufficient Sample Volume:

Yes ✓ No _____

If **NO** is checked above, generate an NCR listing affected sample IDs in its appropriate category. NCR# _____

CHLORINE CHECK REQUIRED? (Blue dot on container)

Yes _____ No ✓ Init: KK

Chlorine detected? (One container checked per Field ID)

Yes _____ No _____ Init: _____

If chlorine is detected, generate an NCR listing affected sample IDs . NCR# _____

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH < 2.0?

Yes ✓ No _____ NA _____ Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?

Yes _____ No _____ NA ✓ Init: KK

If samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

Coolers Unpacked/Checked by: KK

Date: 9/ 2 /21

Event contains NCRs (Y/N)? N

Event ID: Reference Lake Sampling
BSSP-2021-09-02-01 (LAKESREF)
 Date Received: 02-SEP-2021 16:20

Login Checklist

Login Preservation Equipment

Lot # & Exp: Date

Additional Comments:

Infrared Thermometer ID:	IR TEMP GUN #5 EXP:10-28-21
pH Test Strips 0 – 6	Lot#210620 EXP:4-15-23
pH Paper 0 – 3	
pH Paper 0 – 13	Lot#210620 EXP:4-15-23
Chlorine Test Strips	Lot#0261 EXP:5-23

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ Init: _____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

If S-VOC-MS samples were not preserved correctly, generate an NCR listing affected sample IDs . NCR# _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Request Number: RQ-2021-08-16-17

Reference Lake Sampling

Florida Department of Environmental Protection Central Laboratory Submittal Form

Page 1 of 2

last revised Jan 25, 2018

Customer: BSSP

Project ID: LAKESREF

Requester: Jennifer. N. Piacente

Collected By: K. Sprague

Field Report Prepared By: K. Sprague

Sampling Agency: FDEP

Location Lake Iamonia LVI		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 9/2/21 Time 14:30		Eastern Central	Composite end Date Time		Bottle Group(s) (See pg 2) A
Field ID Lake Iamonia		Matrix (type, e.g., Salt, Fresh, etc) Fresh		Diss. Oxygen 53.9% / 4.11 mg/L	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C) 29.7	pH 7.53	Sample Depth 0.2	☐ ft ☒ m	Sp. Conductance (umho/cm) 31.3		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)		Comments				
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time		Eastern Central	Composite end Date Time		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)		Comments				
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time		Eastern Central	Composite end Date Time		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)		Comments				
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time		Eastern Central	Composite end Date Time		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)		Comments				
Location		☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time		Eastern Central	Composite end Date Time		Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		
WIN/STORET #		Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)		
Latitude ☐ dd ☐ dms	Longitude ☐ dd ☐ dms	Salinity (ppt)		Comments				

Relinquished By: Kara Sprague	Date/Time 9/2/21 16:15	Shipping Method _____	Number of Coolers Shipped: _____	Received By: [Signature]	Date/Time 9/2/21 16:20
---	----------------------------------	---------------------------------	--	------------------------------------	----------------------------------

Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	Lugols	Enter Number of Bottles Sent to Lab _____
	DTY-QN-C					
	PKD-QN-C					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab _____
	W-ICP				Lot: NA1105100	
	W-ICPMS				exp. 6/7/22	
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3				Lot: SA1105060	
	W-NO2NO3				exp. 4/30/22	
	W-S-A-TP					
	W-TKN					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					

Date of Request: 20-JUL-2021
 Created By: PIACENTE_J On: 20-JUL-2021
 Modified By: WATTS_J On: 16-AUG-2021
 Customer: BSSP
 Project: LAKESREF
 Division: Division of Environmental Assessment and Restoration
 District:
 Event Description: Reference Lake Sampling

Send Coolers To:

Phone: 850-245-8073
 2600 Blair Stone Rd.
 Tallahassee, FL 32399-2400
 Attn: Jennifer Piacente
 Cooler Ship EMail: jennifer.piacente@floridadep.gov

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 20-JUL-2021
 Biology Request Reviewed By: JASROTIA_P On: 21-JUL-2021
 Sampling Kit Required: YES Ship on: 12-AUG-2021
 Sampling Kit Shipped: YES On: 09-AUG-2021
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 02-SEP-2021
 Logged In By:

Send Final Report To:

2600 Blair Stone Rd.
 Tallahassee, FL 32399-2400
 Attn: Jennifer Piacente
 Report Notification EMail: jennifer.piacente@floridadep.gov

Comments:**Bottle Group A (Water) With 1 Samples:**

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: Lugols
DTY-QN-C	Template: DEFAULT	(SOP-AB05_1) No. of diatom taxa of quantitative phytoplankton sample.
PKD-QN-C	Template: DEFAULT	(SOP-AB05) No. of wet taxa of quantitative phytoplankton sample.
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Beryllium		
Cadmium		
Chromium		
Copper		

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Lead
Nickel
Silver

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.