

Florida Department of Environmental Protection

Central Laboratory Submittal Form

UEC NORTH

last revised Nov 10, 2015

Customer: NE-DIST


Requester: Jann Gruentzel

Field Report Prepared By: P O'Connor

Project ID: SMP

Collected By: P. O'Connor, B Davis,

Sampling Agency: DEAR NED ROC

Location			☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/5/16 Time 1005	Eastern Central	Composite end Date Time	Bottle Group(s) (See pg 2)
Field ID	27010056 Oyster @ Dixie		Matrix (type, e.g., Salt, Fresh, etc) SURFACE SALT		Diss. Oxygen 2.58	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	B
STORET #			Temp (C) 26.16		pH 7.45	Sample Depth 0.3	Sp. Conductance (umho/cm) 29853	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 12.5	Comments DO% 34.3			
Location			☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/5/16 Time 1110	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID	27010182 Ponte Verda @ sawgrass		Matrix (type, e.g., Salt, Fresh, etc) SURFACE Fresh		Diss. Oxygen 2.06	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	NA
STORET #			Temp (C) 17.99		pH 7.51	Sample Depth 0.3	Sp. Conductance (umho/cm) 752	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 0.37	Comments No Sample Taken Due			
Location			☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/5/16 Time 1110	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID	27010182 Ponte Verda @ sawgrass		Matrix (type, e.g., Salt, Fresh, etc) SURFACE Fresh		Diss. Oxygen 2.06	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	A
STORET #			Temp (C) 17.99		pH 7.51	Sample Depth 0.3	Sp. Conductance (umho/cm) 752	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 0.37	Comments sample collected 4/5/16 DO% 21.9			
Location			☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/5/16 Time 1130	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID	27010181 Lake Verda @ Corona		Matrix (type, e.g., Salt, Fresh, etc) SURFACE Fresh		Diss. Oxygen 7.28	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	A
STORET #			Temp (C) 23.01		pH 8.39	Sample Depth 0.3	Sp. Conductance (umho/cm) 770	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 0.38	Comments DO% 84.6			

Relinquished By:	Date/Time	Shipping Method	Received By:	Date/Time	Relinquished By:	Date/Time	Received By:	Date/Time
P O'Connor	4/5/16 1400	Fed Ex	C	4/6/16 9:24				

Group: A	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	BOD-UNIN						
Group: A	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 3	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 3	Preservative:	ICE-FLTR	Enter Number of Bottles Sent to Lab	
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY						
	TURBIDITY						
	W-F						
	W-TSS						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	BOD-UNIN						
Group: B	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3						
	W-NO2NO3						

Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab
	W-S-A-TP				
	W-TKN				
	W-TOC				

Group: B	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: ICE-FLTR	Enter Number of Bottles Sent to Lab
	W-PO4-F				

Date of Request: 02-MAR-2016
 Created By: GRUENTZE_J On: 02-MAR-2016
 Modified By: WATTS_J On: 16-MAR-2016
 Customer: NE-DIST
 Project: SMP
 Division:
 District: Northeast District
 Sampling Event: UEC NORTH

Send Coolers To:

Phone: 904-256-1700
8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: J. Gruentzel

Program Module Number:
 Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 16-MAR-2016
 Biology Request Reviewed By: SWANSON_C On: 04-MAR-2016
 Sampling Kit Required: YES Ship on: 23-MAR-2016
 Sampling Kit Shipped: YES On: 21-MAR-2016
 Sampling Kit Packed By: KITCHEN_S
 Preservatives Needed: NO
 Date to Receive Samples: 04-APR-2016
 Received By:

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jann Gruentzel

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: NE ROC SMP

Bottle Group A (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
BOD-UNIN	Template: DEFAULT	(SM 5210 B) BOD, NOT nitrogen-inhibited
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, phaeophytin and ratio by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
BOD-UNIN	Template: DEFAULT	(SM 5210 B) BOD, NOT nitrogen-inhibited
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, phaeophytin and ratio by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Log-in Checklist

RQ- 2016-04-04-25

Shipping Method: Fedex

Date/Time of Receipt: 4/6/16 9:24

Cooler ID	Cooler Temperature*	No. Sample Containers in Cooler	Evidence Tape				Tracking # (fill out only if waybill copy is damaged)
			Present?		*Intact?		
			Yes	No	Yes	No	
Red	0.6	15		✓			8099 4719 3686

*If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged, identify the containers in the affected cooler(s) on back of this form.

****Note:** If "No" is checked in any of the fields below, fill out the back of this form with additional details (Field ID, Test IDs, etc.) and generate an NCR.

****Chain Of Custody/ Field Sheet(s) Included?** Yes ☒ No ☐

CONTAINER CHECK

****Evidence Tape on Bottles?** Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐

****Caps on tight?** Yes ☒ No ☐ ****Containers intact?** Yes ☒ No ☐

****Sufficient Sample Volume:** Yes ☐ No ☐

CHLORINE CHECK (Blue dot on container)

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-AHERB-AA (-AHB-AA-R)			W-PCL-SQ (-R)		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)			W-PESTNP-R		
W-ENDO-AA			W-PSCL-TQ		
W-GLYPH			W-PSNP-TQ		
W-NP-AA-SF			W-PST-CL-R		
W-PAH (-R)			W-TR-TQ		
W-PCB-R					

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples:** pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: CE

****W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?** Yes ☐ No ☐ NA ☒ Init: CE

Coolers Unpacked/Checked by: CE Date: 4/6/16 NCRs (Y/N)? N

Event ID: NE-DIST-2016-04-06-01 NCR #

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes ☐ No ☒

Date and Time Placed in Freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes ☐ No ☐

If no, were samples shipped on dry ice? Yes ☐ No ☐

FOR CLEAN LAB USE ONLY – Methyl Mercury Preservation Check:

Samples Preserved within 48 hours? Yes ☐ No ☐

Date and time samples preserved: _____

Additional Comments: