

UEC South

last revised Apr 7, 2016

Customer: NE-DIST

Requester: Jeremy M. Parrish

Field Report Prepared By:

Project ID: SMP

Collected By:

Sampling Agency:

Location	Field ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>10-18-2016</u> Time <u>0905</u>	<u>Eastern</u> Central	Composite end Date _____ Time _____	Bottle Group(s) (See pg 2)	
Field ID	G5NE0079 10182016			Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen <u>2.05</u> ☒ mg/L <u>23.7</u> ☒ % sat	Total Res. Chlorine (mg/L)	A	
STORE	Cracker Branch at CR 204	Storet ID		Temp (C) <u>22.5</u>	pH <u>6.93</u>	Sample Depth <u>0.3</u> ☐ ft ☒ m		Sp. Conductance (umho/cm) <u>257</u>
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) <u>0.12</u>	Comments			
Location	field ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>10-18-2016</u> Time <u>240955</u>	<u>Eastern</u> Central	Composite end Date _____ Time _____	Bottle Group(s)	
Field ID	G5NE0005 10182016			Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen <u>3.83</u> ☒ mg/L <u>45.8</u> ☒ % sat	Total Res. Chlorine (mg/L)	A	
STORET	Palm Coast Canal at Old Kings Rd.	storet ID		Temp (C) <u>24.6</u>	pH <u>7.41</u>	Sample Depth <u>0.3</u> ☐ ft ☒ m		Sp. Conductance (umho/cm) <u>293</u>
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) <u>0.14</u>	Comments			
Location	field ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>10-18-2016</u> Time <u>1020</u>	<u>Eastern</u> Central	Composite end Date _____ Time _____	Bottle Group(s)	
Field ID	G5NE0016 10182016			Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen <u>4.91</u> ☒ mg/L <u>71.5</u> ☒ % sat	Total Res. Chlorine (mg/L)	B	
STORET #	ICW at St. Joe Walkway, PC	storet ID		Temp (C) <u>26.3</u>	pH <u>7.62</u>	Sample Depth <u>0.3</u> ☐ ft ☒ m		Sp. Conductance (umho/cm) <u>44.563</u>
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) <u>28.76</u>	Comments			
Location	Field Blank		☐ Comp ☒ Grab	Collection (comp begin or grab) Date <u>10-18-2016</u> Time <u>1040</u>	<u>Eastern</u> Central	Composite end Date _____ Time _____	Bottle Group(s)	
Field ID				Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen ☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	C	
STORET #				Temp (C)	pH	Sample Depth ☐ ft ☐ m		Sp. Conductance (umho/cm)
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			

Relinquished By:

Date/Time

Shipping Method

Number of Coolers Shipped:

Received By:

Date/Time

A. Kalmbacher10-18-20161430Fed Ex1AK10-19-16/10:05

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	ICE-FLTR	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	ALKALINITY						
	TURBIDITY						
	W-F						
	W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	CHLSUITE-W						
Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-ICP						
	W-ICPMS						
Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						

Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-TKN					
	W-TOC					

Group: B	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: ICE-FLTR	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-PO4-F					

Group: C	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-ICP					
	W-ICPMS					

Group: C	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-NH3					
	W-NO2NO3					
	W-TKN					
	W-TOC					

Group: C	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: ICE-FLTR	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-PO4-F					

Date of Request: 09-SEP-2016
 Created By: PARRISH_J On: 09-SEP-2016
 Modified By: MATTHEWS_D On: 27-SEP-2016
 Customer: NE-DIST
 Project: SMP
 Division:
 District: Northeast District
 Sampling Event: UEC South

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way West

 Jacksonville, FL 32256-7577
 Attn: Jeremy Parrish

Send Final Report To:

8800 Baymeadows Way West

 Jacksonville, FL 32256-7577
 Attn: Jeremy Parrish

Program Module Number:
 Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 23-SEP-2016
 Biology Request Reviewed By: MATTHEWS_D On: 27-SEP-2016
 Sampling Kit Required: YES Ship on: 06-OCT-2016
 Sampling Kit Shipped: YES On: 10-OCT-2016
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 17-OCT-2016
 Received By: SHAIK_A On: 19-OCT-2016

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments:**Bottle Group A (Water) With 2 Samples:**

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, phaeophytin and ratio by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: ICE-FLTR
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, phaeophytin and ratio by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Chromium		
Iron		
Zinc		
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Cadmium		
Copper		
Lead		
Nickel		
Silver		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Chromium		
Iron		
Zinc		
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Cadmium		
Copper		
Lead		
Nickel		
Silver		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Log-in Checklist

RQ- 2016-10-17-07

Shipping Method: Fed

Date/Time of Receipt: 10-19-16-10:05

Cooler ID	Cooler Temperature*	No. Sample Containers in Cooler	Evidence Tape				Tracking # (fill out only if waybill copy is damaged)
			Present?		*Intact?		
			Yes	No	Yes	No	
Red	2.8°	16		☒			

*If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged, identify the containers in the affected cooler(s) on back of this form.

****Note:** If "No" is checked in any of the fields below, fill out the back of this form with additional details (Field ID, Test IDs, etc.) and generate an NCR.

**Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

CONTAINER CHECK

**Evidence Tape on Bottles? Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐

**Caps on tight? Yes ☒ No ☐ **Containers intact? Yes ☒ No ☐

**Sufficient Sample Volume: Yes ☒ No ☐

CHLORINE CHECK (Blue dot on container)

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-AHERB-AA (-AHB-AA-R)			W-PCL-SQ (-R)		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)			W-PESTNP-R		
W-ENDO-AA			W-PSCL-TQ		
W-GLYPH			W-PSNP-TQ		
W-NP-AA-SF			W-PST-CL-R		
W-PAH (-R)			W-TR-TQ		
W-PCB-R					

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: ABP

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☐ NA ☒ Init: ABP

Coolers Unpacked/Checked by: ABP Date: 10-19-16 NCRs (Y/N)? N

Event ID: UEC South
NE-DIST-2016-10-19-01 (SMP)
 Date Received: 19-OCT-2016 10:05
 NCR #

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes____ No____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes____ No____

If no, were samples shipped on dry ice? Yes____ No____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes____ No____

Date and time samples preserved: _____

Additional Comments: