

Log-in Checklist

RQ- 2017-11-20-08

Shipping Method: FEDEX

Date/Time of Receipt: 12/01/17 @ 10:25

Cooler ID	Cooler Temperature*	No. Sample Containers in Cooler	Evidence Tape				Tracking # (fill out only if waybill copy is damaged)
			Present?		*Intact?		
			Yes	No	Yes	No	
Red	1.7°C	19		✓			811977809059

*If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged, identify the containers in the affected cooler(s) on back of this form.

****Note:** If "No" is checked in any of the fields below, fill out the back of this form with additional details (Field ID, Test IDs, etc.) and generate an **NCR**.

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No ✓ If yes, is it intact? Yes No

**Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No

**Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK (Blue dot on container)

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-AHERB-AA (-AHB-AA-R)		✓	W-PCL-SQ (-R)		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)			W-PESTNP-R		
W-ENDO-AA			W-PSCL-TQ		
W-GLYPH			W-PSNP-TQ		
W-NP-AA-SF			W-PST-CL-R		
W-PAH (-R)			W-TR-TQ		
W-PCB-R			W-CT-CI-R		

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: jm

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA ✓ Init: jm

Coolers Unpacked/Checked by: Tyler R. Date: 12/01/17 NCRs (Y/N)?

Event ID: LSJR North NCR #

NE-DIST-2017-12-01-01 (SMP)

Date Received: 01-DEC-2017 10:25

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No ✓

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Additional Comments:

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: NE-DIST

Requester: Jeremy M. Parrish

Field Report Prepared By:

JParrish

Project ID: SMP


Collected By:

JParrish

Sampling Agency:

FREP NE

Location	Field ID:  G2NE0147 11302017	☐ Comp ☒ Grab		Collection (comp begin or grab) Date 11/30/17 Time 1045	Eastern Central	Composite end Date	Time	Bottle Group(s) (See pg 2)
Field ID	Dunn Creek @ Faye Rd.	STORET #	 20030140	Matrix (type, e.g., Salt, Fresh, etc) Salt	Diss. Oxygen 8.1	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	B
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Temp (C) 18.6	pH 7.15	Sample Depth 0.3	Sp. Conductance (umho/cm) 5071	
Location	Field ID:  G2NE012211202017	☐ Comp ☒ Grab		Collection (comp begin or grab) Date 11/30/17 Time 1130	Eastern Central	Composite end Date	Time	Bottle Group(s)
Field ID	Moncrief Creek near mouth	STORET #	 20030115	Matrix (type, e.g., Salt, Fresh, etc) Fresh	Diss. Oxygen 7.36	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	A
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Temp (C) 20.1	pH 7.2	Sample Depth 0.3	Sp. Conductance (umho/cm) 3844	
Location	Field ID:  G2NE0133 11320217	☐ Comp ☒ Grab		Collection (comp begin or grab) Date 11/30/17 Time 1210	Eastern Central	Composite end Date	Time	Bottle Group(s)
Field ID	Ribault R Lem Turner rd.	STORET #	 20030126	Matrix (type, e.g., Salt, Fresh, etc) Fresh	Diss. Oxygen 6.7	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	B
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Temp (C) 19.5	pH 7.14	Sample Depth 0.2	Sp. Conductance (umho/cm) 2173	
Location	Field ID:	☐ Comp ☐ Grab		Collection (comp begin or grab) Date	Eastern Central	Composite end Date	Time	Bottle Group(s)
Field ID				Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
STORET #				Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			

Relinquished By: 	Date/Time: 11/30/17 1400	Shipping Method: Fedex	Number of Coolers Shipped: 1	Received By: Tyler R.	Date/Time: 12/01/17 @ 10:25
---	--------------------------	------------------------	------------------------------	-----------------------	-----------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-F W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W					
Group: A	Bottle Type:	P-120ML-WC-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1 - ALS lab overturn
	NE-ALS-ENQ					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab	1 -
	W-ICP W-ICPMS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	1
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
	ALKALINITY TURBIDITY W-F W-TSS					
Group: B	Bottle Type:	BP-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
	CHLSUITE-W					
Group: B	Bottle Type:	P-120ML-WC-THI	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	2 - ALS overturn
	NE-ALS-ENQ					
Group: B	Bottle Type:	QPCR-P-250ML	# of Bottles: 4	Preservative: ICE	Enter Number of Bottles Sent to Lab	4
	PCR-FILTER					
Group: B	Bottle Type:	BG-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	2

Group: B	Bottle Type:	BG-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-AHERB-AA						
	W-SUC-AA-R						
	W-UHERB-AA						
Group: B	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: B	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-PO4-F						
Group: C	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	ALKALINITY						
	TURBIDITY						
	W-F						
	W-TSS						
Group: C	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	CHLSUITE-W						
Group: C	Bottle Type:	P-120ML-WC-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	
	NE-ALS-ENQ						
Group: C	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: C	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	
	W-PO4-F						

Date of Request: 04-OCT-2017
 Created By: PARRISH_J On: 04-OCT-2017
 Modified By: SWANSON_C On: 03-NOV-2017
 Customer: NE-DIST
 Project: SMP
 Division:
 District: Northeast District
 Sampling Event: LSJR North

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way W

 Jacksonville, FL 32256-7577
 Attn: Jeremy Parrish

Send Final Report To:

8800 Baymeadows Way West

 Jacksonville, FL 32256-7577
 Attn: Jeremy Parrish

Program Module Number:
 Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 02-NOV-2017
 Biology Request Reviewed By: SWANSON_C On: 03-NOV-2017
 Sampling Kit Required: YES Ship on: 06-NOV-2017
 Sampling Kit Shipped: YES On: 06-NOV-2017
 Sampling Kit Packed By: GREENWOO_J
 Preservatives Needed: NO
 Date to Receive Samples: 20-NOV-2017
 Received By: REYNOLDS_T On: 21-NOV-2017

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Marine Kit With Metals, with Entero
 Group B: Marine Kit, No Metals, with Entero, Markers and Tracers
 Group C: Marine Kit, No Metals, with Entero

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Chromium		
Iron		
Zinc		
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Cadmium		
Copper		
Lead		
Nickel		
Silver		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 2 Samples:

Bottle Type: QPCR-P-250ML	Number of Bottles: 4	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: BG-1L	Number of Bottles: 2	Preserved With: ICE
W-AHERB-AA	Template: DEFAULT	(USGS O-2060-01) Chlorinated (phenoxy acid) herbicides in water matrices by HPLC/MS/MS
W-SUC-AA-R	Template: DEFAULT	(EPA 8321B) Analysis of sucralose in water matrices by HPLC/MS/MS
W-UHERB-AA	Template: DEFAULT	(USGS O-2060-01) Urea herbicides and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Group C (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.