

Customer: CEN-DIST

Requester: Michael Linger

Field Report Prepared By:

Project ID: SMP

Collected By:

Sampling Agency:

Location	Strickland Bay @ 875m East (Downstream) of RR Crossing		G5CE0074 Field ID STORET		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/12/17 Time 11:50		Eastern Central		Composite end Date Time		Bottle Group(s) (See pg 2)	
Field ID					Matrix (type, e.g., Salt, Fresh, etc) Salt		Diss. Oxygen 6.9		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		A	
STORET #	RQ-2017-04-03-64 Date: 04/12/17				Temp (C) 23.8		pH 7.9		Sample Depth 0.3		☐ ft ☒ m		Sp. Conductance (umho/cm) 55,196	
Latitude	☐ dd ☐ dms				☐ dd ☐ dms		Salinity (ppt)		Comments					
Location	Strickland Bay @ 100m SW of US1 Bridge		G5CE0090 Field ID STORET		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/12/17 Time 12:06		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID					Matrix (type, e.g., Salt, Fresh, etc) Salt		Diss. Oxygen 6.4		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		D	
STORET #	RQ-2017-04-03-64 Date: 04/12/17				Temp (C) 23.7		pH 7.9		Sample Depth 0.3		☐ ft ☒ m		Sp. Conductance (umho/cm) 55,220	
Latitude	☐ dd ☐ dms				☐ dd ☐ dms		Salinity (ppt)		Comments					
Location	Rose Bay @ 125m NE of Boat Ramp		G5CE0073 Field ID STORET		☐ Comp ☒ Grab		Collection (comp begin or grab) Date 4/12/17 Time 12:39		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID					Matrix (type, e.g., Salt, Fresh, etc) Salt		Diss. Oxygen 6.7		☒ mg/L ☐ % sat		Total Res. Chlorine (mg/L)		C	
STORET #	RQ-2017-04-03-64 Date: 04/12/17				Temp (C) 24.15		pH 7.8		Sample Depth 0.3		☐ ft ☒ m		Sp. Conductance (umho/cm) 54,780	
Latitude	☐ dd ☐ dms				☐ dd ☐ dms		Salinity (ppt)		Comments					
Location					☐ Comp ☐ Grab		Collection (comp begin or grab) Date Time		Eastern Central		Composite end Date Time		Bottle Group(s)	
Field ID					Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen		☐ mg/L ☐ % sat		Total Res. Chlorine (mg/L)			
STORET #					Temp (C)		pH		Sample Depth		☐ ft ☐ m		Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms		Longitude		☐ dd ☐ dms		Salinity (ppt)		Comments					

Relinquished By: MKL	Date/Time 4/12/17 17:00	Shipping Method FedEx	Number of Coolers Shipped: 2	Received By: P.A.	Date/Time 4/13/17 10:40
-------------------------	----------------------------	--------------------------	---------------------------------	----------------------	----------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-F W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	1
	W-ICP W-ICPMS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	ICE-FLTR	Enter Number of Bottles Sent to Lab	1
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	ALKALINITY TURBIDITY W-F W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	CHLSUITE-W						
Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	0
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: B	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	ICE-FLTR	Enter Number of Bottles Sent to Lab	6
	W-PO4-F						

Group: C	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-F W-TSS						
Group: C	Bottle Type:	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	CD-FLR-ENQ						
Group: C	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						
Group: C	Bottle Type:	QPCR-P-250ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	PCR-FILTER						
Group: C	Bottle Type:	BG-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	W-AHERB-AA W-SUC-AA-R W-UHERB-AA						
Group: C	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: C	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	ICE-FLTR	Enter Number of Bottles Sent to Lab	1
	W-PO4-F						
Group: D	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	ALKALINITY TURBIDITY W-F W-TSS						
Group: D	Bottle Type:	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	CD-FLR-ENQ						
Group: D	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
	CHLSUITE-W						

Group: D	Bottle Type: QPCR-P-250ML PCR-FILTER	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>2</u>
Group: D	Bottle Type: BG-1L W-AHERB-AA W-SUC-AA-R W-UHERB-AA	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: D	Bottle Type: P-500ML W-ICP W-ICPMS	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab <u>1</u>
Group: D	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>1</u>
Group: D	Bottle Type: P-125ML W-PO4-F	# of Bottles: 1	Preservative: ICE-FLTR	Enter Number of Bottles Sent to Lab <u>1</u>
Group: E	Bottle Type: P-250ML-WI-THI CD-FLR-ENQ	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>2</u>

Date of Request: 16-MAR-2017
 Created By: LINGER_M On: 16-MAR-2017
 Modified By: MATTHEWS_D On: 17-MAR-2017
 Customer: CEN-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Central District
 Sampling Event: Rose / Stricklandx2 / Spruce / UnBranch 2642

Send Coolers To:

Phone: 407-897-4180
 FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Mike Linger

Program Module Number: 1306
 Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 16-MAR-2017
 Biology Request Reviewed By: MATTHEWS_D On: 17-MAR-2017
 Sampling Kit Required: YES Ship on: 28-MAR-2017
 Sampling Kit Shipped: YES On: 31-MAR-2017
 Sampling Kit Packed By: KITCHEN_S
 Preservatives Needed: NO
 Date to Receive Samples: 03-APR-2017
 Received By:

Send Final Report To:

FL Dept. of Environmental Protection
 3319 Maguire Blvd., Suite 232
 Orlando, FL 32803-3767
 Attn: Mike Linger

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: A: Strickland
 B:UnBranch 2642
 C: Rose
 D: Strickland #2 (B,T,M)
 E: Spruce

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, phaeophytin and ratio by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Chromium		
Iron		
Zinc		
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Cadmium		
Copper		
Lead		
Nickel		
Silver		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, phaeophytin and ratio by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type:	Number of Bottles: 1	Preserved With: ICE
CD-FLR-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method by Flowers Overflow Laboratory for Central District
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, phaeophytin and ratio by spectrophotometry
Bottle Type: QPCR-P-250ML	Number of Bottles: 2	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: BG-1L	Number of Bottles: 1	Preserved With: ICE
W-AHERB-AA	Template:	(USGS O-2060-01) Chlorinated (phenoxy acid) herbicides in water matrices by HPLC/MS/MS
W-SUC-AA-R	Template: DEFAULT	(EPA 8321B) Analysis of sucralose in water matrices by HPLC/MS/MS
W-UHERB-AA	Template: DEFAULT	(USGS O-2060-01) Urea herbicides and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type:	Number of Bottles: 1	Preserved With: ICE

Bottle Group D (Water) With 1 Samples:

Bottle Type:	Number of Bottles: 1	Preserved With: ICE
CD-FLR-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method by Flowers Overflow Laboratory for Central District
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, phaeophytin and ratio by spectrophotometry
Bottle Type: QPCR-P-250ML	Number of Bottles: 2	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: BG-1L	Number of Bottles: 1	Preserved With: ICE
W-AHERB-AA	Template:	(USGS O-2060-01) Chlorinated (phenoxy acid) herbicides in water matrices by HPLC/MS/MS
W-SUC-AA-R	Template: DEFAULT	(EPA 8321B) Analysis of sucralose in water matrices by HPLC/MS/MS
W-UHERB-AA	Template: DEFAULT	(USGS O-2060-01) Urea herbicides and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Chromium		
Iron		
Zinc		
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Cadmium		
Copper		
Lead		
Nickel		
Silver		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group E (Water) With 1 Samples:

Bottle Type:	Number of Bottles: 1	Preserved With: ICE
CD-FLR-ENQ	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method by Flowers Overflow Laboratory for Central District

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

Log-in Checklist

RQ- 2017-04-03-64

Shipping Method: Fed Ex

Date/Time of Receipt: 4/13/17 10:10

Cooler ID	Cooler Temperature*	No. Sample Containers in Cooler	Evidence Tape				Tracking # (fill out only if waybill copy is damaged)
			Present?		*Intact?		
			Yes	No	Yes	No	
RED	1.6°C	13		✓			8111 7111 8260
RED	1.2°C	7		✓			8111 7111 8250

*If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged, identify the containers in the affected cooler(s) on back of this form.

****Note:** If "No" is checked in any of the fields below, fill out the back of this form with additional details (Field ID, Test IDs, etc.) and generate an NCR.

****Chain of Custody/ Field Sheet(s) Included?** Yes ✓ No

CONTAINER CHECK

****Evidence Tape on Bottles?** Yes No ✓ If yes, is it intact? Yes No

****Caps on tight?** Yes ✓ No ****Containers intact?** Yes ✓ No

****Sufficient Sample Volume:** Yes ✓ No

CHLORINE CHECK (Blue dot on container)

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-AHERB-AA (-AHB-AA-R)		✓	W-PCL-SQ (-R)		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)			W-PESTNP-R		
W-ENDO-AA			W-PSCL-TQ		
W-GLYPH			W-PSNP-TQ		
W-NP-AA-SF			W-PST-CL-R		
W-PAH (-R)			W-TR-TQ		
W-PCB-R			W-CT-CI-R		

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

****Acid Preserved Samples:** pH ≤ 2.0? Yes ✓ No NA Init: JD

****W-1-4-DIOX (Green dot on container) preserved to pH < 4.0?** Yes No NA ✓ Init: JD

Coolers Unpacked/Checked by: JD Date: 4/13/17 NCRs (Y/N)?

Event ID: CEN-DST-2017-04-13-02 NCR #

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes ☐ No ☒

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes ☐ No ☐

If no, were samples shipped on dry ice? Yes ☐ No ☐

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes ☐ No ☐

Date and time samples preserved: _____

Additional Comments: