

Date of Request: 02-MAR-2017
 Created By: PASWATER_B On: 02-MAR-2017
 Modified By: WATTS_J On: 08-MAY-2017
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Sampling Event: SMP: Lee County Streams

Send Coolers To:

Phone: 239-332-6975 SC 748-6975
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Ben Paswater

Program Module Number:
 Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 10-MAR-2017
 Biology Request Reviewed By: MATTHEWS_D On: 14-MAR-2017
 Sampling Kit Required: YES Ship on: 16-MAR-2017
 Sampling Kit Shipped: YES On: 16-MAR-2017
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 27-MAR-2017
 Received By: SHAIK_A On: 29-MAR-2017

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Ben Paswater

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: 2 A kits, 2 B kits, 2 Entero, 3 EColi, 3 MT

Bottle Group A (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
TSS		
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template:	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll/Phaeophytin Ratio		
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		
Bottle Type:	Number of Bottles: 3	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method by Sanders Laboratories for South District
*Escherichia Coli-Quanti-Tray		
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4

Bottle Group A (Water) With 3 Samples:

Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: ICE-FLTR
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		
Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
TSS		
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template:	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll/Phaeophytin Ratio		
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		
Bottle Type:	Number of Bottles: 2	Preserved With: ICE
SD-SND-ENT	Template: DEFAULT	(Enterolert/QT) Enterococci by MPN method by Sanders Laboratories Overflow Laboratory for SD
ENTEROCOCCI-ENTEROLERT		
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		

Bottle Group C (Water) With 3 Samples:

Bottle Type: BG-1L	Number of Bottles: 3	Preserved With: ICE
W-AHERB-AA	Template: SFWMD	(USGS O-2060-01) Chlorinated (phenoxy acid) herbicides in water matrices by HPLC/MS/MS
2,4,5-T		
2,4-D		
Acifluorfen		
Bentazon		
Silvex		
W-SUC-AA-R	Template: DEFAULT	(EPA 8321B) Analysis of sucralose in water matrices by HPLC/MS/MS
*Sucralose		
W-UHERB-AA	Template: DEFAULT	(USGS O-2060-01) Urea herbicides and other chemicals in water matrices by HPLC/MS/MS

Bottle Group C (Water) With 3 Samples:

Bottle Type: BG-1L Number of Bottles: 3 Preserved With: ICE
 W-UHERB-AA Template: DEFAULT (USGS O-2060-01) Urea herbicides and other chemicals in water matrices by HPLC/MS/MS
 *Acetaminophen
 *Carbamazepine
 *Fluridone
 *Primidone
 Diuron
 Fenuron
 Imidacloprid
 Linuron

Bottle Type: BG-500ML Number of Bottles: 8 Preserved With: ICE
 W-PCL-SQ-R Template: DEFAULT (EPA 8270D) Organochlorine pesticides in water matrices by GC/MS-SIM
 Aldrin
 Alpha-BHC
 Alpha-Chlordane
 Beta-BHC
 Carbophenothion
 Chlorothalonil
 Cypermethrin
 DDD-p,p'
 DDE-p,p'
 DDT-p,p'
 Delta-BHC
 Dicofol
 Dieldrin
 Endosulfan I
 Endosulfan II
 Endosulfan Sulfate
 Endrin
 Endrin Aldehyde
 Endrin Ketone
 Gamma-BHC
 Gamma-Chlordane
 Heptachlor
 Heptachlor Epoxide
 Methoxychlor
 Mirex
 Permethrin
 Trifluralin

Bottle Type: BG-1L Number of Bottles: 8 Preserved With: ICE
 W-SPNP-TQ Template: DEFAULT (EPA 8270D) Organonitrogen and phosphorus pesticides (ultra trace level) in water matrices by GC/MS/MS
 Acetochlor
 Alachlor
 Ametryn
 Atrazine
 Atrazine Desethyl
 Azinphos Methyl
 Bromacil
 Butylate
 Chlorpyrifos Ethyl
 Chlorpyrifos Methyl
 Cyanazine
 Demeton
 Diazinon
 Disulfoton
 EPTC
 Ethion
 Ethoprop
 Fenamiphos
 Fipronil

Bottle Group C (Water) With 3 Samples:

Bottle Type: BG-1L Number of Bottles: 8 Preserved With: ICE
W-PSNP-TQ Template: DEFAULT (EPA 8270D) Organonitrogen and phosphorus pesticides (ultra trace level) in water matrices by GC/MS/MS

Fipronil Sulfide
Fipronil Sulfone
Fonofos
Hexazinone
Malathion
Metalaxyl
Metolachlor
Metribuzin
Mevinphos
Molinate
Norflurazon
Parathion Ethyl
Parathion Methyl
Pendimethalin
Phorate
Prometon
Prometryn
Simazine
Terbufos
Terbutylazine

Bottle Type: BG-1L Number of Bottles: 3 Preserved With: ICE
W-PYR-AA-R Template: DEFAULT (EPA 8321B) Pyraclostrobin in water matrices by HPLC/MS/MS
*Pyraclostrobin

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.