

Log-in Checklist

RQ- 2017-12-11-07

Shipping Method: FedEx

Date/Time of Receipt: 12/7/17 10:35

Cooler ID	Cooler Temperature*	No. Sample Containers in Cooler	Evidence Tape				Tracking # (fill out only if waybill copy is damaged)
			Present?		*Intact?		
			Yes	No	Yes	No	
RED	2.3°C	11		☒			

*If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged, identify the containers in the affected cooler(s) on back of this form.

****Note:** If "No" is checked in any of the fields below, fill out the back of this form with additional details (Field ID, Test IDs, etc.) and generate an NCR.

**Chain of Custody/ Field Sheet(s) Included? Yes ☒ No ☐

CONTAINER CHECK

**Evidence Tape on Bottles? Yes ☐ No ☒ If yes, is it intact? Yes ☐ No ☐

**Caps on tight? Yes ☒ No ☐ **Containers intact? Yes ☒ No ☐

**Sufficient Sample Volume: Yes ☒ No ☐

CHLORINE CHECK (Blue dot on container)

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX		☒	W-PC-AA-SF		
W-AHERB-AA (-AHB-AA-R)			W-PCL-SQ (-R)		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)			W-PESTNP-R		
W-ENDO-AA			W-PSCL-TQ		
W-GLYPH			W-PSNP-TQ		
W-NP-AA-SF			W-PST-CL-R		
W-PAH (-R)			W-TR-TQ		
W-PCB-R			W-CT-CI-R		

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ☒ No ☐ NA ☐ Init: 9.2

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes ☐ No ☒ NA ☒ Init: 9.2

Coolers Unpacked/Checked by: 9.2 Date: 12/7/17 NCRs (Y/N)? ☐

Event ID: WQAP-2017-1207-01 NCR # ☐

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No ✓

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ No _____

If no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Additional Comments:

Peace Streams

last revised Apr 7, 2016

Central Laboratory Submittal Form

Customer: WQAP

Requester: Benjamin Paswater

Field Report Prepared By: JOHN BARRINGTON

Project ID: SMP

Collected By: JOHN BARRINGTON, GARY SNOREK

Sampling Agency: FL DEP S ROE

Location	RQ-2017-12-11-07 12/6/2017 WBID 1995 Myrtle 1995 @ Pine Island St.	G3SD120617-2 Field ID STORET 25020641FTM	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 12/6/17 Time 0957	Eastern Central	Composite end Date Time	Bottle Group(s) (See pg 2)
Field ID			Matrix (type, e.g., Salt, Fresh, etc) FRESH	Diss. Oxygen 70.1	☐ mg/L ☒ % sat	Total Res. Chlorine (mg/L)	B, C
STORET #			Temp (C) 20.3	pH 7.2	Sample Depth 0.1	Sp. Conductance (umho/cm) 505	
Latitude	27.08419	Longitude	-81.76230	Salinity (ppt)	Comments		
Location	RQ-2017-12-11-07 12/6/2017 WBID 1997 Hawthorne Creek @ Reynolds St.	G3SD120617-6 Field ID STORET G3SD0011	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 12/6/17 Time 0928	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID			Matrix (type, e.g., Salt, Fresh, etc) FRESH	Diss. Oxygen 83.8	☐ mg/L ☒ % sat	Total Res. Chlorine (mg/L)	B, C 42
STORET #			Temp (C) 20.0	pH 6.8	Sample Depth 0.15	Sp. Conductance (umho/cm) 967	
Latitude	27.15788	Longitude	-81.86200	Salinity (ppt)	Comments		
Location			☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID			Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
STORET #			Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude		Longitude		Salinity (ppt)	Comments		
Location			☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time	Eastern Central	Composite end Date Time	Bottle Group(s)
Field ID			Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
STORET #			Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude		Longitude		Salinity (ppt)	Comments		

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By	Date/Time
JOHN BARRINGTON	1200 12/6/17	FEDEX	1	J.2	12/7/17 10:35

* Logged in for bottle group sent not recorded

Group: A	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: A	Bottle Type:	P-500ML	# of Bottles: 3	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 3	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>1</u> _____
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					
Group: B	Bottle Type:	BP-1L	# of Bottles: 3	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>1</u> _____
	CHLSUITE-W					
Group: B	Bottle Type:	P-500ML	# of Bottles: 3	Preservative:	HNO3	Enter Number of Bottles Sent to Lab <u>1</u> _____
	W-ICP					
	W-ICPMS					

Group: B	Bottle Type:	P-500ML	# of Bottles: 3	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: B	Bottle Type:	P-125ML	# of Bottles: 3	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	1
	W-PO4-F					
Group: C	Bottle Type:	QPCR-P-250ML	# of Bottles: 4	Preservative: ICE	Enter Number of Bottles Sent to Lab	4
	PCR-FILTER					
Group: C	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	0 (SANDERS)
	SD-SND-ECQ					
Group: C	Bottle Type:	BG-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
	W-AHERB-AA					
	W-SUC-AA-R					
	W-UHERB-AA					

Date of Request: 19-SEP-2017
 Created By: PASWATER_B On: 19-SEP-2017
 Modified By: WALTERS_J On: 17-NOV-2017
 Customer: WQAP
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: SROC
 Sampling Event: Peace Streams

Send Coolers To:

Phone: 239-344-5719
 2295 Victoria Ave.
 Suite 364
 Fort Myers, FL 33901
 Attn: Chase Conley

Send Final Report To:

2295 Victoria Ave.
 Suite 364
 Fort Myers, FL 33901
 Attn: Ben Paswater

Program Module Number:
 Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 13-NOV-2017
 Biology Request Reviewed By: WALTERS_J On: 17-NOV-2017
 Sampling Kit Required: YES Ship on: 27-NOV-2017
 Sampling Kit Shipped: YES On: 27-NOV-2017
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 11-DEC-2017
 Received By:

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Yucaa & 3 Alligators

Group A: Freshwater Kit, No Metals
 Group B: Freshwater Kit With Metals

Bottle Group A (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices

Bottle Group B (Water) With 3 Samples:

Bottle Type: P-1L	Number of Bottles: 3	Preserved With: ICE
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices
Bottle Type: BP-1L	Number of Bottles: 3	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Chromium		
Iron		
Magnesium		
Nickel		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Cadmium		
Copper		
Lead		
Silver		
Bottle Type: P-500ML	Number of Bottles: 3	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 3	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 2 Samples:

Bottle Type: QPCR-P-250ML	Number of Bottles: 4	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type:	Number of Bottles: 2	Preserved With: ICE
SD-SND-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Collert 18 Quanti-Tray method by Sanders Laboratories for South District
Bottle Type: BG-1L	Number of Bottles: 2	Preserved With: ICE
W-AHERB-AA	Template: DEFAULT	(USGS O-2060-01) Chlorinated (phenoxy acid) herbicides in water matrices by HPLC/MS/MS
W-SUC-AA-R	Template: DEFAULT	(EPA 8321B) Analysis of sucralose in water matrices by HPLC/MS/MS
W-UHERB-AA	Template: DEFAULT	(USGS O-2060-01) Urea herbicides and other chemicals in water matrices by HPLC/MS/MS

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

01000

FedEx
ExpressPackage
US AirbillFedEx
Tracking
Number

8119 7781 1986

1 From

Date

Sender's
Name

Phone

Company

Address

Dept./Floor/Suite/Room

City

State

ZIP

2 Your Internal Billing Reference**3 To**Recipient's
Name

Phone

Company

Address

Dept./Floor/Suite/Room

Address

Use this line for the HOLD location address or for continuation of your shipping address.

City

State

ZIP

Hold Weekday
FedEx location address
REQUIRED. NOT available for
FedEx First Overnight.Hold Saturday
FedEx location address
REQUIRED. Available ONLY for
FedEx Priority Overnight and
FedEx 2Day to select locations.

0127857428



8119 7781 1986

Form
ID No.

0215

Recipient's Copy

4 Express Package Service

* To most locations.

Packages up to 150 lbs.
For packages over 150 lbs., use the
FedEx Express Freight US Airbill.**Next Business Day**☐ FedEx First Overnight
Earliest next business morning delivery to select
locations. Friday shipments will be delivered on
Monday unless Saturday Delivery is selected.☒ FedEx Priority Overnight
Next business morning.* Friday shipments will be
delivered on Monday unless Saturday Delivery
is selected.☐ FedEx Standard Overnight
Next business afternoon.*
Saturday Delivery NOT available.**2 or 3 Business Days**☐ FedEx 2Day A.M.
Second business morning.*
Saturday Delivery NOT available.☐ FedEx 2Day
Second business afternoon.* Thursday shipments
will be delivered on Monday unless Saturday
Delivery is selected.☐ FedEx Express Saver
Third business day.*
Saturday Delivery NOT available.**5 Packaging**

* Declared value limit \$500.

☐ FedEx Envelope*☐ FedEx Pak*☐ FedEx
Box☐ FedEx
Tube☒ Other**6 Special Handling and Delivery Signature Options**

Fees may apply. See the FedEx Service Guide.

☐ Saturday Delivery

NOT available for FedEx Standard Overnight, FedEx 2Day A.M., or FedEx Express Saver.

☐ No Signature RequiredPackage may be left without
obtaining a signature for delivery.☐ Direct SignatureSomeone at recipient's address
may sign for delivery.☐ Indirect SignatureIf no one is available at recipient's
address, someone at a neighboring
address may sign for delivery. For
residential deliveries only.**Does this shipment contain dangerous goods?**

One box must be checked.

☒ No☐ Yes
As per attached
Shipper's Declaration.☐ Yes
Shipper's Declaration
not required.☐ Dry Ice
Dry ice, 9, UN 1845

x kg

☐ Cargo Aircraft Only

Restrictions apply for dangerous goods — see the current FedEx Service Guide.

7 Payment Bill to:

Enter FedEx Acct. No. or Credit Card No. below.

Obtain recip.
Acct. No.☐ Sender
Acct. No. in Section
1 will be billed.☒ Recipient☐ Third Party☐ Credit Card☐ Cash/Check

Total Packages

Total Weight

Credit Card Auth.

*Our liability is limited to US\$100 unless you declare a higher value. See the current FedEx Service Guide for details.

611

Rev. Date 5/15 • Part #153134 • ©1994–2015 FedEx • PRINTED IN U.S.A. SRM

fedex.com 1800.GoFedEx 1800.463.3339

fedex.com 1800.GoFedEx 1800.463.3339