

Chemical Analysis Report

WQAP-2017-10-11-04

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780

Event Description: **SMP 2017 kit A-b/t/m PCR-FILTER & PCR-HF183
(3603_Boggy, 3389_Sugar, 3480_Bethel)**
Request ID: **RQ-2017-09-25-25**
Customer: **WQAP**
Project ID: **SMP**

Send Reports to:
FL Dept. of Environmental Protection
2600 Blair Stone Rd
MS #3560
Tallahassee, FL 32399-2400
Attn: Michael Eckles

For additional information please contact
Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Thekkekalathil Chandrasekhar, Chemist Administrator

Date Certified: 06-NOV-2017 16:42



Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Bethel Creek @ Mill Creek

Collection Date/Time: 10/11/2017 13:10

Field ID: G1TLHR0062-2017-04

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
1936144	EPA 180.1 Rev. 2.0	Turbidity	2.8	A	NTU	P333196	
	EPA 300.0 Rev. 2.1	Chloride	5.0	A	mg Cl/L	P333258	
	SM 2120 B	Color (true)	710		PCU	P333201	
	SM 2320 B-97	Total Alkalinity	56		mg CaCO3/L	P333704	
	SM 2540 C-97	TDS	156		mg/L	P333564	
	SM 2540 D-97	TSS	2	U	mg/L	P333546	
	SM 4500 F-C-97	Fluoride	0.074	I	mg F/L	P333708	
1936145	EPA 350.1 Rev. 2.0	Ammonia-N	0.019		mg N/L	P333530	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	1.2		mg N/L	P334536	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.033		mg N/L	P333772	
	EPA 365.1 Rev. 2.0	Total-P	0.033		mg P/L	P333435	
	SM 5310 B-00	Organic Carbon	51		mg C/L	P333685	
1936146	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.014		mg P/L	P333314	
1936150	EPA 8321B	Sucralose**	0.010	U	ug/L	P333208	
	USGS O-2060-01	2,4-D	0.0020	U	ug/L	P333230	
		Diuron	8.0E-04	U	ug/L	P333230	
		Fenuron	0.0080	U	ug/L	P333230	
		Imidacloprid	8.0E-04	U	ug/L	P333230	
		Bentazon	8.0E-04	U	ug/L	P333230	
		Linuron	0.0040	U	ug/L	P333230	
		Acetaminophen**	0.0080	U	ug/L	P333230	
		MCP	0.0020	U	ug/L	P333230	
		Carbamazepine**	4.0E-04	U	ug/L	P333230	
		Triclopyr**	0.0040	U	ug/L	P333230	
		Primidone**	0.0040	U	ug/L	P333230	
		Fluridone**	4.0E-04	U	ug/L	P333230	
							MS

Ref. Method and Comment:

SM 2540 D-97: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

USGS O-2060-01: MS accuracy for 2,4-D and bentazon could not be assessed due to high concentration of parameter in the spiked sample.

USGS O-2060-01: MS accuracy for imidacloprid could not be assessed due to high concentration of parameter in the spiked sample.

Quality Assurance Report

Method Blank Results

Reference Method: EPA 180.1 Rev. 2.0

Batch ID: P333196

Component	Result	Code	Units
Turbidity	0.10	U	NTU

Reference Method: EPA 300.0 Rev. 2.1

Batch ID: P333258

Component	Result	Code	Units
Chloride	0.20	U	mg Cl/L

Quality Assurance Report Method Blank Results

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P333530

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P334536

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P333772

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P333435

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P333314

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8321B
Batch ID: P333208

Component	Result	Code	Units
Sucralose	0.010	U	ug/L

Reference Method: SM 2120 B
Batch ID: P333201

Component	Result	Code	Units
Color (true)	2.5	U	PCU

Reference Method: SM 2320 B-97
Batch ID: P333704

Component	Result	Code	Units
Total Alkalinity	0.65	U	mg CaCO3/L

Reference Method: SM 2540 C-97
Batch ID: P333564

Component	Result	Code	Units
TDS	15	U	mg/L

Quality Assurance Report Method Blank Results

Reference Method: SM 2540 D-97
 Batch ID: P333546

Component	Result	Code	Units
TSS	2	U	mg/L

Reference Method: SM 4500 F-C-97
 Batch ID: P333708

Component	Result	Code	Units
Fluoride	0.035	U	mg F/L

Reference Method: SM 5310 B-00
 Batch ID: P333685

Component	Result	Code	Units
Organic Carbon	0.50	U	mg C/L

Reference Method: USGS O-2060-01
 Batch ID: P333230

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
Acetaminophen	0.0080	U	ug/L
Bentazon	8.0E-04	U	ug/L
Carbamazepine	4.0E-04	U	ug/L
Diuron	8.0E-04	U	ug/L
Fenuron	0.0080	U	ug/L
Fluridone	4.0E-04	U	ug/L
Imidacloprid	8.0E-04	U	ug/L
Linuron	0.0040	U	ug/L
MCP	0.0020	U	ug/L
Primidone	0.0040	U	ug/L
Triclopyr	0.0040	U	ug/L

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 300.0 Rev. 2.1
 Batch ID: P333258

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Chloride	105		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
 Batch ID: P333530

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	98.5		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
 Batch ID: P334536

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	103		P	90 - 110

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P333772

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	104		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P333435

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	103		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P333314

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	104		P	90 - 110

Reference Method: EPA 8321B
Batch ID: P333208

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Sucralose	129		P	40 - 150

Reference Method: SM 2320 B-97
Batch ID: P333704

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total Alkalinity	102		P	95 - 108

Reference Method: SM 4500 F-C-97
Batch ID: P333708

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Fluoride	96.9		P	92 - 103

Reference Method: SM 5310 B-00
Batch ID: P333685

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Organic Carbon	96.9		P	85 - 115

Reference Method: USGS O-2060-01
Batch ID: P333230

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	77.9		P	40 - 150
Acetaminophen	118		P	30 - 150
Bentazon	84.3		P	30 - 150
Carbamazepine	130		P	40 - 150
Diuron	119		P	40 - 150
Fenuron	126		P	40 - 150
Fluridone	118		P	40 - 150
Imidacloprid	111		P	40 - 160
Linuron	120		P	40 - 150
MCPP	84.0		P	40 - 150

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: USGS O-2060-01
Batch ID: P333230

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Primidone	107		P	40 - 150
Triclopyr	82.8		P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P333258

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1935913	Chloride	108		P	90 - 110
1936144	Chloride	106		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P333530

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1935391	Ammonia-N	99.5	102	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P334536

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1940458	Kjeldahl Nitrogen	97.9	98.2	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P333772

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1936130	NO2NO3-N	106	104	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P333435

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1936176	Total-P	97.6	99.2	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P333314

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1936131	O-Phosphate-P	95.5	95.9	P/P	90 - 110

Reference Method: EPA 8321B
Batch ID: P333208

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1935714	Sucralose	77.1	77.4	P/P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: SM 4500 F-C-97
Batch ID: P333708

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1936172	Fluoride	97.0	98.3	P/P	91 - 105

Reference Method: SM 5310 B-00
Batch ID: P333685

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1936177	Organic Carbon	96.5	97.9	P/P	85 - 115

Reference Method: USGS O-2060-01
Batch ID: P333230

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1935715	Acetaminophen	99.5	87.9	P/P	30 - 150
1935715	Carbamazepine	108	101	P/P	40 - 150
1935715	Diuron	73.8	69.4	P/P	40 - 150
1935715	Fenuron	114	101	P/P	40 - 150
1935715	Fluridone	42.3	32.8	P/F	40 - 150
1935715	Linuron	90.5	85.1	P/P	40 - 150
1935715	MCP	58.0	55.4	P/P	40 - 150
1935715	Primidone	104	97.2	P/P	40 - 150
1935715	Triclopyr	59.6	58.3	P/P	40 - 150

Quality Assurance Report Precision

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P333196

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1936144	Turbidity	3.92	Sample	P	0 - 20

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P333258

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1936144	Chloride	0.247	Sample	P	0 - 20

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P333530

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1935391	Ammonia-N	1.37	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P334536

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
--------------------------	-----------	-----------	-------------------	-----------	----------------

Quality Assurance Report Precision

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P334536

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1940458	Kjeldahl Nitrogen	0.321	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P333772

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1936130	NO2NO3-N	1.91	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P333435

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1936176	Total-P	1.50	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P333314

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1936131	O-Phosphate-P	0.418	Spike	P	0 - 20

Reference Method: EPA 8321B
Batch ID: P333208

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1935714	Sucralose	0.400	Spike	P	0 - 30

Reference Method: SM 2120 B
Batch ID: P333201

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1935775	Color (true)	0.250	Sample	P	0 - 20

Reference Method: SM 2320 B-97
Batch ID: P333704

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1936172	Total Alkalinity	0.0763	Sample	P	0 - 4.8

Reference Method: SM 2540 C-97
Batch ID: P333564

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1935808	TDS	1.81	Sample	P	0 - 10

Quality Assurance Report Precision

Reference Method: SM 4500 F-C-97
Batch ID: P333708

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1936172	Fluoride	0.979	Spike	P	0 - 3.0

Reference Method: SM 5310 B-00
Batch ID: P333685

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1936177	Organic Carbon	0.841	Spike	P	0 - 20

Reference Method: USGS O-2060-01
Batch ID: P333230

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1935715	2,4-D	2.31	Spike	P	0 - 30
1935715	Acetaminophen	12.4	Spike	P	0 - 30
1935715	Bentazon	2.17	Spike	P	0 - 30
1935715	Carbamazepine	6.43	Spike	P	0 - 30
1935715	Diuron	4.82	Spike	P	0 - 30
1935715	Fenuron	11.9	Spike	P	0 - 30
1935715	Fluridone	10.0	Spike	P	0 - 30
1935715	Imidacloprid	3.52	Spike	P	0 - 30
1935715	Linuron	6.19	Spike	P	0 - 30
1935715	MCPP	4.01	Spike	P	0 - 30
1935715	Primidone	6.99	Spike	P	0 - 30
1935715	Triclopyr	2.20	Spike	P	0 - 30

* Sample, spike and/or laboratory control sample precision (LCS) is reported.
Replicate spike precision may be reported when sample results are below quantifiable levels.

Quality Assurance Report Surrogates

Lab Sample ID: 1936150
Field Sample ID: G1TLHR0062-2017-04

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	Acetaminophen-d4	120	P	30 - 160
EPA 8321B	Carbamazepine-d10	127	P	30 - 160
EPA 8321B	Diuron-d6	91.6	P	30 - 160
EPA 8321B	Primidone-d5	117	P	30 - 160
EPA 8321B	Sucralose-d6	78.6	P	40 - 160
USGS O-2060-01	2,4-D-d3	99.1	P	40 - 160
USGS O-2060-01	Acetaminophen-d4	120	P	30 - 160
USGS O-2060-01	Carbamazepine-d10	127	P	30 - 160
USGS O-2060-01	Diuron-d6	91.6	P	30 - 160
USGS O-2060-01	Primidone-d5	117	P	30 - 160
USGS O-2060-01	Sucralose-d6	78.6	P	40 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A79473

Included Lab Sample IDs: 1936144

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Chloride	108	107	P/P	90 - 110

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A79495

Included Lab Sample IDs: 1936144

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Turbidity	100	100	P/P	95 - 105

Reference Method: SM 2120 B

Run ID: A79497

Included Lab Sample IDs: 1936144

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Color (true)	103	104	P/P	85 - 115

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A79529

Included Lab Sample IDs: 1936146

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	99.7	99.0	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A79594

Included Lab Sample IDs: 1936150

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Sucralose	107	104	P/P	60 - 150

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A79623

Included Lab Sample IDs: 1936145

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	103	103	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A79637

Included Lab Sample IDs: 1936145

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	100	102	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A79651

Included Lab Sample IDs: 1936145

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	101	100	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: SM 5310 B-00
 Run ID: A79660
 Included Lab Sample IDs: 1936145

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Organic Carbon	96.0	96.8	P/P	90 - 110

Reference Method: USGS O-2060-01
 Run ID: A79661
 Included Lab Sample IDs: 1936150

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2,4-D	110	97.6	P/P	50 - 150
Acetaminophen	109	117	P/P	60 - 150
Bentazon	122	125	P/P	50 - 150
Carbamazepine	109	110	P/P	60 - 150
Diuron	102	101	P/P	60 - 150
Fenuron	106	108	P/P	60 - 150
Fluridone	112	115	P/P	60 - 160
Imidacloprid	99.6	106	P/P	60 - 150
Linuron	108	105	P/P	60 - 150
MCPP	104	96.2	P/P	50 - 150
Primidone	91.7	100	P/P	60 - 150
Triclopyr	110	95.2	P/P	50 - 150

Reference Method: SM 2320 B-97
 Run ID: A79666
 Included Lab Sample IDs: 1936144

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total Alkalinity	99.9	102	P/P	90 - 110

Reference Method: SM 4500 F-C-97
 Run ID: A79666
 Included Lab Sample IDs: 1936144

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Fluoride	99.0	110	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
 Run ID: A80046
 Included Lab Sample IDs: 1936145

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	99.4	97.0	P/P	90 - 110

* Pass/Fail determinations are made for each bracketing calibration verification check.
 Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.
 Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery	Precision	MS
				LCS SMP	

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		LCS	Precision	MS
						SMP	
EPA 180.1 Rev. 2.0	Turbidity					3.92	
EPA 300.0 Rev. 2.1	Chloride	105	106	108		0.247	
EPA 350.1 Rev. 2.0	Ammonia-N	98.5	99.5	102			1.37
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	103	97.9	98.2			0.321
EPA 353.2 Rev. 2.0	NO ₂ NO ₃ -N	104	106	104			1.91
EPA 365.1 Rev. 2.0	Total-P	103	97.6	99.2			1.50
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	104	95.5	95.9			0.418
EPA 8321B	Sucralose	129	77.1	77.4			0.400
SM 2120 B	Color (true)					0.250	
SM 2320 B-97	Total Alkalinity	102				0.0763	
SM 2540 C-97	TDS					1.81	
SM 4500 F-C-97	Fluoride	96.9	97.0	98.3			0.979
SM 5310 B-00	Organic Carbon	96.9	96.5	97.9			0.841
USGS O-2060-01	2,4-D	77.9					2.31
	Acetaminophen	118	99.5	87.9			12.4
	Bentazon	84.3					2.17
	Carbamazepine	130	108	101			6.43
	Diuron	119	73.8	69.4			4.82
	Fenuron	126	114	101			11.9
	Fluridone	118	42.3	32.8			10.0
	Imidacloprid	111					3.52
	Linuron	120	90.5	85.1			6.19
	MCP	84.0	58.0	55.4			4.01
	Primidone	107	104	97.2			6.99
	Triclopyr	82.8	59.6	58.3			2.20

Reference Method Descriptions

Method / DoH Cert #	Description	Associated Samples
EPA 180.1 Rev. 2.0 / E31780	Turbidity in aqueous matrices	1936144
EPA 300.0 Rev. 2.1 / E31780	Chloride in aqueous matrices	1936144
EPA 350.1 Rev. 2.0 / E31780	Ammonia in aqueous matrices as mg N/L	1936145
EPA 351.2 Rev. 2.0 / E31780	Total Kjeldahl Nitrogen in aqueous matrices	1936145
EPA 353.2 Rev. 2.0 / E31780	Nitrite/Nitrate in aqueous matrices as mg N/L	1936145
EPA 365.1 Rev. 2.0 / E31780	Total Phosphorus in aqueous matrices as mg P/L	1936145
EPA 365.1 Rev. 2.0 dissolved / E31780	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	1936146
EPA 8321B / E31780	Analysis of sucralose in water matrices by HPLC/MS/MS	1936150
SM 2120 B / E31780	True Color measured at 450 nm	1936144
SM 2320 B-97 / E31780	Alkalinity in aqueous matrices as mg CaCO ₃ /L	1936144
SM 2540 C-97 / E31780	Total Dissolved Solids in aqueous matrices	1936144
SM 2540 D-97 / E31780	Total Suspended Solids in aqueous matrices	1936144
SM 4500 F-C-97 / E31780	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	1936144
SM 5310 B-00 / E31780	Nonpurgeable Organic Carbon in aqueous matrices	1936145
USGS O-2060-01 / E31780	Chlorinated (phenoxy acid) herbicides in water matrices by HPLC/MS/MS	1936150
USGS O-2060-01 / E31780	Urea herbicides and other chemicals in water matrices by HPLC/MS/MS	1936150

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 180.1 Rev. 2.0	10/11/2017			10/11/2017 16:38	DeAsia Armster	1936144
EPA 300.0 Rev. 2.1	10/11/2017			10/12/2017	Julia Storbeck	1936144
EPA 350.1 Rev. 2.0	10/11/2017			10/17/2017	Sofia Elnemr	1936145
EPA 351.2 Rev. 2.0	10/11/2017	11/02/2017	Adrian Shelby	11/03/2017	Joseph Suarez	1936145
EPA 353.2 Rev. 2.0	10/11/2017			10/18/2017	Beverly Y. Sanders	1936145
EPA 365.1 Rev. 2.0	10/11/2017	10/16/2017	Sima Feizi	10/18/2017	Lipi Saha	1936145
EPA 365.1 Rev. 2.0 dissolved	10/11/2017			10/12/2017 15:58	Megan Treadwell	1936146
EPA 8321B	10/11/2017	10/12/2017	Juyoung Kim	10/15/2017	Juyoung Kim	1936150
SM 2120 B	10/11/2017			10/11/2017 17:00	Julia Storbeck	1936144
SM 2320 B-97	10/11/2017			10/19/2017	Dale L. Simmons	1936144
SM 2540 C-97	10/11/2017			10/13/2017	DeAsia Armster	1936144
SM 2540 D-97	10/11/2017			10/13/2017	DeAsia Armster	1936144
SM 4500 F-C-97	10/11/2017			10/19/2017	Dale L. Simmons	1936144
SM 5310 B-00	10/11/2017			10/18/2017	Ping Hua	1936145
USGS O-2060-01	10/11/2017	10/16/2017	Hoor Shaik	10/19/2017	Julie Michelle Frank	1936150