

Chemical Analysis Report

CEN-DIST-2018-08-28-01

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780

Event Description: **Salt X2 / Sweet / Crane Strand / CSD**

Request ID: **RQ-2018-08-27-28**

Customer: **CEN-DIST**

Project ID: **SMP**

Send Reports to:


FL Dept. of Environmental Protection
FL Dept. of Environmental Protection
3319 Maguire Blvd., Suite 232
Orlando, FL 32803-3767
Attn: Mike Linger

For additional information please contact

Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Dr. rer. nat. Bettina Steinbock, Environmental Administrator

Date Certified: 14-SEP-2018 17:19



Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Metals, Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: Crane Strand Drain @ 100m US of University Blvd (3014)

Collection Date/Time: 08/27/2018 09:26

Field ID: G2CE0077

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2020366	EPA 180.1 Rev. 2.0	Turbidity	3.7		NTU	P350939	
	EPA 300.0 Rev. 2.1	Chloride	21		mg Cl/L	P350987	
		Sulfate	11		mg SO4/L	P350990	
	SM 2120 B	Color (true)	52		PCU	P350849	
	SM 2320 B-97	Total Alkalinity	74		mg CaCO3/L	P351143	
	SM 2540 C-97	TDS	152		mg/L	P351238	
	SM 2540 D-97	TSS	10	I	mg/L	P351069	
	SM 4500 F-C-97	Fluoride	0.12		mg F/L	P351052	
2020368	EPA 350.1 Rev. 2.0	Ammonia-N	0.11		mg N/L	P350917	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.80		mg N/L	P350892	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.29		mg N/L	P351125	
	EPA 365.1 Rev. 2.0	Total-P	0.13		mg P/L	P350954	
	SM 5310 B-00	Organic Carbon	9.9		mg C/L	P351336	
2020370	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.062		mg P/L	P350831	
2020391	EPA 8321B	2,4-D	0.036		ug/L	P350709	MS
		Bentazon	0.031		ug/L	P350709	
		MCP	0.011		ug/L	P350709	MS
		Triclopyr**	0.0040	U	ug/L	P350709	MS
		Imidacloprid	0.063		ug/L	P350709	
		Diuron	0.0089		ug/L	P350709	
		Pyraclostrobin**	0.0020	U	ug/L	P350709	
		Primidone**	0.0040	U	ug/L	P350709	
		Linuron	0.0040	U	ug/L	P350709	
		Acetaminophen**	0.0080	U	ug/L	P350709	
		Fenuron	0.016	U	ug/L	P350709	
		Imazapyr**	0.053		ug/L	P350709	
		Carbamazepine**	8.0E-04	U	ug/L	P350709	
		Fluridone**	0.044		ug/L	P350709	
		Hydrocodone**	8.0E-04	U	ug/L	P350709	
		Naproxen**	0.0080	U	ug/L	P350709	
		Ibuprofen**	0.020	U	ug/L	P350709	
		Sucralose**	0.44		ug/L	P350691	
		Acesulfame K**	0.10	U	ug/L	P350691	
2020397	EPA 200.7 Rev. 4.4	Calcium	34.3		mg/L	P350867	
		Iron	480		ug/L	P350867	
		Magnesium	2.77		mg/L	P350867	
		Potassium	2.0		mg/L	P350867	
		Sodium	11.2		mg/L	P350867	
		Zinc	11	I	ug/L	P350867	
	EPA 200.8 Rev. 5.4	Arsenic	0.93		ug/L	P350867	
		Cadmium	0.020	U	ug/L	P350867	
		Chromium	0.97	I	ug/L	P350867	

Field ID: G2CE0077

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2020397	EPA 200.8 Rev. 5.4	Copper	3.22		ug/L	P350867	
		Lead	0.95		ug/L	P350867	
		Nickel	0.48	I	ug/L	P350867	
		Silver	0.010	U	ug/L	P350867	

Ref. Method and Comment:
SM 2540 D-97: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

Sample Location: Crane Strand Drain @ 250m North of University Blvd (3014) **Collection Date/Time: 08/27/2018 09:43**

Field ID: G2CE0157

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2020367	EPA 180.1 Rev. 2.0	Turbidity	4.6		NTU	P350939	
	EPA 300.0 Rev. 2.1	Chloride	21		mg Cl/L	P350987	
		Sulfate	11		mg SO4/L	P350990	
	SM 2120 B	Color (true)	53	A	PCU	P350851	
	SM 2320 B-97	Total Alkalinity	74		mg CaCO3/L	P351143	
	SM 2540 C-97	TDS	160	A	mg/L	P351238	
	SM 2540 D-97	TSS	9	IA	mg/L	P351069	
	SM 4500 F-C-97	Fluoride	0.12		mg F/L	P351052	
	EPA 350.1 Rev. 2.0	Ammonia-N	0.11		mg N/L	P350917	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.84		mg N/L	P350892	
2020369	EPA 353.2 Rev. 2.0	NO2NO3-N	0.29		mg N/L	P351126	
	EPA 365.1 Rev. 2.0	Total-P	0.11		mg P/L	P350955	
	SM 5310 B-00	Organic Carbon	10		mg C/L	P351336	
	EPA 365.1 Rev. 2.0	O-Phosphate-P	0.062		mg P/L	P350831	
	SM 5310 B-00	Organic Carbon	10		mg C/L	P351336	
2020371	EPA 365.1 Rev. 2.0	O-Phosphate-P	0.062		mg P/L	P350831	
2020392	EPA 8321B	2,4-D	0.034		ug/L	P350709	MS
		Bentazon	0.028		ug/L	P350709	
		MCP	0.0093		ug/L	P350709	MS
		Triclopyr**	0.0040	U	ug/L	P350709	MS
		Imidacloprid	0.051		ug/L	P350709	
		Diuron	0.0086		ug/L	P350709	
		Pyraclostrobin**	0.0020	U	ug/L	P350709	
		Primidone**	0.0040	U	ug/L	P350709	
		Linuron	0.0040	U	ug/L	P350709	
		Acetaminophen**	0.0080	U	ug/L	P350709	
		Fenuron	0.016	U	ug/L	P350709	
		Imazapyr**	0.057		ug/L	P350709	
		Carbamazepine**	8.0E-04	U	ug/L	P350709	
		Fluridone**	0.043		ug/L	P350709	
		Hydrocodone**	8.0E-04	U	ug/L	P350709	
		Naproxen**	0.0080	U	ug/L	P350709	
		Ibuprofen**	0.020	U	ug/L	P350709	
		Sucralose**	0.51		ug/L	P350691	
		Acesulfame K**	0.10	U	ug/L	P350691	
2020398	EPA 200.7 Rev. 4.4	Calcium	34.0		mg/L	P350867	
		Iron	440		ug/L	P350867	
		Magnesium	2.73		mg/L	P350867	
		Potassium	2.0		mg/L	P350867	
		Sodium	11.3		mg/L	P350867	
		Zinc	11	I	ug/L	P350867	
		Arsenic	0.96		ug/L	P350867	
		Cadmium	0.020	U	ug/L	P350867	
		Chromium	0.96	I	ug/L	P350867	
	EPA 200.8 Rev. 5.4	Arsenic	0.96		ug/L	P350867	

Field ID: G2CE0157

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2020398	EPA 200.8 Rev. 5.4	Copper	3.24		ug/L	P350867	
		Lead	0.88		ug/L	P350867	
		Nickel	0.46	I	ug/L	P350867	
		Silver	0.010	U	ug/L	P350867	

Ref. Method and Comment:
SM 2540 D-97: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

Sample Location: Salt Creek @ Packard Avenue (2990)

Collection Date/Time: 08/27/2018 11:10

Field ID: G2CE0088

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2020393	EPA 8321B	2,4-D	0.0024	I	ug/L	P350709	MS
		Bentazon	8.0E-04	U	ug/L	P350709	
		MCP	0.0020	U	ug/L	P350709	MS
		Triclopyr**	0.0040	U	ug/L	P350709	MS
		Imidacloprid	0.0025	I	ug/L	P350709	
		Diuron	0.0020	U	ug/L	P350709	
		Pyraclostrobin**	0.0020	U	ug/L	P350709	
		Primidone**	0.0040	U	ug/L	P350709	
		Linuron	0.0040	U	ug/L	P350709	
		Acetaminophen**	0.0080	U	ug/L	P350709	
		Fenuron	0.016	U	ug/L	P350709	
		Imazapyr**	0.0078	I	ug/L	P350709	
		Carbamazepine**	8.0E-04	U	ug/L	P350709	
		Fluridone**	0.0018		ug/L	P350709	
		Hydrocodone**	8.0E-04	U	ug/L	P350709	
		Naproxen**	0.0080	U	ug/L	P350709	
		Ibuprofen**	0.020	U	ug/L	P350709	
		Sucralose**	0.17		ug/L	P350691	
		Acesulfame K**	0.10	U	ug/L	P350691	

Sample Location: Salt Creek @ Stone St (2990)

Collection Date/Time: 08/27/2018 11:19

Field ID: G2CE0143

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2020394	EPA 8321B	2,4-D	0.0020	U	ug/L	P350709	MS
		Bentazon	8.0E-04	U	ug/L	P350709	
		MCP	0.0020	U	ug/L	P350709	MS
		Triclopyr**	0.0040	U	ug/L	P350709	MS
		Imidacloprid	0.025		ug/L	P350709	
		Diuron	0.0020	U	ug/L	P350709	
		Pyraclostrobin**	0.0020	U	ug/L	P350709	
		Primidone**	0.0040	U	ug/L	P350709	
		Linuron	0.0040	U	ug/L	P350709	
		Acetaminophen**	0.0080	U	ug/L	P350709	
		Fenuron	0.016	U	ug/L	P350709	
		Imazapyr**	0.0040	U	ug/L	P350709	
		Carbamazepine**	8.0E-04	U	ug/L	P350709	
		Fluridone**	4.0E-04	U	ug/L	P350709	
		Hydrocodone**	8.0E-04	U	ug/L	P350709	
		Naproxen**	0.0080	U	ug/L	P350709	
		Ibuprofen**	0.020	U	ug/L	P350709	
		Sucralose**	0.098		ug/L	P350691	
		Acesulfame K**	0.10	U	ug/L	P350691	

Quality Assurance Report Method Blank Results

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P350939

Component	Result	Code	Units
Turbidity	0.10	U	NTU

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P350867

Component	Result	Code	Units
Calcium	0.075	U	mg/L
Iron	30	U	ug/L
Magnesium	0.040	U	mg/L
Potassium	0.30	U	mg/L
Sodium	0.50	U	mg/L
Zinc	5.0	U	ug/L

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P350867

Component	Result	Code	Units
Arsenic	0.050	U	ug/L
Cadmium	0.020	U	ug/L
Chromium	0.40	U	ug/L
Copper	0.20	U	ug/L
Lead	0.050	U	ug/L
Nickel	0.20	U	ug/L
Silver	0.010	U	ug/L

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P350987

Component	Result	Code	Units
Chloride	0.20	U	mg Cl/L

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P350990

Component	Result	Code	Units
Sulfate	0.20	U	mg SO4/L

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P350917

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P350892

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P351125

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P351126

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P350954

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P350955

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P350831

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8321B
Batch ID: P350691

Component	Result	Code	Units
Acesulfame K	0.10	U	ug/L
Sucralose	0.010	U	ug/L

Reference Method: EPA 8321B
Batch ID: P350709

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
Acetaminophen	0.0080	U	ug/L
Bentazon	8.0E-04	U	ug/L
Carbamazepine	8.0E-04	U	ug/L
Diuron	0.0020	U	ug/L
Fenuron	0.016	U	ug/L
Fluridone	4.0E-04	U	ug/L
Hydrocodone	8.0E-04	U	ug/L
Ibuprofen	0.020	U	ug/L
Imazapyr	0.0040	U	ug/L
Imidacloprid	0.0020	U	ug/L
Linuron	0.0040	U	ug/L
MCPP	0.0020	U	ug/L
Naproxen	0.0080	U	ug/L
Primidone	0.0040	U	ug/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8321B
Batch ID: P350709

Component	Result	Code	Units
Pyraclostrobin	0.0020	U	ug/L
Triclopyr	0.0040	U	ug/L

Reference Method: SM 2120 B
Batch ID: P350849

Component	Result	Code	Units
Color (true)	2.5	U	PCU

Reference Method: SM 2120 B
Batch ID: P350851

Component	Result	Code	Units
Color (true)	2.5	U	PCU

Reference Method: SM 2320 B-97
Batch ID: P351143

Component	Result	Code	Units
Total Alkalinity	0.65	U	mg CaCO3/L

Reference Method: SM 2540 C-97
Batch ID: P351238

Component	Result	Code	Units
TDS	15	U	mg/L

Reference Method: SM 2540 D-97
Batch ID: P351069

Component	Result	Code	Units
TSS	2	U	mg/L

Reference Method: SM 4500 F-C-97
Batch ID: P351052

Component	Result	Code	Units
Fluoride	0.035	U	mg F/L

Reference Method: SM 5310 B-00
Batch ID: P351336

Component	Result	Code	Units
Organic Carbon	0.50	U	mg C/L

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P350867

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Calcium	108		P	85 - 115
Iron	106		P	85 - 115
Magnesium	108		P	85 - 115
Potassium	98.1		P	85 - 115
Sodium	102		P	85 - 115
Zinc	101		P	85 - 115

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P350867

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Arsenic	98.4		P	85 - 115
Cadmium	99.0		P	85 - 115
Chromium	96.6		P	85 - 115
Copper	94.8		P	85 - 115
Lead	97.8		P	85 - 115
Nickel	96.0		P	85 - 115
Silver	96.5		P	85 - 115

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P350987

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Chloride	102		P	90 - 110

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P350990

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Sulfate	101		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P350917

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	97.4		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P350892

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	101		P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P351125

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	99.5		P	90 - 110

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P351126

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	100		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P350954

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	97.2		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P350955

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	99.2		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P350831

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	98.7		P	90 - 110

Reference Method: EPA 8321B
Batch ID: P350691

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Acesulfame K	101		P	40 - 150
Sucralose	122		P	40 - 150

Reference Method: EPA 8321B
Batch ID: P350709

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	96.9		P	40 - 150
Acetaminophen	99.9		P	30 - 150
Bentazon	104		P	30 - 150
Carbamazepine	74.9		P	40 - 150
Diuron	69.4		P	40 - 150
Fenuron	82.4		P	40 - 150
Fluridone	78.6		P	40 - 150
Hydrocodone	87.9		P	40 - 150
Ibuprofen	107		P	40 - 150
Imazapyr	84.9		P	40 - 150
Imidacloprid	100		P	40 - 160
Linuron	64.0		P	40 - 150
MCPP	116		P	40 - 150
Naproxen	123		P	40 - 150
Primidone	101		P	40 - 150
Pyraclostrobin	71.7		P	40 - 150
Triclopyr	112		P	40 - 150

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: SM 2120 B
Batch ID: P350849

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Color (true)	96.6		P	85 - 115

Reference Method: SM 2120 B
Batch ID: P350851

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Color (true)	98.9		P	85 - 115

Reference Method: SM 2320 B-97
Batch ID: P351143

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total Alkalinity	103		P	98 - 107

Reference Method: SM 4500 F-C-97
Batch ID: P351052

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Fluoride	97.7		P	91 - 105

Reference Method: SM 5310 B-00
Batch ID: P351336

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Organic Carbon	97.1		P	85 - 115

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P350867

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2019961	Calcium	109	106	P/P	80 - 120
2019961	Iron	106	103	P/P	80 - 120
2019961	Magnesium	109	106	P/P	80 - 120
2019961	Potassium	104	101	P/P	80 - 120
2019961	Sodium	99.7	97.7	P/P	80 - 120
2019961	Zinc	102	102	P/P	80 - 120

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P350867

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2019961	Arsenic	102	102	P/P	80 - 120
2019961	Cadmium	102	102	P/P	80 - 120
2019961	Chromium	99.0	99.2	P/P	80 - 120
2019961	Copper	98.3	98.2	P/P	80 - 120
2019961	Lead	100	99.3	P/P	80 - 120
2019961	Nickel	98.6	98.2	P/P	80 - 120
2019961	Silver	98.3	97.8	P/P	80 - 120

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P350987

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020175	Chloride	97.6		P	90 - 110
2020467	Chloride	97.0		P	90 - 110

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P350990

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020175	Sulfate	98.1		P	90 - 110
2020467	Sulfate	101		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P350917

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020144	Ammonia-N	95.4	98.4	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P350892

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020337	Kjeldahl Nitrogen	103	104	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P351125

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020368	NO2NO3-N	100		P	90 - 110

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P351126

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020369	NO2NO3-N	99.5		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P350954

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020176	Total-P	96.2	95.0	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P350955

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020465	Total-P	94.2	92.8	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P350831

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020340	O-Phosphate-P	100	98.3	P/P	90 - 110

Reference Method: EPA 8321B
Batch ID: P350691

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2019942	Acesulfame K	89.7	94.1	P/P	40 - 150
2019942	Sucralose	117	118	P/P	40 - 150

Reference Method: EPA 8321B
Batch ID: P350709

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2019942	2,4-D	168	151	F/F	40 - 150
2019942	Acetaminophen	125	119	P/P	30 - 150
2019942	Bentazon	91.9	83.2	P/P	30 - 150
2019942	Carbamazepine	72.0	69.8	P/P	40 - 150
2019942	Diuron	61.8	61.6	P/P	40 - 150
2019942	Fenuron	57.7	55.8	P/P	40 - 150
2019942	Fluridone	80.4	67.4	P/P	40 - 150
2019942	Hydrocodone	82.9	79.2	P/P	40 - 150
2019942	Ibuprofen	95.9	90.0	P/P	40 - 150
2019942	Imazapyr	107	101	P/P	40 - 150
2019942	Imidacloprid	129	131	P/P	40 - 160
2019942	Linuron	67.0	59.5	P/P	40 - 150
2019942	MCP	177	155	F/F	40 - 150
2019942	Naproxen	133	127	P/P	40 - 150
2019942	Primidone	80.9	69.3	P/P	40 - 150
2019942	Pyraclostrobin	71.2	70.6	P/P	40 - 150
2019942	Triclopyr	215	217	F/F	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: SM 4500 F-C-97
Batch ID: P351052

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020073	Fluoride	98.1	98.3	P/P	91 - 105

Reference Method: SM 5310 B-00
Batch ID: P351336

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2020368	Organic Carbon	95.5	97.9	P/P	85 - 115

Quality Assurance Report Precision

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P350939

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020327	Turbidity	13.0	Sample	P	0 - 20

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P350867

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2019961	Calcium	2.19	Spike	P	0 - 20
2019961	Iron	2.64	Spike	P	0 - 20
2019961	Magnesium	2.60	Spike	P	0 - 20
2019961	Potassium	2.20	Spike	P	0 - 20
2019961	Sodium	1.57	Spike	P	0 - 20
2019961	Zinc	0.193	Spike	P	0 - 20

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P350867

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2019961	Arsenic	0.243	Spike	P	0 - 20
2019961	Cadmium	0.615	Spike	P	0 - 20
2019961	Chromium	0.173	Spike	P	0 - 20
2019961	Copper	0.178	Spike	P	0 - 20
2019961	Lead	1.05	Spike	P	0 - 20
2019961	Nickel	0.336	Spike	P	0 - 20
2019961	Silver	0.542	Spike	P	0 - 20

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P350987

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020175	Chloride	8.28	Sample	P	0 - 20

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P350990

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020175	Sulfate	9.98	Sample	P	0 - 20

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P350917

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020144	Ammonia-N	2.59	Spike	P	0 - 20

Quality Assurance Report Precision

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P350892

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020337	Kjeldahl Nitrogen	0.732	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P351125

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020368	NO2NO3-N	1.23	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P351126

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020369	NO2NO3-N	0.614	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P350954

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020176	Total-P	1.19	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P350955

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020465	Total-P	1.45	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P350831

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020340	O-Phosphate-P	1.81	Spike	P	0 - 20

Reference Method: EPA 8321B
Batch ID: P350691

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2019942	Acesulfame K	4.74	Spike	P	0 - 30
2019942	Sucralose	0.944	Spike	P	0 - 30

Reference Method: EPA 8321B
Batch ID: P350709

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2019942	2,4-D	10.6	Spike	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8321B
Batch ID: P350709

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2019942	Acetaminophen	4.47	Spike	P	0 - 30
2019942	Bentazon	9.34	Spike	P	0 - 30
2019942	Carbamazepine	3.17	Spike	P	0 - 30
2019942	Diuron	0.337	Spike	P	0 - 30
2019942	Fenuron	3.43	Spike	P	0 - 30
2019942	Fluridone	17.6	Spike	P	0 - 30
2019942	Hydrocodone	4.54	Spike	P	0 - 30
2019942	Ibuprofen	6.34	Spike	P	0 - 30
2019942	Imazapyr	5.58	Spike	P	0 - 30
2019942	Imidacloprid	1.86	Spike	P	0 - 30
2019942	Linuron	11.9	Spike	P	0 - 30
2019942	MCP	13.3	Spike	P	0 - 30
2019942	Naproxen	4.53	Spike	P	0 - 30
2019942	Primidone	15.5	Spike	P	0 - 30
2019942	Pyraclostrobin	0.934	Spike	P	0 - 30
2019942	Triclopyr	1.07	Spike	P	0 - 30

Reference Method: SM 2120 B
Batch ID: P350849

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020334	Color (true)	1.35	Sample	P	0 - 20

Reference Method: SM 2120 B
Batch ID: P350851

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020367	Color (true)	2.28	Sample	P	0 - 20

Reference Method: SM 2320 B-97
Batch ID: P351143

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020073	Total Alkalinity	0.102	Sample	P	0 - 1.6

Reference Method: SM 2540 C-97
Batch ID: P351238

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020367	TDS	6.90	Sample	P	0 - 10

Reference Method: SM 4500 F-C-97
Batch ID: P351052

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020073	Fluoride	0.477	Spike	P	0 - 3.5

Quality Assurance Report Precision

Reference Method: SM 5310 B-00
Batch ID: P351336

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2020368	Organic Carbon	1.64	Spike	P	0 - 20

* Sample, spike and/or laboratory control sample precision (LCS) is reported.
Replicate spike precision may be reported when sample results are below quantifiable levels.

Quality Assurance Report Surrogates

Lab Sample ID: 2020391
Field Sample ID: G2CE0077

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	118	P	30 - 160
EPA 8321B	Acetaminophen-d4	113	P	30 - 160
EPA 8321B	Carbamazepine-d10	83.1	P	30 - 160
EPA 8321B	Diuron-d6	81.2	P	30 - 160
EPA 8321B	Endothall-d6	136	P	40 - 160
EPA 8321B	Ibuprofen-d3	99.4	P	30 - 160
EPA 8321B	Primidone-d5	71.5	P	30 - 160
EPA 8321B	Sucralose-d6	130	P	40 - 160

Lab Sample ID: 2020392
Field Sample ID: G2CE0157

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	108	P	30 - 160
EPA 8321B	Acetaminophen-d4	106	P	30 - 160
EPA 8321B	Carbamazepine-d10	75.1	P	30 - 160
EPA 8321B	Diuron-d6	67.6	P	30 - 160
EPA 8321B	Endothall-d6	127	P	40 - 160
EPA 8321B	Ibuprofen-d3	92.4	P	30 - 160
EPA 8321B	Primidone-d5	75.1	P	30 - 160
EPA 8321B	Sucralose-d6	140	P	40 - 160

Lab Sample ID: 2020393
Field Sample ID: G2CE0088

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	146	P	30 - 160
EPA 8321B	Acetaminophen-d4	82.6	P	30 - 160
EPA 8321B	Carbamazepine-d10	57.8	P	30 - 160
EPA 8321B	Diuron-d6	49.7	P	30 - 160
EPA 8321B	Endothall-d6	135	P	40 - 160
EPA 8321B	Ibuprofen-d3	115	P	30 - 160
EPA 8321B	Primidone-d5	40.0	P	30 - 160
EPA 8321B	Sucralose-d6	136	P	40 - 160

Lab Sample ID: 2020394
Field Sample ID: G2CE0143

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	145	P	30 - 160
EPA 8321B	Acetaminophen-d4	79.1	P	30 - 160
EPA 8321B	Carbamazepine-d10	59.8	P	30 - 160
EPA 8321B	Diuron-d6	47.3	P	30 - 160
EPA 8321B	Endothall-d6	142	P	40 - 160
EPA 8321B	Ibuprofen-d3	94.9	P	30 - 160
EPA 8321B	Primidone-d5	41.2	P	30 - 160
EPA 8321B	Sucralose-d6	159	P	40 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A86148

Included Lab Sample IDs: 2020370, 2020371

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	101	100	P/P	90 - 110

Reference Method: SM 2120 B

Run ID: A86154

Included Lab Sample IDs: 2020366, 2020367

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Color (true)	97.4	97.2	P/P	90 - 115
Color (true)	98.6	99.2	P/P	90 - 115

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A86185

Included Lab Sample IDs: 2020368, 2020369

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	101	101	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A86190

Included Lab Sample IDs: 2020391, 2020392, 2020393, 2020394

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acesulfame K	131	87.9	P/P	60 - 160
Acesulfame K	87.9	85.8	P/P	60 - 160

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A86194

Included Lab Sample IDs: 2020366, 2020367

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Chloride	106	95.8	P/P	90 - 110
Sulfate	104	94.3	P/P	90 - 110

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A86200

Included Lab Sample IDs: 2020366, 2020367

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Turbidity	104	102	P/P	95 - 105

Reference Method: EPA 200.7 Rev. 4.4

Run ID: A86211

Included Lab Sample IDs: 2020397, 2020398

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Calcium	105	107	P/P	90 - 110
Iron	104	103	P/P	90 - 110
Magnesium	103	102	P/P	90 - 110
Potassium	97.8	96.7	P/P	90 - 110
Sodium	99.4	98.6	P/P	90 - 110
Zinc	103	103	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: EPA 8321B

Run ID: A86218

Included Lab Sample IDs: 2020391, 2020392, 2020393, 2020394

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Sucralose	120	135	P/P	60 - 160
Sucralose	93.4	85.6	P/P	60 - 160

Reference Method: EPA 8321B

Run ID: A86219

Included Lab Sample IDs: 2020391, 2020392, 2020393, 2020394

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2,4-D	96.9	87.1	P/P	50 - 150
Acetaminophen	106	109	P/P	60 - 160
Acetaminophen	109	106	P/P	60 - 160
Bentazon	103	94.6	P/P	50 - 160
Carbamazepine	109	102	P/P	60 - 160
Carbamazepine	99.0	109	P/P	60 - 160
Diuron	87.6	96.2	P/P	60 - 150
Diuron	96.2	104	P/P	60 - 150
Fenuron	93.0	97.8	P/P	60 - 150
Fenuron	97.8	107	P/P	60 - 150
Fluridone	83.3	91.9	P/P	60 - 160
Fluridone	91.9	83.4	P/P	60 - 160
Hydrocodone	105	97.5	P/P	60 - 150
Hydrocodone	98.0	105	P/P	60 - 150
Ibuprofen	126	134	P/P	50 - 160
Imazapyr	76.9	79.5	P/P	50 - 150
Imazapyr	79.5	90.1	P/P	50 - 150
Imidacloprid	85.2	94.8	P/P	60 - 150
Imidacloprid	88.3	85.2	P/P	60 - 150
Linuron	100	104	P/P	60 - 150
Linuron	104	106	P/P	60 - 150
MCPP	102	98.8	P/P	50 - 150
Naproxen	112	93.1	P/P	50 - 160
Primidone	99.5	99.6	P/P	60 - 150
Primidone	99.6	101	P/P	60 - 150
Pyraclostrobin	92.4	95.6	P/P	60 - 150
Pyraclostrobin	95.1	92.4	P/P	60 - 150
Triclopyr	109	97.9	P/P	50 - 160

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A86222

Included Lab Sample IDs: 2020368, 2020369

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	100	99.4	P/P	90 - 110
Total-P	99.4	102	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A86229

Included Lab Sample IDs: 2020368, 2020369

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	98.4	106	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A86251

Included Lab Sample IDs: 2020397, 2020398

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Arsenic	95.5	95.6	P/P	90 - 110
Cadmium	95.4	94.2	P/P	90 - 110
Chromium	93.8	95.6	P/P	90 - 110
Copper	93.4	93.1	P/P	90 - 110
Lead	102	100	P/P	90 - 110
Nickel	93.3	94.2	P/P	90 - 110
Silver	95.3	93.3	P/P	90 - 110

Reference Method: SM 4500 F-C-97

Run ID: A86252

Included Lab Sample IDs: 2020366, 2020367

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Fluoride	99.5	101	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A86298

Included Lab Sample IDs: 2020368, 2020369

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	102	102	P/P	90 - 110
NO2NO3-N	102	102	P/P	90 - 110

Reference Method: SM 2320 B-97

Run ID: A86303

Included Lab Sample IDs: 2020366, 2020367

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total Alkalinity	103	101	P/P	90 - 110

Reference Method: SM 5310 B-00

Run ID: A86377

Included Lab Sample IDs: 2020368, 2020369

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Organic Carbon	93.8	95.0	P/P	90 - 110
Organic Carbon	95.0	94.5	P/P	90 - 110

* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.
Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		LCS	Precision SMP	MS
EPA 180.1 Rev. 2.0	Turbidity					13.0	
EPA 200.7 Rev. 4.4	Calcium	108	109	106			2.19
	Iron	106	106	103			2.64
	Magnesium	108	109	106			2.60
	Potassium	98.1	104	101			2.20
	Sodium	102	99.7	97.7			1.57
	Zinc	101	102	102			0.193
EPA 200.8 Rev. 5.4	Arsenic	98.4	102	102			0.243
	Cadmium	99.0	102	102			0.615
	Chromium	96.6	99.0	99.2			0.173
	Copper	94.8	98.3	98.2			0.178
	Lead	97.8	100	99.3			1.05
	Nickel	96.0	98.6	98.2			0.336
	Silver	96.5	98.3	97.8			0.542
EPA 300.0 Rev. 2.1	Chloride	102	97.6	97.0		8.28	
	Sulfate	101	98.1	101		9.98	
EPA 350.1 Rev. 2.0	Ammonia-N	97.4	95.4	98.4			2.59
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	101	103	104			0.732
EPA 353.2 Rev. 2.0	NO2NO3-N	99.5	100				1.23
	NO2NO3-N	100	99.5				0.614
EPA 365.1 Rev. 2.0	Total-P	97.2	96.2	95.0			1.19
	Total-P	99.2	94.2	92.8			1.45
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	98.7	100	98.3			1.81
EPA 8321B	2,4-D	96.9	168	151			10.6
	Acesulfame K	101	89.7	94.1			4.74
	Acetaminophen	99.9	125	119			4.47
	Bentazon	104	91.9	83.2			9.34
	Carbamazepine	74.9	72.0	69.8			3.17
	Diuron	69.4	61.8	61.6			0.337
	Fenuron	82.4	57.7	55.8			3.43
	Fluridone	78.6	80.4	67.4			17.6
	Hydrocodone	87.9	82.9	79.2			4.54
	Ibuprofen	107	95.9	90.0			6.34
	Imazapyr	84.9	107	101			5.58
	Imidacloprid	100	129	131			1.86
	Linuron	64.0	67.0	59.5			11.9
	MCPP	116	177	155			13.3
	Naproxen	123	133	127			4.53
	Primidone	101	80.9	69.3			15.5
	Pyraclostrobin	71.7	71.2	70.6			0.934
	Sucralose	122	117	118			0.944
	Triclopyr	112	215	217			1.07
SM 2120 B	Color (true)	96.6				1.35	
	Color (true)	98.9				2.28	
SM 2320 B-97	Total Alkalinity	103				0.102	
SM 2540 C-97	TDS					6.90	
SM 4500 F-C-97	Fluoride	97.7	98.1	98.3			0.477
SM 5310 B-00	Organic Carbon	97.1	95.5	97.9			1.64

Reference Method Descriptions

Method / DoH Cert #	Description	Associated Samples
---------------------	-------------	--------------------

Reference Method Descriptions

Method / DoH Cert #	Description	Associated Samples
EPA 180.1 Rev. 2.0 / E31780	Turbidity in aqueous matrices	2020366, 2020367
EPA 200.7 Rev. 4.4 / E31780	Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	2020397, 2020398
EPA 200.8 Rev. 5.4 / E31780	Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	2020397, 2020398
EPA 300.0 Rev. 2.1 / E31780	Chloride in aqueous matrices	2020366, 2020367
EPA 300.0 Rev. 2.1 / E31780	Sulfate in aqueous matrices	2020366, 2020367
EPA 350.1 Rev. 2.0 / E31780	Ammonia in aqueous matrices as mg N/L	2020368, 2020369
EPA 351.2 Rev. 2.0 / E31780	Total Kjeldahl Nitrogen in aqueous matrices	2020368, 2020369
EPA 353.2 Rev. 2.0 / E31780	Nitrite/Nitrate in aqueous matrices as mg N/L	2020368, 2020369
EPA 365.1 Rev. 2.0 / E31780	Total Phosphorus in aqueous matrices as mg P/L	2020368, 2020369
EPA 365.1 Rev. 2.0 dissolved / E31780	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	2020370, 2020371
EPA 8321B / E31780	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	2020391, 2020392, 2020393, 2020394
SM 2120 B / E31780	True Color measured at 450 nm	2020366, 2020367
SM 2320 B-97 / E31780	Alkalinity in aqueous matrices as mg CaCO ₃ /L	2020366, 2020367
SM 2540 C-97 / E31780	Total Dissolved Solids in aqueous matrices	2020366, 2020367
SM 2540 D-97 / E31780	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	2020366, 2020367
SM 4500 F-C-97 / E31780	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	2020366, 2020367
SM 5310 B-00 / E31780	Nonpurgeable Organic Carbon in aqueous matrices	2020368, 2020369

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 180.1 Rev. 2.0	08/28/2018			08/28/2018 15:32	Megan Treadwell	2020366, 2020367
EPA 200.7 Rev. 4.4	08/28/2018	08/28/2018 17:10	Elliott D. Healy	08/30/2018 14:05	Betina Topolski	2020397
	08/28/2018	08/28/2018 17:10	Elliott D. Healy	08/30/2018 14:13	Betina Topolski	2020398
EPA 200.8 Rev. 5.4	08/28/2018	08/28/2018 17:10	Elliott D. Healy	08/31/2018 21:33	Allison Taylor	2020397
	08/28/2018	08/28/2018 17:10	Elliott D. Healy	08/31/2018 21:43	Allison Taylor	2020398
EPA 300.0 Rev. 2.1	08/28/2018			08/30/2018 21:06	Lipi Saha	2020366
	08/28/2018			08/30/2018 21:18	Lipi Saha	2020367
EPA 350.1 Rev. 2.0	08/28/2018			08/29/2018 13:19	Ping Hua	2020368
	08/28/2018			08/29/2018 13:21	Ping Hua	2020369
EPA 351.2 Rev. 2.0	08/28/2018	08/29/2018 15:30	Adrian Shelby	08/31/2018 10:17	Joseph Suarez	2020368
		08/29/2018 15:30	Adrian Shelby	08/31/2018 10:19	Joseph Suarez	2020369
EPA 353.2 Rev. 2.0	08/28/2018			09/05/2018 13:06	Lauren Bottorf	2020368
	08/28/2018			09/05/2018 13:28	Lauren Bottorf	2020369
EPA 365.1 Rev. 2.0	08/28/2018	08/30/2018 11:37	Sima Feizi	08/31/2018 07:46	Beverly Y. Sanders	2020368
	08/28/2018	08/30/2018 11:37	Sima Feizi	08/31/2018 07:55	Beverly Y. Sanders	2020369
EPA 365.1 Rev. 2.0 dissolved	08/28/2018			08/28/2018 13:36	Lipi Saha	2020370
	08/28/2018			08/28/2018 13:37	Lipi Saha	2020371
EPA 8321B	08/28/2018	08/29/2018 11:00	Hoor Shaik	08/30/2018 08:57	Juyoung Kim	2020391
	08/28/2018	08/29/2018 11:00	Hoor Shaik	08/30/2018 09:31	Juyoung Kim	2020392
	08/28/2018	08/29/2018 11:00	Hoor Shaik	08/30/2018 10:06	Juyoung Kim	2020393
	08/28/2018	08/29/2018 11:00	Hoor Shaik	08/30/2018 10:41	Juyoung Kim	2020394
	08/28/2018	08/29/2018 11:00	Hoor Shaik	08/31/2018 01:40	Juyoung Kim	2020391
	08/28/2018	08/29/2018 11:00	Hoor Shaik	08/31/2018 02:15	Juyoung Kim	2020392
	08/28/2018	08/29/2018 11:00	Hoor Shaik	08/31/2018 03:24	Juyoung Kim	2020393
	08/28/2018	08/29/2018 11:00	Hoor Shaik	08/31/2018 03:58	Juyoung Kim	2020394
	08/28/2018	08/29/2018 11:50	Mohammad Ghaffari	08/29/2018 15:06	Mohammad Ghaffari	2020391
	08/28/2018	08/29/2018 11:50	Mohammad Ghaffari	08/29/2018 15:35	Mohammad Ghaffari	2020392
	08/28/2018	08/29/2018 11:50	Mohammad Ghaffari	08/29/2018 15:50	Mohammad Ghaffari	2020393
	08/28/2018	08/29/2018 11:50	Mohammad Ghaffari	08/29/2018 16:05	Mohammad Ghaffari	2020394
	08/28/2018	08/29/2018 11:50	Mohammad Ghaffari	08/30/2018 13:28	Mohammad Ghaffari	2020391
	08/28/2018	08/29/2018 11:50	Mohammad Ghaffari	08/30/2018 13:42	Mohammad Ghaffari	2020392
	08/28/2018	08/29/2018 11:50	Mohammad Ghaffari	08/30/2018 14:12	Mohammad Ghaffari	2020394
	08/28/2018	08/29/2018 11:50	Mohammad Ghaffari	08/30/2018 16:55	Mohammad Ghaffari	2020393
SM 2120 B	08/28/2018			08/28/2018 14:50	Julia Storbeck	2020366
	08/28/2018			08/28/2018 15:11	Julia Storbeck	2020367
SM 2320 B-97	08/28/2018			09/05/2018 20:53	Dale L. Simmons	2020366
	08/28/2018			09/05/2018 21:01	Dale L. Simmons	2020367
SM 2540 C-97	08/28/2018			08/30/2018 14:22	Yijie Li	2020366, 2020367
SM 2540 D-97	08/28/2018			08/30/2018 14:22	Yijie Li	2020366, 2020367
SM 4500 F-C-97	08/28/2018			08/31/2018 05:35	Dale L. Simmons	2020366

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
SM 4500 F-C-97	08/28/2018			08/31/2018 05:45	Dale L. Simmons	2020367
SM 5310 B-00	08/28/2018			09/07/2018 15:22	Megan Treadwell	2020368
	08/28/2018			09/07/2018 17:59	Megan Treadwell	2020369