

Log-in Checklist

RQ- 2018-07-09-30

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound | _____ Date/Time of Receipt: 07/17/18 @ 10:25am

Cooler ID	Cooler Temperature*	No. Sample Containers in Cooler	Evidence Tape				Tracking # (fill out only if waybill copy is damaged)
			Present?		*Intact?		
			Yes	No	Yes	No	
Red	2.1°C	12		X			4385 5030 8609
Red	1.7°C	11		X			4385 5030 8583
Red	1.6°C	13		X			4385 5030 8594
Blue	1.9°C	4		X			4385 5030 8572

*If the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged, identify the containers in the affected cooler(s) on back of this form.

****Note:** If "No" is checked in any of the fields below, fill out the back of this form with additional details (Field ID, Test IDs, etc.) and generate an NCR.

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No _____

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes _____ No X Date _____

CONTAINER CHECK

**Evidence Tape on Bottles? Yes _____ No X If yes, is it intact? Yes _____ No _____

**Caps on tight? Yes ✓ No _____ **Containers intact? Yes ✓ No _____

**Sufficient Sample Volume: Yes ✓ No _____

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ✓ No _____ Init: ML

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-E8321-DI, -MS, -21		X	W-NP-AA-SF		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)		X	W-PCL-SQ-R		X
W-U2060-MS			W-TR-TQ		
W-PCB-R			W-CT-CI-R		X
W-PAH (-R)			W-PSNP-TQ		X

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No _____ NA _____ Init: ML

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes _____ No _____ NA X Init: ML

Coolers Unpacked/Checked by: Tyler R. Date: 07/17/18 NCRs (Y/N)? N

Event ID: Sarasota Gators
SO-DIST-2018-07-17-02 (SMP)
 Date Received: 17-JUL-2018 1
 NCR # _____

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_05_2018
pH Paper 0.0 – 3.0 Lot #	230515 EXP:10/30/2018
pH Paper 0 – 13 Lot #	222516 EXP:09/15/2019
Chlorine Test Strips Lot #	091417V EXP:09/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Sarasota Gators

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: SO-DIST

Requester: Nicole Reistad

Field Report Prepared By: Nicole Reistad

Project ID: SMP

Collected By: Nicole Reistad, Maryann Dugan

Sampling Agency: FDEP - SoROC

Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 07/16/2018 Time 0950	Eastern Central	Composite end Date	Time	Bottle Group(s) (See pg 2)
Field ID	Location	G3SD0066	Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		B, C, D
WIN/STORET	Curry(Tidal)@AlbeeFarm		Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)		
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			
Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 07/16/2018 Time 1040	Eastern Central	Composite end Date	Time	Bottle Group(s)
Field ID	Location	G3SD0103	Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		B, C
WIN/STORET #	HatchettCrk@PinebrookRd		Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)		
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			
Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 07/16/2018 Time 1115	Eastern Central	Composite end Date	Time	Bottle Group(s)
Field ID	Location	G2SD0025	Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		B, C, E
WIN/STORET #	Alligator Tidal @ US 41		Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)		
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			
Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 07/16/2018 Time 1235	Eastern Central	Composite end Date	Time	Bottle Group(s)
Field ID	Location	G2SD0026	Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)		A, B, C
WIN/STORET #	Alligator @ Jacaranda		Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)		
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
N. Reistad	07/16/18 1500	FedEx	4	Tyler R.	07/17/18 @ 10:25

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ALKALINITY					
	TURBIDITY					
	W-CL-IC					
	W-COLOR					
	W-F					
	W-SO4-IC					
	W-TDS					
	W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	CHLSUITE-W					
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ALKALINITY					
	TURBIDITY					
	W-F					
	W-TSS					
Group: B	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	CHLSUITE-W					
Group: B	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	SD-BES-ECQ					
Group: B	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab
	W-ICP					
	W-ICPMS					
Group: B	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab
	W-NH3					

Sarasota Gators

Central Laboratory Submittal Form

last revised Jan 25, 2018

Customer: SO-DIST

Requester: Nicole Reistad

Field Report Prepared By: Nicole Reistad

Project ID: SMP

Collected By: Nicole Reistad, Maryann Dugan

Sampling Agency: FDEP - So. ROC

Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 07/16/2018 Time 1305	Eastern Central	Composite end Date	Time	Bottle Group(s) (See pg 2)
Field ID	Location	G2SD0027	Matrix (type, e.g., Salt, Fresh, etc) Fresh		Diss. Oxygen 5.67	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	C
WIN/STORET #	Woodmere Creek@Heron Rd		Temp (C) 29.9	pH 7.0	Sample Depth 0.1	☐ ft ☒ m	Sp. Conductance (umho/cm) 1097	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 0.54	Comments Enter @ Benchmark			
Location	Field ID/WIN ID		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 07/16/2018 Time 1340	Eastern Central	Composite end Date	Time	Bottle Group(s)
Field ID	Location	G2SD0028	Matrix (type, e.g., Salt, Fresh, etc) Salt		Diss. Oxygen 2.91	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	C
WIN/STORET #	Gottfried@DeerCrkMobile		Temp (C) 31.7	pH 7.6	Sample Depth 0.3	☐ ft ☒ m	Sp. Conductance (umho/cm) 39504	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 24.99	Comments Enter @ Benchmark			
Location			☐ Comp ☐ Grab	Collection (comp begin or grab) Date	Eastern Central	Composite end Date	Time	Bottle Group(s)
Field ID			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/STORET #			Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			
Location			☐ Comp ☐ Grab	Collection (comp begin or grab) Date	Eastern Central	Composite end Date	Time	Bottle Group(s)
Field ID			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/STORET #			Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			

Relinquished By: N. Reistad	Date/Time 07/16/18 1500	Shipping Method FedEx	Number of Coolers Shipped: 4	Received By: Tyler R.	Date/Time 07/17/18 @ 10:25
--------------------------------	----------------------------	--------------------------	---------------------------------	--------------------------	-------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	ALKALINITY TURBIDITY W-F W-TSS						
Group: B	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	CHLSUITE-W						
Group: B	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>0; 2@ Benchmark</u>
	SD-BES-ECQ						
Group: B	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-ICP W-ICPMS						
Group: B	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-NH3						

Group: B	Bottle Type: W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 2	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>2</u>
Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 2	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab <u>2</u>
Group: C	Bottle Type: PCR-FILTER	QPCR-P-500ML	# of Bottles: 4	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>4</u>
Group: C	Bottle Type: SD-BES-ENT	P-120ML-WC-THI	# of Bottles: 4	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>0; 4 @ Benchmark</u>
Group: C	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 4	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>4</u>
Group: D	Bottle Type: PCR-FILTER	QPCR-P-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: D	Bottle Type: W-CARB-AA	BG-500ML	# of Bottles: 1	Preservative: CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab <u>1</u>
Group: D	Bottle Type: W-CT-CI-R W-PCL-SQ-R	BG-500ML	# of Bottles: 4	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>4</u>
Group: D	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: D	Bottle Type: W-PSNP-TQ	BG-1L	# of Bottles: 4	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>4</u>
Group: E	Bottle Type: PCR-FILTER	QPCR-P-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>1</u>
Group: E	Bottle Type: W-CARB-AA	BG-500ML	# of Bottles: 1	Preservative: CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab <u>1</u>
Group: E	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab _____

NEXT PAGE ↓

Group: E	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-CT-CI-R						
	W-PCL-SQ-R						
Group: E	Bottle Type:	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>31</u>
	W-E8321-DI						
	W-E8321-MS						
Group: E	Bottle Type:	BG-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	<u>2</u>
	W-PSNP-TQ						

Cooler Packing Worksheet for Request: RQ-2018-07-09-30

Sarasota Gators

Ship Cooler On: 6/29/2018

Customer/Project: SO-DIST/SMP

Assigned To: SHAIK_A

Requester: Nicole Reistad

Priority: 3

239-344-5718
FLDEP South District Office
2295 Victoria Ave. Suite 364
Fort Myers, FL 33901-3381

Attn: Nicole Reistad

Please return
packing list with
sample submittal
forms.

Comments:

No preservatives needed.

Group A: Freshwater Kit, No Metals (Kit A) x 1
Group B: Marine Kit with Metals (Kit D); E.Coli x 2
Group C: Markers, Tracers; Entero x 4
Group D: Markers, Pesticides x 1
Group E: Markers, Pesticides x 1

Requested Analyses:

Bottle Group: A

of Sites: 1

Container ID: P-1L

Qty: 1

Preservation: ICE

Lot #

50071006

Description: Plastic Bottle 1L

Analysis

ALKALINITY

TURBIDITY

W-CL-IC

W-COLOR

W-F

W-SO4-IC

W-TDS

W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L

Turbidity in aqueous matrices

Chloride in aqueous matrices

True Color measured at 450 nm

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Sulfate in aqueous matrices

Total Dissolved Solids in aqueous matrices

Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 1

Preservation: ICE

Lot #

1223623

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-500ML

Qty: 1 Preservation: ICE And H2SO4

Lot # 00070684

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3
W-NO2NO3
W-S-A-TP
W-TKN
W-TOC

Description

Ammonia in aqueous matrices as mg N/L
Nitrite/Nitrate in aqueous matrices as mg N/L
Total Phosphorus in aqueous matrices as mg P/L
Total Kjeldahl Nitrogen in aqueous matrices
Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00069732

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group: B

of Sites: 2

Container ID: P-1L

Qty: 2 Preservation: ICE

Lot # 00071006

Description: Plastic Bottle 1L

Analysis

ALKALINITY
TURBIDITY
W-F
W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L
Turbidity in aqueous matrices
Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 2 Preservation: ICE

Lot # 1223623

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WI-THI

Qty: 2 Preservation: ICE

Lot # L18005

Description:

Analysis

SD-BES-ECQ

Description

Escherichia coli by Colilert 18 Quanti-Tray method by Benchmark EA South

Container ID: P-500ML

Qty: 2 Preservation: HNO3

Lot # 55070684

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP

W-ICPMS

Description

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 2 Preservation: ICE And H2SO4

Lot # 55070684

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 2 Preservation: FILTER-ICE

Lot # 55069732

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group: C

of Sites: 4

Container ID: QPCR-P-500ML

Qty: 4 Preservation: ICE

Lot # 55070507

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-FILTER

Description

Preparation of Samples by Filtration and held for qPCR Analysis

Container ID: P-120ML-WC-THI

Qty: 4 Preservation: ICE

Lot # 6482-1

Description: 120 ml Sterilized White Cap with tablet

Analysis

SD-BES-ENT

Description

Enterococci by membrane filter method by Benchmark EA South

Container ID: BG-500ML

Qty: 4

Preservation: ICE

Lot # 05071432

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group: D

of Sites: 1

Container ID: QPCR-P-500ML

Qty: 1

Preservation: ICE

Lot # 05070507

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-FILTER

Description

Preparation of Samples by Filtration and held for qPCR Analysis

Container ID: BG-500ML

Qty: 1

Preservation: CH₂ClCOOH Pre-Preserved

Lot # 05071432

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML

Qty: 4

Preservation: ICE

Lot # 05071432

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CT-CI-R

W-PCL-SQ-R

Description

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Organochlorine pesticides in water matrices by GC/MS-SIM

Container ID: BG-500ML

Qty: 1

Preservation: ICE

Lot # 05071432

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: BG-1L

Qty: 4 Preservation: ICE

Lot # 55071178

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

Description

Organonitrogen and phosphorus pesticides (ultra trace level) in water matrices by GC/MS/MS

Bottle Group: E

of Sites: 1

Container ID: QPCR-P-500ML

Qty: 1 Preservation: ICE

Lot # 55070507

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-FILTER

Description

Preparation of Samples by Filtration and held for qPCR Analysis

Container ID: BG-500ML

Qty: 1 Preservation: CH₂ClCOOH Pre-Preserved

Lot # 55071432

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML

Qty: 2 Preservation: ICE

Lot # 55071432

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CT-Cl-R

W-PCL-SQ-R

Description

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Organochlorine pesticides in water matrices by GC/MS-SIM

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 55071432

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: BG-1L

Qty: 2 Preservation: ICE

Lot # 00071178

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

Description

Organonitrogen and phosphorus pesticides (ultra trace level) in water matrices by GC/MS/MS

Cooler Packed By: ABP

Number of Coolers: 4

Date: 6-26-18

Kit must also include:

- ☒ Field Sheets
- ☒ Temperature Control Bottle
- ☒ FedEx Bills, if applicable
- ☒ Plastic Bags/Zip Ties
- ☒ Acid Labels (sets of 24)

If Preservation Included:

ID <u>MCAD</u>	Exp <u>10-1-19</u>	Lot # <u>85819</u>
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____

PLEASE RETURN ALL COOLERS FOR RQ-2018-07-09-30

Date of Request: 14-JUN-2018
 Created By: REISTAD_N On: 14-JUN-2018
 Modified By: SWANSON_C On: 20-JUN-2018
 Customer: SO-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: South District
 Sampling Event: Sarasota Gators

Send Coolers To:

Phone: 239-344-5718
 FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Program Module Number:
 Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 15-JUN-2018
 Biology Request Reviewed By: SWANSON_C On: 20-JUN-2018
 Sampling Kit Required: YES Ship on: 29-JUN-2018
 Sampling Kit Shipped: YES On: 26-JUN-2018
 Sampling Kit Packed By: SHAIK_A
 Preservatives Needed: NO
 Date to Receive Samples: 09-JUL-2018
 Received By:

Send Final Report To:

FLDEP South District Office
 2295 Victoria Ave. Suite 364
 Fort Myers, FL 33901-3381
 Attn: Nicole Reistad

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Freshwater Kit, No Metals (Kit A) x 1
 Group B: Marine Kit with Metals (Kit D); E.Coli x 2
 Group C: Markers, Tracers; Entero x 4
 Group D: Markers, Pesticides x 1
 Group E: Markers, Pesticides x 1

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
----------------------	----------------------	----------------------------

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
SD-BES-ECQ	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method by Benchmark EA South in North Port
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Chromium		
Iron		
Zinc		
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Cadmium		
Copper		
Lead		
Nickel		
Silver		
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group C (Water) With 4 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 4	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: P-120ML-WC-THI	Number of Bottles: 4	Preserved With: ICE
SD-BES-ENT	Template: DEFAULT	(EPA 1600 (MF)) Enterococci by membrane filter method by Benchmark EA South
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-E8321-DI	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group D (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270D) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270D) Organonitrogen and phosphorus pesticides (ultra trace level) in water matrices by GC/MS/MS

Bottle Group E (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
---------------------------	----------------------	---------------------

Bottle Group E (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270D) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: BG-1L	Number of Bottles: 2	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270D) Organonitrogen and phosphorus pesticides (ultra trace level) in water matrices by GC/MS/MS

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

