

Chemical Analysis Report

TLH-ROC-2018-05-10-01

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780


Event Description: **A-b/t/m**
Request ID: **RQ-2018-05-14-41**
Customer: **TLH-ROC**
Project ID: **SMP**

Send Reports to:
FL Dept. of Environmental Protection
2600 Blair Stone Rd
Tallahassee, FL 32399
Attn: Michael Eckles

For additional information please contact
Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Colin Wright, Program Administrator

Date Certified: 04-JUN-2018 11:15

A handwritten signature in black ink, appearing to read "Colin Wright", is written over a light blue rectangular background.

Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: G1TLHR0069

Collection Date/Time: 05/10/2018 09:45

Field ID: G1TLHR0069

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
1992057	EPA 180.1 Rev. 2.0	Turbidity	2.6		NTU	P345063	
	EPA 300.0 Rev. 2.1	Chloride	5.0		mg Cl/L	P345277	
		Sulfate	3.9		mg SO4/L	P345279	
	SM 2120 B	Color (true)	8.2		PCU	P345039	
	SM 2320 B-97	Total Alkalinity	112		mg CaCO3/L	P345482	RPD
	SM 2540 C-97	TDS	128	A	mg/L	P345475	
	SM 2540 D-97	TSS	6	IA	mg/L	P345286	
	SM 4500 F-C-97	Fluoride	0.13		mg F/L	P345485	
1992058	EPA 350.1 Rev. 2.0	Ammonia-N	0.036		mg N/L	P345386	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.16	I	mg N/L	P345399	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.044		mg N/L	P345406	
	EPA 365.1 Rev. 2.0	Total-P	0.057		mg P/L	P345300	
	SM 5310 B-00	Organic Carbon	1.3		mg C/L	P345359	
1992059	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.026		mg P/L	P345054	
1992063	EPA 8321B	2,4-D	0.0020	U	ug/L	P344935	
		Bentazon	8.0E-04	U	ug/L	P344935	MS
		MCP	0.0020	U	ug/L	P344935	
		Triclopyr**	0.0040	U	ug/L	P344935	
		Imidacloprid	0.0020	U	ug/L	P344935	
		Diuron	0.0020	U	ug/L	P344935	MS
		Pyraclostrobin**	0.0020	U	ug/L	P344935	
		Primidone**	0.0040	U	ug/L	P344935	
		Linuron	0.0040	U	ug/L	P344935	
		Acetaminophen**	0.0080	U	ug/L	P344935	
		Fenuron	0.016	U	ug/L	P344935	
		Imazapyr**	0.0040	U	ug/L	P344935	
		Carbamazepine**	4.0E-04	U	ug/L	P344935	MS
		Fluridone**	4.0E-04	U	ug/L	P344935	
		Hydrocodone**	8.0E-04	U	ug/L	P344935	
		Sucralose**	0.010	U	ug/L	P345005	

Ref. Method and Comment:

EPA 300.0 Rev. 2.1: Chloride: Batch matrix spike recoveries for one of two spiked samples are unavailable because of high analyte concentration in the QC sample.

EPA 300.0 Rev. 2.1: Sulfate: Batch matrix spike recoveries for one of two spiked samples are unavailable because of high analyte concentration in the QC sample.

SM 2540 D-97: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

Quality Assurance Report

Method Blank Results

Reference Method: EPA 180.1 Rev. 2.0

Batch ID: P345063

Component	Result	Code	Units
Turbidity	0.10	U	NTU

Quality Assurance Report Method Blank Results

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P345277

Component	Result	Code	Units
Chloride	0.20	U	mg Cl/L

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P345279

Component	Result	Code	Units
Sulfate	0.20	U	mg SO4/L

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P345386

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P345399

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P345406

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P345300

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P345054

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8321B
Batch ID: P344935

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
Acetaminophen	0.0080	U	ug/L
Bentazon	8.0E-04	U	ug/L
Carbamazepine	4.0E-04	U	ug/L
Diuron	0.0020	U	ug/L
Fenuron	0.016	U	ug/L
Fluridone	4.0E-04	U	ug/L
Hydrocodone	8.0E-04	U	ug/L
Imazapyr	0.0040	U	ug/L
Imidacloprid	0.0020	U	ug/L

Quality Assurance Report Method Blank Results

Reference Method: EPA 8321B
Batch ID: P344935

Component	Result	Code	Units
Linuron	0.0040	U	ug/L
MCPP	0.0020	U	ug/L
Primidone	0.0040	U	ug/L
Pyraclostrobin	0.0020	U	ug/L
Triclopyr	0.0040	U	ug/L

Reference Method: EPA 8321B
Batch ID: P345005

Component	Result	Code	Units
Sucralose	0.010	U	ug/L

Reference Method: SM 2120 B
Batch ID: P345039

Component	Result	Code	Units
Color (true)	2.5	U	PCU

Reference Method: SM 2320 B-97
Batch ID: P345482

Component	Result	Code	Units
Total Alkalinity	0.65	U	mg CaCO3/L

Reference Method: SM 2540 C-97
Batch ID: P345475

Component	Result	Code	Units
TDS	15	U	mg/L

Reference Method: SM 2540 D-97
Batch ID: P345286

Component	Result	Code	Units
TSS	2	U	mg/L

Reference Method: SM 4500 F-C-97
Batch ID: P345485

Component	Result	Code	Units
Fluoride	0.035	U	mg F/L

Reference Method: SM 5310 B-00
Batch ID: P345359

Component	Result	Code	Units
Organic Carbon	0.50	U	mg C/L

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 300.0 Rev. 2.1
 Batch ID: P345277

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Chloride	92.9		P	90 - 110

Reference Method: EPA 300.0 Rev. 2.1
 Batch ID: P345279

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Sulfate	92.2		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
 Batch ID: P345386

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	101		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
 Batch ID: P345399

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	104		P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
 Batch ID: P345406

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	98.5		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
 Batch ID: P345300

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	103		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
 Batch ID: P345054

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	101		P	90 - 110

Reference Method: EPA 8321B
 Batch ID: P344935

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	104		P	40 - 150
Acetaminophen	93.4		P	30 - 150
Bentazon	102		P	30 - 150
Carbamazepine	67.4		P	40 - 150
Diuron	65.0		P	40 - 150
Fenuron	107		P	40 - 150
Fluridone	85.4		P	40 - 150
Hydrocodone	109		P	40 - 150
Imazapyr	103		P	40 - 150
Imidacloprid	113		P	40 - 160

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 8321B
 Batch ID: P344935

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Linuron	101		P	40 - 150
MCPP	109		P	40 - 150
Primidone	103		P	40 - 150
Pyraclostrobin	83.4		P	40 - 150
Triclopyr	109		P	40 - 150

Reference Method: EPA 8321B
 Batch ID: P345005

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Sucralose	109		P	40 - 150

Reference Method: SM 2320 B-97
 Batch ID: P345482

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total Alkalinity	102		P	98 - 107

Reference Method: SM 4500 F-C-97
 Batch ID: P345485

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Fluoride	95.6		P	91 - 105

Reference Method: SM 5310 B-00
 Batch ID: P345359

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Organic Carbon	95.1		P	85 - 115

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 300.0 Rev. 2.1
 Batch ID: P345277

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1992071	Chloride	94.2		P	90 - 110

Reference Method: EPA 300.0 Rev. 2.1
 Batch ID: P345279

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1992071	Sulfate	93.6		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
 Batch ID: P345386

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1991843	Ammonia-N	97.8	99.9	P/P	90 - 110

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P345399

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1992103	Kjeldahl Nitrogen	99.6	96.7	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P345406

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1991908	NO2NO3-N	90.5	91.5	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P345300

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1992058	Total-P	98.0	97.5	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P345054

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1991832	O-Phosphate-P	93.2	93.8	P/P	90 - 110

Reference Method: EPA 8321B
Batch ID: P344935

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1990998	2,4-D	74.1	71.4	P/P	40 - 150
1990998	Acetaminophen	71.6	72.9	P/P	30 - 150
1990998	Bentazon	25.7	27.9	F/F	30 - 150
1990998	Carbamazepine	33.9	35.1	F/F	40 - 150
1990998	Diuron	37.5	38.0	F/F	40 - 150
1990998	Fenuron	42.6	46.5	P/P	40 - 150
1990998	Fluridone	63.7	66.1	P/P	40 - 150
1990998	Hydrocodone	67.5	71.6	P/P	40 - 150
1990998	Imazapyr	91.0	89.8	P/P	40 - 150
1990998	Imidacloprid	102	103	P/P	40 - 160
1990998	Linuron	78.7	77.8	P/P	40 - 150
1990998	MCPP	65.8	60.1	P/P	40 - 150
1990998	Primidone	60.5	55.6	P/P	40 - 150
1990998	Pyraclostrobin	69.1	69.7	P/P	40 - 150
1990998	Triclopyr	77.8	78.2	P/P	40 - 150

Reference Method: EPA 8321B
Batch ID: P345005

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1991713	Sucralose	97.2	99.2	P/P	40 - 150

Reference Method: SM 4500 F-C-97
Batch ID: P345485

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1992222	Fluoride	95.2	93.6	P/P	91 - 105

Quality Assurance Report Matrix Spike Accuracy

Reference Method: SM 5310 B-00
Batch ID: P345359

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
1991899	Organic Carbon	94.0	95.1	P/P	85 - 115

Quality Assurance Report Precision

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P345063

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1992071	Turbidity	3.36	Sample	P	0 - 20

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P345277

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1991830	Chloride	0.213	Sample	P	0 - 20

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P345279

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1991830	Sulfate	0.204	Sample	P	0 - 20

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P345386

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1991843	Ammonia-N	1.78	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P345399

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1992103	Kjeldahl Nitrogen	2.03	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P345406

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1991908	NO2NO3-N	1.10	Spike	P	0 - 20

Quality Assurance Report Precision

Reference Method: EPA 365.1 Rev. 2.0

Batch ID: P345300

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1992058	Total-P	0.469	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Batch ID: P345054

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1991832	O-Phosphate-P	0.642	Spike	P	0 - 20

Reference Method: EPA 8321B

Batch ID: P344935

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1990998	2,4-D	3.71	Spike	P	0 - 30
1990998	Acetaminophen	1.78	Spike	P	0 - 30
1990998	Bentazon	8.36	Spike	P	0 - 30
1990998	Carbamazepine	3.60	Spike	P	0 - 30
1990998	Diuron	1.32	Spike	P	0 - 30
1990998	Fenuron	8.76	Spike	P	0 - 30
1990998	Fluridone	3.74	Spike	P	0 - 30
1990998	Hydrocodone	5.84	Spike	P	0 - 30
1990998	Imazapyr	0.809	Spike	P	0 - 30
1990998	Imidacloprid	0.974	Spike	P	0 - 30
1990998	Linuron	1.24	Spike	P	0 - 30
1990998	MCP	9.09	Spike	P	0 - 30
1990998	Primidone	8.44	Spike	P	0 - 30
1990998	Pyraclostrobin	0.775	Spike	P	0 - 30
1990998	Triclopyr	0.510	Spike	P	0 - 30

Reference Method: EPA 8321B

Batch ID: P345005

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1991713	Sucralose	1.94	Spike	P	0 - 30

Reference Method: SM 2120 B

Batch ID: P345039

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1991937	Color (true)	2.00	Sample	P	0 - 20

Reference Method: SM 2320 B-97

Batch ID: P345482

Replicated

Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1992222	Total Alkalinity	4.30	Sample	F	0 - 1.6

Quality Assurance Report Precision

Reference Method: SM 2540 C-97
Batch ID: P345475

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1992057	TDS	3.89	Sample	P	0 - 10

Reference Method: SM 4500 F-C-97
Batch ID: P345485

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1992222	Fluoride	1.45	Spike	P	0 - 3.5

Reference Method: SM 5310 B-00
Batch ID: P345359

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
1991899	Organic Carbon	1.01	Spike	P	0 - 20

* Sample, spike and/or laboratory control sample precision (LCS) is reported.
Replicate spike precision may be reported when sample results are below quantifiable levels.

Quality Assurance Report Surrogates

Lab Sample ID: 1992063
Field Sample ID: G1TLHR0069

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	76.2	P	30 - 160
EPA 8321B	Acetaminophen-d4	79.5	P	30 - 160
EPA 8321B	Carbamazepine-d10	70.0	P	30 - 160
EPA 8321B	Diuron-d6	70.1	P	30 - 160
EPA 8321B	Primidone-d5	88.4	P	30 - 160
EPA 8321B	Sucralose-d6	128	P	40 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 300.0 Rev. 2.1
Run ID: A83732
Included Lab Sample IDs: 1992057

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Chloride	97.0	99.9	P/P	90 - 110
Sulfate	97.3	100	P/P	90 - 110

Reference Method: SM 2120 B
Run ID: A83803
Included Lab Sample IDs: 1992057

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Color (true)	102	104	P/P	90 - 115

Quality Assurance Report Calibration Verification

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A83807

Included Lab Sample IDs: 1992059

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	99.1	98.5	P/P	90 - 110

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A83809

Included Lab Sample IDs: 1992057

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Turbidity	100	100	P/P	95 - 105

Reference Method: EPA 8321B

Run ID: A83887

Included Lab Sample IDs: 1992063

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2,4-D	110	101	P/P	50 - 150
Bentazon	112	119	P/P	50 - 150
MCP	104	104	P/P	50 - 150
Triclopyr	103	108	P/P	50 - 160

Reference Method: SM 5310 B-00

Run ID: A83906

Included Lab Sample IDs: 1992058

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Organic Carbon	94.7	94.1	P/P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A83925

Included Lab Sample IDs: 1992058

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	100	100	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A83934

Included Lab Sample IDs: 1992058

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO ₂ NO ₃ -N	100	100	P/P	90 - 110

Reference Method: SM 2320 B-97

Run ID: A83969

Included Lab Sample IDs: 1992057

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total Alkalinity	99.4	103	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: SM 4500 F-C-97
 Run ID: A83969
 Included Lab Sample IDs: 1992057

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Fluoride	98.1	99.1	P/P	90 - 110

Reference Method: EPA 8321B
 Run ID: A83978
 Included Lab Sample IDs: 1992063

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Sucralose	110	109	P/P	60 - 160

Reference Method: EPA 351.2 Rev. 2.0
 Run ID: A84004
 Included Lab Sample IDs: 1992058

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	98.4	94.8	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
 Run ID: A84011
 Included Lab Sample IDs: 1992058

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	103	102	P/P	90 - 110

Reference Method: EPA 8321B
 Run ID: A84229
 Included Lab Sample IDs: 1992063

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acetaminophen	103	108	P/P	60 - 150
Carbamazepine	94.7	91.8	P/P	60 - 150
Diuron	99.0	96.2	P/P	60 - 150
Fenuron	94.4	99.1	P/P	60 - 150
Fluridone	97.9	97.4	P/P	60 - 160
Hydrocodone	110	106	P/P	60 - 150
Imazapyr	114	108	P/P	50 - 150
Imidacloprid	104	97.7	P/P	60 - 150
Linuron	112	112	P/P	60 - 150
Primidone	107	107	P/P	60 - 150
Pyraclostrobin	97.8	91.7	P/P	60 - 150

* Pass/Fail determinations are made for each bracketing calibration verification check.
 Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.
 Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery	LCS	Precision SMP	MS
EPA 180.1 Rev. 2.0	Turbidity				3.36	

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery	MS % Recovery		Precision	
					LCS	MS
EPA 300.0 Rev. 2.1	Chloride	92.9	94.2		0.213	
	Sulfate	92.2	93.6		0.204	
EPA 350.1 Rev. 2.0	Ammonia-N	101	97.8	99.9		1.78
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	104	99.6	96.7		2.03
EPA 353.2 Rev. 2.0	NO ₂ NO ₃ -N	98.5	90.5	91.5		1.10
EPA 365.1 Rev. 2.0	Total-P	103	98.0	97.5		0.469
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	101	93.2	93.8		0.642
EPA 8321B	2,4-D	104	74.1	71.4		3.71
	Acetaminophen	93.4	71.6	72.9		1.78
	Bentazon	102	25.7	27.9		8.36
	Carbamazepine	67.4	33.9	35.1		3.60
	Diuron	65.0	37.5	38.0		1.32
	Fenuron	107	42.6	46.5		8.76
	Fluridone	85.4	63.7	66.1		3.74
	Hydrocodone	109	67.5	71.6		5.84
	Imazapyr	103	91.0	89.8		0.809
	Imidacloprid	113	102	103		0.974
	Linuron	101	78.7	77.8		1.24
	MCP	109	65.8	60.1		9.09
	Primidone	103	60.5	55.6		8.44
	Pyraclostrobin	83.4	69.1	69.7		0.775
	Sucralose	109	97.2	99.2		1.94
	Triclopyr	109	77.8	78.2		0.510
SM 2120 B	Color (true)				2.00	
SM 2320 B-97	Total Alkalinity	102			4.30	
SM 2540 C-97	TDS				3.89	
SM 4500 F-C-97	Fluoride	95.6	95.2	93.6		1.45
SM 5310 B-00	Organic Carbon	95.1	94.0	95.1		1.01

Reference Method Descriptions

Method / DoH Cert #	Description	Associated Samples
EPA 180.1 Rev. 2.0 / E31780	Turbidity in aqueous matrices	1992057
EPA 300.0 Rev. 2.1 / E31780	Chloride in aqueous matrices	1992057
EPA 300.0 Rev. 2.1 / E31780	Sulfate in aqueous matrices	1992057
EPA 350.1 Rev. 2.0 / E31780	Ammonia in aqueous matrices as mg N/L	1992058
EPA 351.2 Rev. 2.0 / E31780	Total Kjeldahl Nitrogen in aqueous matrices	1992058
EPA 353.2 Rev. 2.0 / E31780	Nitrite/Nitrate in aqueous matrices as mg N/L	1992058
EPA 365.1 Rev. 2.0 / E31780	Total Phosphorus in aqueous matrices as mg P/L	1992058
EPA 365.1 Rev. 2.0 dissolved / E31780	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	1992059
EPA 8321B / E31780	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	1992063
SM 2120 B / E31780	True Color measured at 450 nm	1992057
SM 2320 B-97 / E31780	Alkalinity in aqueous matrices as mg CaCO ₃ /L	1992057
SM 2540 C-97 / E31780	Total Dissolved Solids in aqueous matrices	1992057
SM 2540 D-97 / E31780	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	1992057
SM 4500 F-C-97 / E31780	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	1992057
SM 5310 B-00 / E31780	Nonpurgeable Organic Carbon in aqueous matrices	1992058

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 180.1 Rev. 2.0	05/10/2018			05/10/2018 16:14	William L. Brown IV	1992057
EPA 300.0 Rev. 2.1	05/10/2018			05/12/2018 02:50	Lipi Saha	1992057
EPA 350.1 Rev. 2.0	05/10/2018			05/15/2018 12:06	Ping Hua	1992058
EPA 351.2 Rev. 2.0	05/10/2018	05/16/2018 11:00	Adrian Shelby	05/17/2018 18:27	Joseph Suarez	1992058
EPA 353.2 Rev. 2.0	05/10/2018			05/16/2018 11:16	Lauren Bottorf	1992058
EPA 365.1 Rev. 2.0	05/10/2018	05/15/2018 12:25	Sima Feizi	05/17/2018 11:02	Beverly Y. Sanders	1992058
EPA 365.1 Rev. 2.0 dissolved	05/10/2018			05/10/2018 16:03	Julia Storbeck	1992059
EPA 8321B	05/10/2018	05/11/2018 13:00	Hoor Shaik	05/12/2018 10:26	Juyoung Kim	1992063
	05/10/2018	05/11/2018 13:00	Hoor Shaik	05/16/2018 10:59	Juyoung Kim	1992063
	05/10/2018	05/15/2018 16:00	Hoor Shaik	05/15/2018 20:41	Juyoung Kim	1992063
SM 2120 B	05/10/2018			05/10/2018 14:41	Tanya Welborn	1992057
SM 2320 B-97	05/10/2018			05/16/2018 00:24	Dale L. Simmons	1992057
SM 2540 C-97	05/10/2018			05/11/2018 17:30	William L. Brown IV	1992057
SM 2540 D-97	05/10/2018			05/11/2018 17:30	William L. Brown IV	1992057
SM 4500 F-C-97	05/10/2018			05/16/2018 00:24	Dale L. Simmons	1992057
SM 5310 B-00	05/10/2018			05/15/2018 03:01	Megan Treadwell	1992058