

Log-in Checklist

RQ- 2018-11-26-57

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 11/27/18 4:04pm

Cooler Temperature*	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # (fill out only if waybill copy is damaged)
				Present?		*Intact?		
	HNO ₃	Formalin		Yes	No	Yes	No	
2.2°C			15+2 (17)		X			

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form.

****Note:** If "No" is checked in any of the fields below, fill out the back of this form with additional details (Field ID, Test IDs, etc.) and generate an NCR.

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No X Date

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No X If yes, is it intact? Yes No

**Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No

**Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes No X Init: m

Check the Box marked "Yes" or "No" for the Presence of Chlorine. If Cl detected, an NCR is required.					
Analysis	Yes	No	Analysis	Yes	No
W-1,4 DIOX			W-PC-AA-SF		
W-E8321-DI, -MS, -21			W-NP-AA-SF		
W-BNA (-625, -R)			W-PDQUAT		
W-CARB-AA (-CAB-AA-R)			W-PCL-SQ-R		
W-U2060-MS			W-TR-TQ		
W-PCB-R			W-CT-CI-R		
W-PAH (-R)			W-PSNP-TQ		

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: m

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA X Init: m

Coolers Unpacked/Checked by: Tyler R Date: 11/27/18 NCRs (Y/N)? N

Event ID: G1 Run 2
TLH-ROC-2018-11-27-01 (SMP) NCR #

Page 1 of 2, 8/ Date Received: 27-NOV-2018 16

Log-in Checklist

Samples with Incorrect pH Preservation or presence of Chlorine

Field ID	Bottle Test ID(s)	pH / Cl	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_04_2018
pH Paper 0.0 – 3.0 Lot #	
pH Paper 0 – 13 Lot #	222516 EXP:09/15/2019
Chlorine Test Strips Lot #	091417V EXP:09/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes_____ No_____

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes_____ If No_____

no, were samples shipped on dry ice? Yes_____ No_____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check(W-HG-AF;W-HG-AF-F):

Samples preserved within 48 hours? Yes_____ No_____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

G1 Run 2

last revised Jan 25, 2018

Customer: TLH-ROC

Requester: Michael Eckles

Field Report Prepared By:

Project ID: SMP

Collected By:

Sampling Agency:

Location		☐ Comp	Collection (comp begin or grab)		☒ Eastern	Composite end		Bottle Group(s) (See pg 2)
Field/WIN ID →		☒ Grab	Date 11/27/18	Time 10:20	Central	Date	Time	
Location ↓	G1TLHR0007	Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☒ mg/L	Total Res. Chlorine (mg/L)		
WI		Temp (C) 12.88		pH 6.79	☒ % sat	Sp. Conductance (umho/cm) 157.7		
Lat	MIDDLE WARRIOR CREEK	☐ dd	Salinity (ppt) 0.07	Comments Add MI-FW-QLDC (SCI) 10:45				
Loc		☐ dms						
Field/WIN ID →		☐ Comp	Collection (comp begin or grab)		☒ Eastern	Composite end		Bottle Group(s)
Location ↓	G1TLHR0092	☒ Grab	Date 11/27/18	Time 14:30	Central	Date	Time	
WI	Econfina River @ Cabbage Grove Salt Rd	Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☒ mg/L	Total Res. Chlorine (mg/L)		
Lat		Temp (C) 15.34		pH 7.06	☒ % sat	Sp. Conductance (umho/cm) 164.8		
Loc		☐ dd	Salinity (ppt) 0.08	Comments				
Field/WIN ID →		☐ dms						
Location ↓		☐ Comp	Collection (comp begin or grab)		☒ Eastern	Composite end		Bottle Group(s)
FI	Econfina River 100m upstream of US98	☒ Grab	Date 11/27/18	Time 15:00	Central	Date	Time	
WIN/STORET #		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L	Total Res. Chlorine (mg/L)		
Latitude		Temp (C) 16.150		pH 7.20	☐ % sat	Sp. Conductance (umho/cm) 202.5		
Longitude		☐ dd	Salinity (ppt) 0.10	Comments				
Location		☐ dms						
Field ID		☐ Comp	Collection (comp begin or grab)		☐ Eastern	Composite end		Bottle Group(s)
WIN/STORET #		☐ Grab	Date	Time	Central	Date	Time	
Latitude		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L	Total Res. Chlorine (mg/L)		
Longitude		Temp (C)		pH	☐ % sat	Sp. Conductance (umho/cm)		
Field ID		☐ dd	Salinity (ppt)	Comments				
WIN/STORET #		☐ dms						

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
Eckles/Green	11/27/18 16:00	HD	1		11/27/18 1604

Group: A	Bottle Type: P-250ML-WO-THI ECOLI-18QT	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: P-1L ALKALINITY TURBIDITY W-F W-TSS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: BP-1L CHLSUITE-W	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: P-250ML-WO-THI ENT-24-QT	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: QPCR-P-500ML PCR-FILTER	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: BG-500ML W-E8321-DI W-E8321-MS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
Group: B	Bottle Type: P-125ML W-PO4-F	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab _____
Group: C	Bottle Type: P-1L ALKALINITY TURBIDITY W-CL-IC W-COLOR W-F W-SO4-IC W-TDS W-TSS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab _____

Group: C	Bottle Type: BP-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab
CHLSUITE-W				
Group: C	Bottle Type: P-250ML-WO-THI	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab
ECOLI-18QT				
Group: C	Bottle Type: P-500ML	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab
W-ICP				
W-ICPMS				
Group: C	Bottle Type: P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab
W-NH3				
W-NO2NO3				
W-S-A-TP				
W-TKN				
W-TOC				
Group: C	Bottle Type: P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab
W-PO4-F				
Group: D	Bottle Type: P-1L	# of Bottles: 5	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>TIME 3</u>
ALKALINITY				
TURBIDITY				
W-CL-IC				
W-COLOR				
W-F				
W-SO4-IC				
W-TDS				
W-TSS				
Group: D	Bottle Type: BP-1L	# of Bottles: 5	Preservative: ICE	Enter Number of Bottles Sent to Lab <u>TIME 3</u>
CHLSUITE-W				
Group: D	Bottle Type: P-500ML	# of Bottles: 5	Preservative: HNO3	Enter Number of Bottles Sent to Lab <u>TIME 3</u>
W-ICP				
W-ICPMS				
Group: D	Bottle Type: P-500ML	# of Bottles: 5	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>TIME 3</u>
W-NH3				
W-NO2NO3				
W-S-A-TP				

AA-

HNO3
LOT# NA8197080
EXP: 07/16/2019

7/16/19

SP-

H2SO4
LOT# SA8274050
EXP: 10/01/2019

exp. 10/1/19

Group: D	Bottle Type:	P-500ML	# of Bottles: 5	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>THE 3</u>
	W-TKN					
	W-TOC					

Group: D	Bottle Type:	P-125ML	# of Bottles: 5	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	<u>THE 3</u>
	W-PO4-F					

Date of Request: 13-NOV-2018
 Created By: ECKLES_M On: 13-NOV-2018
 Modified By: JASROTIA_P On: 14-NOV-2018
 Customer: TLH-ROC
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Not Applicable
 Sampling Event: G1 Run 2

Send Coolers To:

Phone: 850-245-7586
 2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles

Program Module Number: 0100
 Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 13-NOV-2018
 Biology Request Reviewed By: JASROTIA_P On: 14-NOV-2018
 Sampling Kit Required: YES Ship on: 21-NOV-2018
 Sampling Kit Shipped: YES On: 21-NOV-2018
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 26-NOV-2018
 Received By:

Send Final Report To:

2600 Blair Stone Rd

 Tallahassee, FL 32399
 Attn: Michael Eckles

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A Bacteria only
 WBID 3518

 Group B Saltwater with Bacteria, Markers, and Tracers
 WBID 3310A

 Group C Freshwater Metals w/bacteria
 WBID 3310

 Group D Freshwater Metals
 WBID 3402 5 sites

 No fedex labels

 Adding an extra bottle for Lab QC for Tracers in B

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ENT-24-QT	Template: DEFAULT	(Enterolert/QT) Enterococci by Enterolert Quanti-Tray method - non-chlorinated water systems
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE

Bottle Group B (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WO-THI	Number of Bottles: 1	Preserved With: ICE
ECOLI-18QT	Template: DEFAULT	(SM 9223 Quanti-Tray) Escherichia coli by Colilert 18 Quanti-Tray method - non-chlorinated water systems
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Silver		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Group D (Water) With 5 Samples:

Bottle Type: P-1L	Number of Bottles: 5	Preserved With: ICE
-------------------	----------------------	---------------------

Bottle Group D (Water) With 5 Samples:

Bottle Type: P-1L		Number of Bottles: 5	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L	
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices	
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices	
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm	
Color (true)			
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	
W-SO ₄ -IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices	
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices	
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	
Bottle Type: BP-1L		Number of Bottles: 5	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Bottle Type: P-500ML		Number of Bottles: 5	Preserved With: HNO ₃
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	
Calcium			
Iron			
Magnesium			
Potassium			
Sodium			
Zinc			
W-ICPMS	Template: PRTY	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	
Arsenic			
Cadmium			
Chromium			
Copper			
Lead			
Nickel			
Silver			
Bottle Type: P-500ML		Number of Bottles: 5	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L	
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L	
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L	
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices	
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices	
Bottle Type: P-125ML		Number of Bottles: 5	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.

