

Chemical Analysis Report

NE-DIST-2019-04-19-02

Florida Department of Environmental Protection
Central Laboratory
2600 Blair Stone Road
Tallahassee, FL 32399-2400
DOH Accreditation E31780

Event Description: **SCI Cedar, and Trout**

Request ID: **RQ-2019-04-08-19**

Customer: **NE-DIST**

Project ID: **SMP**

Send Reports to:
FL Dept. of Environmental Protection
8800 Baymeadows Way West
Suite 100
Jacksonville, FL 32256
Attn: Jeremy Parrish

For additional information please contact
Colin Wright, Ph.D.
Liang-Tsair Lin, Ph.D.
Kerry Tate, Ph.D.
Dr. rer. nat. Bettina Steinbock
Thekkekalathil Chandrasekhar, Ph.D, QA Officer
Phone (850) 245-8085

Certified by: Thekkekalathil Chandrasekhar, Chemist Administrator

Date Certified: 06-MAY-2019 13:42



Case Narrative

Unless otherwise noted, all samples included in this report were received in accordance with protocols referenced in Chapter 62-160, Florida Administrative Code (F.A.C.). Results published in this report pertain only to the samples as submitted to, and received by the laboratory. All times in this report are adjusted to the applicable Eastern Time Zone (EST or EDT).

Results for the following analytical groups are included in this report: Metals, Nutrients and Pesticides.

Scientific notation may be used in reporting very large or small values. Values reported using scientific notation will take the form of the following example: 1.3E+03, which is equivalent to 1.3×10^3 or 1300.

Unless otherwise noted, analytical values for soil and sediment samples are reported on a dry weight basis, and analytical values for waste and tissue samples are reported on a wet weight basis.

Results for TNI accredited tests met requirements established by The NELAC Institute. A double asterisk (**) is used to indicate an analyte/matrix/method for which the laboratory is not TNI accredited by the Florida Department of Health Environmental Laboratory Certification Program or where accreditation for that field of testing is not applicable.

Any significant anomalies or deviations from established protocols are documented in Non-Conformance Reports, which, where appropriate, are included within this analytical report. Additional comments related to specific analytical tests may be included as remarks following the analytical results for each sample. Such comments and remarks are for informational purposes only and are not intended to convey judgement about the usability of the reported data.

A quality control report on the performance of the test method for the submitted samples is included. Uncertainty associated with the analytical results contained in this report can be estimated from the reported quality assurance results and from published quality control acceptance limits for each analytical test. Matrix quality control results (matrix spike recoveries and matrix sample precision) pertain only to the matrix sample tested and do not necessarily reflect test method performance for other samples.

Typical matrix quality control (QC) measurements may include matrix spike recovery, matrix spike duplicate recovery, matrix spike precision and matrix sample precision. Not all matrix QC results may be available or reportable; where they are not an explanation is provided. Typical reasons for unavailable QC results include, but are not limited to, a) insufficient matrix sample to perform some or all QC measurements; b) analyte concentration in the sample replicated was too low for a meaningful measurement of precision and c) analyte concentration in the matrix sample spiked was too high (relative to the amount of analyte spiked) for a meaningful measurement of recovery. Where matrix QC results are unavailable, other method performance metrics (e.g., LCS recovery, LCS precision, surrogate recovery) may be used to assess performance of the method. Comments explaining any missing QC measurements are not intended to convey any adverse conclusions about the quality of the reported data.

Precision is reported as relative percent difference unless otherwise noted.

Quality Control codes as defined below may be used in this report to indicate results that are associated with one or more quality control elements which did not fall within established test method criteria. Such results may be qualified as estimates using a J qualifier as required by 62-160 F.A.C. Explanations are included in the report for any results that were reported as estimates for other reasons.

QC Codes used in this report may include:

- LCS – Recovery for the batch Laboratory Control Sample (LCS) was outside existing control limits;
- MS – Recovery for the batch matrix spike (MS) was outside existing control limits;
- CCV – Recovery for a continuing calibration verification (CCV) standard was outside existing control limits;
- SUR – Recovery of a surrogate (SUR) for associated analytes was outside existing control limits;
- RPD – The precision, measured as relative percent difference (RPD), of batch replicate measurements was outside existing control limits;
- RSD – The precision, measured as relative standard deviation (RSD), of batch replicate measurements was outside existing control limits;
- SMP – Sample - used precision derived from replicate analyses of a sample;

The following data qualifiers are used, where applicable, in this report as specified in 62-160 F.A.C.

- A - Value reported is the mean of two or more determinations.
- B - Results based on colony counts outside the acceptable range.
- I - The reported value is between the laboratory method detection limit and the laboratory practical quantitation limit.
- J - Estimated value and/or the analysis did not meet established quality control criteria.
- K - Actual value is known to be less than value given.
- L - Actual value is known to be greater than value given.
- N - Presumptive evidence of presence of material.
- O - Sampled, but analysis lost or not performed.
- Q - Sample held beyond normal holding time.
- T - Value reported is less than the criterion of detection.
- U - Material was analyzed for but not detected. The reported value is the method detection limit for the sample analyzed.
- V - Analyte was detected in both sample and method blank.
- X - Too few individuals to calculate SCI value.
- Y - The laboratory analysis was from an unpreserved or improperly preserved sample. The data may not be accurate.
- Z - Colonies were too numerous to count (TNTC).

Quality control information from overflow laboratories may not be included in this report. Please refer to the associated report from the overflow laboratory for additional information.

Sample Location: TroutCreek 400m South of West Clevelly Lane Collection Date/Time: 04/18/2019 12:45

Field ID: G2NE1193

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2079861	EPA 180.1 Rev. 2.0	Turbidity	15	A	NTU	P362512	
	EPA 300.0 Rev. 2.1	Chloride	170		mg Cl/L	P362823	
		Sulfate	130		mg SO4/L	P362826	
		Color (true)	44		PCU	P362527	
	SM 2120 B	Total Alkalinity	91		mg CaCO3/L	P363067	
	SM 2540 C-97	TDS	560		mg/L	P363102	
	SM 2540 D-97	TSS	22		mg/L	P363051	
	SM 4500 F-C-97	Fluoride	0.31		mg F/L	P363068	
2079862	EPA 350.1 Rev. 2.0	Ammonia-N	0.025		mg N/L	P363028	
	EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	0.69		mg N/L	P363094	
	EPA 353.2 Rev. 2.0	NO2NO3-N	0.17		mg N/L	P362979	
	EPA 365.1 Rev. 2.0	Total-P	0.16		mg P/L	P362779	
	SM 5310 B-00	Organic Carbon	6.9		mg C/L	P362920	
2079863	EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	0.10		mg P/L	P362539	
2079866	EPA 200.7 Rev. 4.4	Barium	29.4		ug/L	P362675	
		Calcium	46.2		mg/L	P362675	
		Iron	440		ug/L	P362675	
		Magnesium	22.0		mg/L	P362675	
		Potassium	9.0		mg/L	P362675	
		Sodium	112		mg/L	P362675	
		Zinc	5.0	U	ug/L	P362675	
		Aluminum	316		ug/L	P362675	
		Antimony	0.12	I	ug/L	P362675	
		Arsenic	0.41		ug/L	P362675	
	EPA 200.8 Rev. 5.4	Boron**	137		ug/L	P362675	
		Cadmium	0.020	U	ug/L	P362675	
		Chromium	0.40	U	ug/L	P362675	
		Copper	0.55	I	ug/L	P362675	
		Lead	0.53		ug/L	P362675	
		Nickel	0.80	I	ug/L	P362675	
		Selenium	0.20	U	ug/L	P362675	
		Silver	0.010	U	ug/L	P362675	
		Thallium	0.10	U	ug/L	P362675	
		Acetochlor	0.26	U	ng/L	P362397	
2079867	EPA 8270D	Alachlor	0.26	U	ng/L	P362397	
		Ametryn	0.63	UJ	ng/L	P362397	RPD
		Atrazine	48		ng/L	P362397	
		Atrazine Desethyl	6.9		ng/L	P362397	
		Azinphos Methyl	5.3	U	ng/L	P362397	
		Bromacil	0.53	UJ	ng/L	P362397	RPD
		Butylate	0.42	U	ng/L	P362397	
		Chlorpyrifos Ethyl	0.26	U	ng/L	P362397	
		Chlorpyrifos Methyl	0.11	U	ng/L	P362397	

Field ID: G2NE1193

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2079867	EPA 8270D	Cyanazine	3.4	U	ng/L	P362397	
		Demeton	7.4	U	ng/L	P362397	
		Diazinon	0.13	U	ng/L	P362397	
		Dimethenamid**	0.11	U	ng/L	P362397	
		Disulfoton	0.53	U	ng/L	P362397	
		Dithiopyr**	0.27	I	ng/L	P362397	
		EPTC	1.3	U	ng/L	P362397	
		Ethion	0.16	U	ng/L	P362397	
		Ethoprop	0.11	U	ng/L	P362397	
		Fenamiphos	0.53	UJ	ng/L	P362397	LCS, RPD
		Fipronil	2.2		ng/L	P362397	
		Fipronil Desulfinyl**	2.1		ng/L	P362397	
		Fipronil Sulfide	2.8		ng/L	P362397	
		Fipronil Sulfone	1.6		ng/L	P362397	
		Fonofos	0.21	U	ng/L	P362397	
		Hexazinone	0.53	UJ	ng/L	P362397	LCS, MS, RPD
		Malathion	0.37	U	ng/L	P362397	
		Metalaxyl	0.32	UJ	ng/L	P362397	LCS, RPD
		Metolachlor	0.53	U	ng/L	P362397	
		Metribuzin	0.79	UJ	ng/L	P362397	CCV
		Mevinphos	0.53	UJ	ng/L	P362397	LCS, RPD
		Molinate	0.32	U	ng/L	P362397	
		Norflurazon	0.53	U	ng/L	P362397	
		Oxadiazon**	7.1		ng/L	P362397	
		Parathion Ethyl	0.26	U	ng/L	P362397	
		Parathion Methyl	0.58	U	ng/L	P362397	
		Pendimethalin	1.1	U	ng/L	P362397	
		Phorate	0.26	U	ng/L	P362397	
		Prodiamine**	0.19	U	ng/L	P362397	
		Prometon	0.95	UJ	ng/L	P362397	LCS
		Prometryn	0.21	UJ	ng/L	P362397	LCS, RPD
		Simazine	11		ng/L	P362397	
		Tebuconazole**	3.3	J	ng/L	P362397	LCS, RPD
		Terbufos	0.11	U	ng/L	P362397	
		Terbuthylazine	0.45	U	ng/L	P362397	

Ref. Method and Comment:

SM 2540 D-97: Batch relative percent difference is unavailable because of low analyte concentration in the QC sample.

EPA 8270D: MS accuracies for atrazine, simazine, metribuzin, and bromacil not assessed due to high content of these parameters in the sample spiked. Refer to the narrative for an explanation of QC Codes.

Sample Location: TroutCreek 400m South of West Clevelly Lane Collection Date/Time: 04/18/2019 12:45

Field ID: G2NE1193

Matrix: W-SURF-FRH

Sample ID	Ref. Method	Component	Result	Code	Units	Batch ID	QC Codes
2079870	EPA 8321B	2,4-D	0.0099		ug/L	P362343	
		Acesulfame K**	0.12	I	ug/L	P362544	MS
		AMPA**	0.24	I	ug/L	P362544	
		Sucralose**	41		ug/L	P362544	
		Acetaminophen**	0.0080	U	ug/L	P362343	
		Endothall**	0.25	U	ug/L	P362544	
		Glufosinate**	0.10	U	ug/L	P362544	
		Bentazon	0.018		ug/L	P362343	
		Glyphosate**	0.10	U	ug/L	P362544	
		Carbamazepine**	0.059		ug/L	P362343	
		Diuron	0.0090		ug/L	P362343	
		Fenuron	0.022	I	ug/L	P362343	
		Fluridone**	0.015		ug/L	P362343	
		Imazapyr**	0.096		ug/L	P362343	
		Hydrocodone**	0.0059	I	ug/L	P362343	
		Ibuprofen**	0.020	U	ug/L	P362343	
		Imidacloprid	0.027		ug/L	P362343	MS
		Linuron	0.0040	U	ug/L	P362343	
		MCPP	0.011		ug/L	P362343	
		Naproxen**	0.0080	U	ug/L	P362343	
		Primidone**	0.060		ug/L	P362343	
		Pyraclostrobin**	0.0020	U	ug/L	P362343	
		Triclopyr**	0.0040	U	ug/L	P362343	

Quality Assurance Report Method Blank Results

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P362512

Component	Result	Code	Units
Turbidity	0.10	U	NTU

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P362675

Component	Result	Code	Units
Barium	1.0	U	ug/L
Calcium	0.075	U	mg/L
Iron	30	U	ug/L
Magnesium	0.040	U	mg/L
Potassium	0.30	U	mg/L
Sodium	0.50	U	mg/L
Zinc	5.0	U	ug/L

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P362675

Component	Result	Code	Units
Aluminum	5.0	U	ug/L
Antimony	0.050	U	ug/L
Arsenic	0.050	U	ug/L
Boron	2.0	U	ug/L
Cadmium	0.020	U	ug/L
Chromium	0.40	U	ug/L
Copper	0.40	U	ug/L
Lead	0.20	U	ug/L
Nickel	0.50	U	ug/L
Selenium	0.20	U	ug/L
Silver	0.010	U	ug/L
Thallium	0.10	U	ug/L

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P362823

Component	Result	Code	Units
Chloride	0.20	U	mg Cl/L

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P362826

Component	Result	Code	Units
Sulfate	0.20	U	mg SO4/L

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P363028

Component	Result	Code	Units
Ammonia-N	0.002	U	mg N/L

Quality Assurance Report Method Blank Results

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P363094

Component	Result	Code	Units
Kjeldahl Nitrogen	0.080	U	mg N/L

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P362979

Component	Result	Code	Units
NO2NO3-N	0.004	U	mg N/L

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P362779

Component	Result	Code	Units
Total-P	0.002	U	mg P/L

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P362539

Component	Result	Code	Units
O-Phosphate-P	0.004	U	mg P/L

Reference Method: EPA 8270D
Batch ID: P362397

Component	Result	Code	Units
Acetochlor	0.25	U	ng/L
Alachlor	0.25	U	ng/L
Ametryn	0.60	U	ng/L
Atrazine	0.25	U	ng/L
Atrazine Desethyl	1.5	U	ng/L
Azinphos Methyl	5.0	U	ng/L
Bromacil	0.50	U	ng/L
Butylate	0.40	U	ng/L
Chlorpyrifos Ethyl	0.25	U	ng/L
Chlorpyrifos Methyl	0.10	U	ng/L
Cyanazine	3.2	U	ng/L
Demeton	7.0	U	ng/L
Diazinon	0.12	U	ng/L
Dimethenamid	0.10	U	ng/L
Disulfoton	0.50	U	ng/L
Dithiopyr	0.10	U	ng/L
EPTC	1.2	U	ng/L
Ethion	0.15	U	ng/L
Ethoprop	0.10	U	ng/L
Fenamiphos	0.50	U	ng/L
Fipronil	0.25	U	ng/L
Fipronil Desulfinyl	0.12	U	ng/L
Fipronil Sulfide	0.15	U	ng/L
Fipronil Sulfone	0.15	U	ng/L
Fonofos	0.20	U	ng/L
Hexazinone	0.50	U	ng/L
Malathion	0.35	U	ng/L
Metalaxyl	0.30	U	ng/L

Quality Assurance Report

Method Blank Results

Reference Method: EPA 8270D
Batch ID: P362397

Component	Result	Code	Units
Metolachlor	0.50	U	ng/L
Metribuzin	0.75	U	ng/L
Mevinphos	0.50	U	ng/L
Molinate	0.30	U	ng/L
Norflurazon	0.50	U	ng/L
Oxadiazon	0.10	U	ng/L
Parathion Ethyl	0.25	U	ng/L
Parathion Methyl	0.55	U	ng/L
Pendimethalin	1.0	U	ng/L
Phorate	0.25	U	ng/L
Prodiamine	0.18	U	ng/L
Prometon	0.90	U	ng/L
Prometryn	0.20	U	ng/L
Simazine	0.50	U	ng/L
Tebuconazole	0.50	U	ng/L
Terbufos	0.10	U	ng/L
Terbutylazine	0.42	U	ng/L

Reference Method: EPA 8321B
Batch ID: P362343

Component	Result	Code	Units
2,4-D	0.0020	U	ug/L
Acetaminophen	0.0080	U	ug/L
Bentazon	8.0E-04	U	ug/L
Carbamazepine	8.0E-04	U	ug/L
Diuron	0.0020	U	ug/L
Fenuron	0.016	U	ug/L
Fluridone	8.0E-04	U	ug/L
Hydrocodone	0.0020	U	ug/L
Ibuprofen	0.020	U	ug/L
Imazapyr	0.0040	U	ug/L
Imidacloprid	0.0020	U	ug/L
Linuron	0.0040	U	ug/L
MCPP	0.0020	U	ug/L
Naproxen	0.0080	U	ug/L
Primidone	0.0040	U	ug/L
Pyraclostrobin	0.0020	U	ug/L
Triclopyr	0.0040	U	ug/L

Reference Method: EPA 8321B
Batch ID: P362544

Component	Result	Code	Units
Acesulfame K	0.10	U	ug/L
AMPA	0.10	U	ug/L
Endothall	0.25	U	ug/L
Glufosinate	0.10	U	ug/L
Glyphosate	0.10	U	ug/L
Sucralose	0.010	U	ug/L

Quality Assurance Report

Method Blank Results

Reference Method: SM 2120 B
Batch ID: P362527

Component	Result	Code	Units
Color (true)	2.5	U	PCU

Reference Method: SM 2320 B-97
Batch ID: P363067

Component	Result	Code	Units
Total Alkalinity	0.65	U	mg CaCO ₃ /L

Reference Method: SM 2540 C-97
Batch ID: P363102

Component	Result	Code	Units
TDS	15	U	mg/L

Reference Method: SM 2540 D-97
Batch ID: P363051

Component	Result	Code	Units
TSS	2	U	mg/L

Reference Method: SM 4500 F-C-97
Batch ID: P363068

Component	Result	Code	Units
Fluoride	0.035	U	mg F/L

Reference Method: SM 5310 B-00
Batch ID: P362920

Component	Result	Code	Units
Organic Carbon	0.50	U	mg C/L

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P362675

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Barium	97.4		P	85 - 115
Calcium	103		P	85 - 115
Iron	105		P	85 - 115
Magnesium	102		P	85 - 115
Potassium	98.9		P	85 - 115
Sodium	101		P	85 - 115
Zinc	99.1		P	85 - 115

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P362675

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Aluminum	98.8		P	85 - 115
Antimony	100		P	85 - 115
Arsenic	105		P	85 - 115
Boron	99.9		P	85 - 115
Cadmium	102		P	85 - 115
Chromium	95.2		P	85 - 115
Copper	103		P	85 - 115
Lead	93.3		P	85 - 115
Nickel	103		P	85 - 115
Selenium	102		P	85 - 115
Silver	97.8		P	85 - 115
Thallium	103		P	85 - 115

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P362823

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Chloride	101		P	90 - 110

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P362826

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Sulfate	101		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
Batch ID: P363028

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Ammonia-N	99.2		P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
Batch ID: P363094

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Kjeldahl Nitrogen	93.7		P	90 - 110

Quality Assurance Report Laboratory Control Sample Accuracy

Reference Method: EPA 353.2 Rev. 2.0
Batch ID: P362979

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
NO2NO3-N	98.5		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
Batch ID: P362779

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total-P	98.4		P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
Batch ID: P362539

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
O-Phosphate-P	102		P	90 - 110

Reference Method: EPA 8270D
Batch ID: P362397

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Acetochlor	104	101	P/P	71 - 121
Alachlor	102	99.7	P/P	72 - 119
Ametryn	47.4	75.9	P/P	47 - 144
Atrazine	96.6	97.2	P/P	75 - 123
Atrazine Desethyl	52.1	49.3	P/P	45 - 133
Azinphos Methyl	101	96.4	P/P	66 - 165
Bromacil	62.2	43.8	P/P	43 - 123
Butylate	58.1	58.5	P/P	27 - 83.0
Chlorpyrifos Ethyl	98.7	97.0	P/P	70 - 117
Chlorpyrifos Methyl	90.9	84.9	P/P	71 - 120
Cyanazine	72.2	70.5	P/P	34 - 264
Demeton	61.0	65.0	P/P	41 - 122
Diazinon	98.2	94.8	P/P	70 - 127
Dimethenamid	103	99.2	P/P	66 - 123
Disulfoton	84.5	81.5	P/P	56 - 127
Dithiopyr	107	104	P/P	67 - 125
EPTC	61.0	58.3	P/P	24 - 84.0
Ethion	103	104	P/P	53 - 132
Ethoprop	88.1	84.3	P/P	57 - 117
Fenamiphos	32.9	15.2	F/F	55 - 136
Fipronil	103	91.4	P/P	64 - 126
Fipronil Desulfinyl	101	94.3	P/P	47 - 114
Fipronil Sulfide	102	96.2	P/P	57 - 120
Fipronil Sulfone	97.7	86.9	P/P	52 - 115
Fonofos	82.4	82.7	P/P	61 - 121
Hexazinone	48.4	16.9	F/F	62 - 131
Malathion	101	97.5	P/P	67 - 126
Metalaxyl	13.7	9.41	F/F	54 - 128
Metolachlor	104	100	P/P	71 - 118
Metribuzin	73.1	72.4	P/P	42 - 221
Mevinphos	51.2	26.7	P/F	45 - 114
Molinate	67.5	70.4	P/P	33 - 91.0
Norflurazon	92.6	81.4	P/P	60 - 123
Oxadiazon	110	109	P/P	66 - 121

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: EPA 8270D
Batch ID: P362397

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Parathion Ethyl	90.2	89.3	P/P	73 - 111
Parathion Methyl	91.2	89.4	P/P	74 - 126
Pendimethalin	103	109	P/P	63 - 131
Phorate	73.7	72.0	P/P	54 - 115
Prodiamine	115	114	P/P	38 - 140
Prometon	22.6	27.6	F/F	61 - 120
Prometryn	59.8	88.9	F/P	62 - 126
Simazine	101	92.6	P/P	75 - 126
Tebuconazole	56.4	14.6	P/F	21 - 115
Terbufos	85.6	83.3	P/P	65 - 116
Terbuthylazine	100	97.6	P/P	73 - 117

Reference Method: EPA 8321B
Batch ID: P362343

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2,4-D	86.2		P	40 - 150
Acetaminophen	83.1		P	30 - 150
Bentazon	83.4		P	30 - 150
Carbamazepine	81.0		P	40 - 150
Diuron	82.1		P	40 - 150
Fenuron	93.8		P	40 - 150
Fluridone	120		P	40 - 150
Hydrocodone	110		P	40 - 150
Ibuprofen	83.3		P	40 - 150
Imazapyr	85.5		P	40 - 150
Imidacloprid	97.9		P	40 - 150
Linuron	75.2		P	40 - 150
MCPP	97.9		P	40 - 150
Naproxen	76.6		P	40 - 150
Primidone	95.6		P	40 - 150
Pyraclostrobin	70.0		P	40 - 150
Triclopyr	75.1		P	40 - 150

Reference Method: EPA 8321B
Batch ID: P362544

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Acesulfame K	110		P	40 - 150
AMPA	120		P	40 - 150
Endothall	118		P	40 - 150
Glufosinate	128		P	40 - 150
Glyphosate	125		P	40 - 140
Sucralose	98.7		P	40 - 150

Reference Method: SM 2120 B
Batch ID: P362527

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Color (true)	104		P	85 - 115

Quality Assurance Report

Laboratory Control Sample Accuracy

Reference Method: SM 2320 B-97
Batch ID: P363067

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Total Alkalinity	102		P	98 - 106

Reference Method: SM 4500 F-C-97
Batch ID: P363068

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Fluoride	96.9		P	92 - 103

Reference Method: SM 5310 B-00
Batch ID: P362920

Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
Organic Carbon	90.8		P	85 - 115

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P362675

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079738	Barium	98.1		P	80 - 120
2079738	Calcium	106		P	80 - 120
2079738	Iron	106		P	80 - 120
2079738	Magnesium	110		P	80 - 120
2079738	Potassium	102		P	80 - 120
2079738	Sodium	103		P	80 - 120
2079738	Zinc	99.8		P	80 - 120
2079859	Barium	94.1	94.3	P/P	80 - 120
2079859	Calcium	99.2		P	80 - 120
2079859	Iron	106	104	P/P	80 - 120
2079859	Magnesium	104		P	80 - 120
2079859	Potassium	105		P	80 - 120
2079859	Sodium	97.2		P	80 - 120
2079859	Zinc	98.4	97.8	P/P	80 - 120

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P362675

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079738	Aluminum	96.5		P	80 - 120
2079738	Antimony	101		P	80 - 120
2079738	Arsenic	105		P	80 - 120
2079738	Boron	99.4		P	80 - 120
2079738	Cadmium	102		P	80 - 120
2079738	Chromium	98.4		P	80 - 120
2079738	Copper	104		P	80 - 120
2079738	Lead	93.6		P	80 - 120
2079738	Nickel	105		P	80 - 120
2079738	Selenium	105		P	80 - 120
2079738	Silver	97.3		P	80 - 120
2079738	Thallium	106		P	80 - 120
2079859	Aluminum	97.4	96.0	P/P	80 - 120
2079859	Antimony	105	102	P/P	80 - 120
2079859	Arsenic	110	110	P/P	80 - 120
2079859	Boron	95.0	92.0	P/P	80 - 120
2079859	Cadmium	105	103	P/P	80 - 120
2079859	Chromium	95.6	96.1	P/P	80 - 120
2079859	Copper	99.8	99.1	P/P	80 - 120
2079859	Lead	94.7	93.4	P/P	80 - 120
2079859	Nickel	103	103	P/P	80 - 120
2079859	Selenium	106	104	P/P	80 - 120
2079859	Silver	96.4	95.7	P/P	80 - 120
2079859	Thallium	107	107	P/P	80 - 120

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P362823

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079691	Chloride	100		P	90 - 110
2079757	Chloride	102		P	90 - 110

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 300.0 Rev. 2.1
 Batch ID: P362826

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079691	Sulfate	101		P	90 - 110
2079757	Sulfate	101		P	90 - 110

Reference Method: EPA 350.1 Rev. 2.0
 Batch ID: P363028

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079856	Ammonia-N	101	101	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0
 Batch ID: P363094

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079862	Kjeldahl Nitrogen	102	109	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0
 Batch ID: P362979

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079760	NO2NO3-N	97.0	96.5	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0
 Batch ID: P362779

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079769	Total-P	93.2	96.8	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0 dissolved
 Batch ID: P362539

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079693	O-Phosphate-P	98.5	97.7	P/P	90 - 110

Reference Method: EPA 8270D
 Batch ID: P362397

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2078905	Acetochlor	93.2	94.2	P/P	63 - 129
2078905	Alachlor	89.9	89.6	P/P	65 - 127
2078905	Ametryn	92.4	94.3	P/P	40 - 164
2078905	Atrazine Desethyl	63.2	58.8	P/P	14 - 157
2078905	Azinphos Methyl	94.5	90.1	P/P	49 - 180
2078905	Butylate	46.5	47.6	P/P	10 - 94.0
2078905	Chlorpyrifos Ethyl	97.4	98.2	P/P	58 - 123
2078905	Chlorpyrifos Methyl	92.9	91.1	P/P	58 - 125
2078905	Cyanazine	108	97.0	P/P	24 - 253
2078905	Demeton	85.6	82.4	P/P	25 - 149
2078905	Diazinon	98.9	98.1	P/P	59 - 144
2078905	Dimethenamid	93.0	91.7	P/P	46 - 139
2078905	Disulfoton	90.9	84.6	P/P	54 - 132
2078905	Dithiopyr	95.9	96.5	P/P	64 - 130
2078905	EPTC	48.7	51.9	P/P	10 - 92.0

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8270D
Batch ID: P362397

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2078905	Ethion	101	98.2	P/P	30 - 148
2078905	Ethoprop	91.4	90.1	P/P	50 - 130
2078905	Fenamiphos	89.0	92.4	P/P	49 - 142
2078905	Fipronil	80.1	75.2	P/P	46 - 140
2078905	Fipronil Desulfinyl	68.7	66.3	P/P	30 - 121
2078905	Fipronil Sulfide	71.4	65.1	P/P	31 - 136
2078905	Fipronil Sulfone	52.7	45.4	P/P	16 - 136
2078905	Fonofos	93.1	91.2	P/P	55 - 129
2078905	Hexazinone	100	172	P/F	56 - 141
2078905	Malathion	95.6	92.3	P/P	56 - 135
2078905	Metalaxyl	90.4	82.6	P/P	54 - 135
2078905	Metolachlor	90.3	92.5	P/P	51 - 140
2078905	Mevinphos	77.1	83.1	P/P	33 - 131
2078905	Molinate	65.9	66.6	P/P	14 - 98.0
2078905	Norflurazon	77.6	72.3	P/P	34 - 136
2078905	Oxadiazon	94.8	94.8	P/P	67 - 116
2078905	Parathion Ethyl	95.5	92.5	P/P	66 - 118
2078905	Parathion Methyl	99.7	96.5	P/P	64 - 136
2078905	Pendimethalin	120	119	P/P	59 - 144
2078905	Phorate	82.3	79.2	P/P	42 - 130
2078905	Prodiamine	124	123	P/P	42 - 148
2078905	Prometon	93.7	121	P/P	59 - 134
2078905	Prometryn	95.0	92.9	P/P	54 - 135
2078905	Tebuconazole	78.9	75.2	P/P	10 - 131
2078905	Terbufos	99.5	92.6	P/P	57 - 131
2078905	Terbutylazine	96.7	94.8	P/P	68 - 125

Reference Method: EPA 8321B
Batch ID: P362343

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079441	2,4-D	98.0	81.8	P/P	40 - 150
2079441	Acetaminophen	80.9	79.6	P/P	30 - 150
2079441	Bentazon	56.9	52.0	P/P	30 - 150
2079441	Carbamazepine	92.7	85.8	P/P	40 - 150
2079441	Diuron	72.6	71.6	P/P	40 - 150
2079441	Fenuron	116	111	P/P	40 - 150
2079441	Fluridone	117	122	P/P	40 - 150
2079441	Hydrocodone	107	102	P/P	40 - 150
2079441	Ibuprofen	87.2	78.2	P/P	40 - 150
2079441	Imazapyr	92.8	85.9	P/P	40 - 150
2079441	Imidacloprid	154	122	F/P	40 - 150
2079441	Linuron	79.6	81.1	P/P	40 - 150
2079441	MCP	107	99.0	P/P	40 - 150
2079441	Naproxen	62.2	66.5	P/P	40 - 150
2079441	Primidone	89.6	90.7	P/P	40 - 150
2079441	Pyraclostrobin	65.5	68.2	P/P	40 - 150
2079441	Triclopyr	75.4	62.5	P/P	40 - 150

Quality Assurance Report Matrix Spike Accuracy

Reference Method: EPA 8321B
Batch ID: P362544

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079736	Acesulfame K	187	184	F/F	40 - 150
2079736	AMPA	134	131	P/P	40 - 150
2079736	Endothall	97.9	96.2	P/P	40 - 150
2079736	Glufosinate	130	128	P/P	40 - 150
2079736	Glyphosate	118	117	P/P	40 - 140
2079736	Sucralose	102	104	P/P	40 - 150

Reference Method: SM 4500 F-C-97
Batch ID: P363068

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079855	Fluoride	96.5	97.2	P/P	89 - 106

Reference Method: SM 5310 B-00
Batch ID: P362920

Spiked Sample	Component	% Rec.1	% Rec.2	Pass/Fail	Control Limits
2079856	Organic Carbon	88.8	87.6	P/P	85 - 115

Quality Assurance Report Precision

Reference Method: EPA 180.1 Rev. 2.0
Batch ID: P362512

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079861	Turbidity	2.03	Sample	P	0 - 20

Reference Method: EPA 200.7 Rev. 4.4
Batch ID: P362675

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079859	Barium	0.190	Spike	P	0 - 20
2079859	Calcium	1.19	Spike	P	0 - 20
2079859	Iron	1.76	Spike	P	0 - 20
2079859	Magnesium	3.09	Spike	P	0 - 20
2079859	Potassium	1.61	Spike	P	0 - 20
2079859	Sodium	0.409	Spike	P	0 - 20
2079859	Zinc	0.605	Spike	P	0 - 20

Reference Method: EPA 200.8 Rev. 5.4
Batch ID: P362675

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079859	Aluminum	1.41	Spike	P	0 - 20
2079859	Antimony	2.34	Spike	P	0 - 20
2079859	Arsenic	0.444	Spike	P	0 - 20
2079859	Boron	2.17	Spike	P	0 - 20
2079859	Cadmium	1.98	Spike	P	0 - 20
2079859	Chromium	0.552	Spike	P	0 - 20
2079859	Copper	0.683	Spike	P	0 - 20
2079859	Lead	1.35	Spike	P	0 - 20
2079859	Nickel	0.769	Spike	P	0 - 20
2079859	Selenium	1.06	Spike	P	0 - 20
2079859	Silver	0.800	Spike	P	0 - 20
2079859	Thallium	0.630	Spike	P	0 - 20

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P362823

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079691	Chloride	0.149	Sample	P	0 - 20

Reference Method: EPA 300.0 Rev. 2.1
Batch ID: P362826

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079691	Sulfate	0.313	Sample	P	0 - 20

Quality Assurance Report Precision

Reference Method: EPA 350.1 Rev. 2.0
 Batch ID: P363028

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079856	Ammonia-N	0.606	Spike	P	0 - 20

Reference Method: EPA 351.2 Rev. 2.0
 Batch ID: P363094

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079862	Kjeldahl Nitrogen	4.11	Spike	P	0 - 20

Reference Method: EPA 353.2 Rev. 2.0
 Batch ID: P362979

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079760	NO2NO3-N	0.265	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0
 Batch ID: P362779

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079769	Total-P	2.03	Spike	P	0 - 20

Reference Method: EPA 365.1 Rev. 2.0 dissolved
 Batch ID: P362539

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079693	O-Phosphate-P	0.758	Spike	P	0 - 20

Reference Method: EPA 8270D
 Batch ID: P362397

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2078905	Acetochlor	1.11	Spike	P	0 - 30
2078905	Alachlor	0.334	Spike	P	0 - 30
2078905	Ametryn	1.55	Spike	P	0 - 30
2078905	Atrazine	1.89	Spike	P	0 - 30
2078905	Atrazine Desethyl	5.13	Spike	P	0 - 30
2078905	Azinphos Methyl	4.78	Spike	P	0 - 30
2078905	Bromacil	4.83	Spike	P	0 - 30
2078905	Butylate	2.38	Spike	P	0 - 30
2078905	Chlorpyrifos Ethyl	0.884	Spike	P	0 - 30
2078905	Chlorpyrifos Methyl	1.94	Spike	P	0 - 30
2078905	Cyanazine	10.9	Spike	P	0 - 30
2078905	Demeton	3.78	Spike	P	0 - 30
2078905	Diazinon	0.864	Spike	P	0 - 30
2078905	Dimethenamid	1.46	Spike	P	0 - 30
2078905	Disulfoton	7.18	Spike	P	0 - 30
2078905	Dithiopyr	0.549	Spike	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8270D
Batch ID: P362397

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2078905	EPTC	6.41	Spike	P	0 - 30
2078905	Ethion	2.36	Spike	P	0 - 30
2078905	Ethoprop	1.10	Spike	P	0 - 30
2078905	Fenamiphos	3.79	Spike	P	0 - 30
2078905	Fipronil	5.70	Spike	P	0 - 30
2078905	Fipronil Desulfinyl	2.99	Spike	P	0 - 30
2078905	Fipronil Sulfide	7.15	Spike	P	0 - 30
2078905	Fipronil Sulfone	8.46	Spike	P	0 - 30
2078905	Fonofos	2.08	Spike	P	0 - 30
2078905	Hexazinone	46.0	Spike	F	0 - 30
2078905	Malathion	3.47	Spike	P	0 - 30
2078905	Metalaxyl	8.69	Spike	P	0 - 30
2078905	Metolachlor	1.40	Spike	P	0 - 30
2078905	Metribuzin	7.82	Spike	P	0 - 30
2078905	Mevinphos	7.50	Spike	P	0 - 30
2078905	Molinate	1.09	Spike	P	0 - 30
2078905	Norflurazon	7.07	Spike	P	0 - 30
2078905	Oxadiazon	0.00932	Spike	P	0 - 30
2078905	Parathion Ethyl	3.23	Spike	P	0 - 30
2078905	Parathion Methyl	3.21	Spike	P	0 - 30
2078905	Pendimethalin	1.32	Spike	P	0 - 30
2078905	Phorate	3.83	Spike	P	0 - 30
2078905	Prodiamine	0.994	Spike	P	0 - 30
2078905	Prometon	25.4	Spike	P	0 - 30
2078905	Prometryn	2.21	Spike	P	0 - 30
2078905	Simazine	0.137	Spike	P	0 - 30
2078905	Tebuconazole	4.00	Spike	P	0 - 30
2078905	Terbufos	7.11	Spike	P	0 - 30
2078905	Terbutylazine	2.03	Spike	P	0 - 30
LFB	Acetochlor	3.46	LCS	P	0 - 30
LFB	Alachlor	2.74	LCS	P	0 - 30
LFB	Ametryn	46.1	LCS	F	0 - 30
LFB	Atrazine	0.615	LCS	P	0 - 30
LFB	Atrazine Desethyl	5.45	LCS	P	0 - 30
LFB	Azinphos Methyl	4.94	LCS	P	0 - 30
LFB	Bromacil	34.7	LCS	F	0 - 30
LFB	Butylate	0.548	LCS	P	0 - 30
LFB	Chlorpyrifos Ethyl	1.69	LCS	P	0 - 30
LFB	Chlorpyrifos Methyl	6.83	LCS	P	0 - 30
LFB	Cyanazine	2.41	LCS	P	0 - 30
LFB	Demeton	6.40	LCS	P	0 - 30
LFB	Diazinon	3.46	LCS	P	0 - 30
LFB	Dimethenamid	3.42	LCS	P	0 - 30
LFB	Disulfoton	3.61	LCS	P	0 - 30
LFB	Dithiopyr	2.59	LCS	P	0 - 30
LFB	EPTC	4.42	LCS	P	0 - 30
LFB	Ethion	1.22	LCS	P	0 - 30
LFB	Ethoprop	4.42	LCS	P	0 - 30
LFB	Fenamiphos	74.0	LCS	F	0 - 30
LFB	Fipronil	12.0	LCS	P	0 - 30
LFB	Fipronil Desulfinyl	6.75	LCS	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8270D
Batch ID: P362397

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
LFB	Fipronil Sulfide	5.39	LCS	P	0 - 30
LFB	Fipronil Sulfone	11.8	LCS	P	0 - 30
LFB	Fonofos	0.370	LCS	P	0 - 30
LFB	Hexazinone	96.3	LCS	F	0 - 30
LFB	Malathion	3.35	LCS	P	0 - 30
LFB	Metalaxyl	37.0	LCS	F	0 - 30
LFB	Metolachlor	3.58	LCS	P	0 - 30
LFB	Metribuzin	0.906	LCS	P	0 - 30
LFB	Mevinphos	63.1	LCS	F	0 - 30
LFB	Molinate	4.11	LCS	P	0 - 30
LFB	Norflurazon	12.9	LCS	P	0 - 30
LFB	Oxadiazon	1.35	LCS	P	0 - 30
LFB	Parathion Ethyl	1.04	LCS	P	0 - 30
LFB	Parathion Methyl	2.08	LCS	P	0 - 30
LFB	Pendimethalin	6.04	LCS	P	0 - 30
LFB	Phorate	2.36	LCS	P	0 - 30
LFB	Prodiamine	0.668	LCS	P	0 - 30
LFB	Prometon	20.0	LCS	P	0 - 30
LFB	Prometryn	39.2	LCS	F	0 - 30
LFB	Simazine	8.61	LCS	P	0 - 30
LFB	Tebuconazole	118	LCS	F	0 - 30
LFB	Terbufos	2.69	LCS	P	0 - 30
LFB	Terbuthylazine	2.59	LCS	P	0 - 30

Reference Method: EPA 8321B
Batch ID: P362343

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079441	2,4-D	16.6	Spike	P	0 - 30
2079441	Acetaminophen	1.65	Spike	P	0 - 30
2079441	Bentazon	5.47	Spike	P	0 - 30
2079441	Carbamazepine	7.29	Spike	P	0 - 30
2079441	Diuron	1.36	Spike	P	0 - 30
2079441	Fenuron	3.79	Spike	P	0 - 30
2079441	Fluridone	2.62	Spike	P	0 - 30
2079441	Hydrocodone	4.57	Spike	P	0 - 30
2079441	Ibuprofen	10.9	Spike	P	0 - 30
2079441	Imazapyr	4.83	Spike	P	0 - 30
2079441	Imidacloprid	19.3	Spike	P	0 - 30
2079441	Linuron	1.78	Spike	P	0 - 30
2079441	MCP	7.34	Spike	P	0 - 30
2079441	Naproxen	6.69	Spike	P	0 - 30
2079441	Primidone	1.16	Spike	P	0 - 30
2079441	Pyraclostrobin	4.04	Spike	P	0 - 30
2079441	Triclopyr	18.6	Spike	P	0 - 30

Quality Assurance Report Precision

Reference Method: EPA 8321B
Batch ID: P362544

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079736	Acesulfame K	1.51	Spike	P	0 - 30
2079736	AMPA	2.13	Spike	P	0 - 30
2079736	Endothall	1.79	Spike	P	0 - 30
2079736	Glufosinate	1.06	Spike	P	0 - 30
2079736	Glyphosate	0.940	Spike	P	0 - 30
2079736	Sucralose	2.24	Spike	P	0 - 30

Reference Method: SM 2120 B
Batch ID: P362527

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079756	Color (true)	0.517	Sample	P	0 - 20

Reference Method: SM 2320 B-97
Batch ID: P363067

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079855	Total Alkalinity	0.961	Sample	P	0 - 2.8

Reference Method: SM 2540 C-97
Batch ID: P363102

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079855	TDS	0.962	Sample	P	0 - 10

Reference Method: SM 4500 F-C-97
Batch ID: P363068

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079855	Fluoride	0.467	Spike	P	0 - 2.5

Reference Method: SM 5310 B-00
Batch ID: P362920

Replicated Lab Sample	Component	% RSD/RPD	Sample/Spike/LCS*	Pass/Fail	Control Limits
2079856	Organic Carbon	0.899	Spike	P	0 - 20

* Sample, spike and/or laboratory control sample precision (LCS) is reported.
Replicate spike precision may be reported when sample results are below quantifiable levels.

Quality Assurance Report Surrogates

Lab Sample ID: 2079867
Field Sample ID: G2NE1193

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8270D	Simazine-d10	102	P	68 - 130
EPA 8270D	Terbufos-d10	87.8	P	61 - 136

Lab Sample ID: 2079870
Field Sample ID: G2NE1193

Reference Method	Surrogate	% Rec.	Pass/Fail	Control Limits
EPA 8321B	2,4-D-d3	72.0	P	30 - 160
EPA 8321B	Acetaminophen-d4	89.6	P	30 - 160
EPA 8321B	Carbamazepine-d10	118	P	30 - 160
EPA 8321B	Diuron-d6	82.0	P	30 - 160
EPA 8321B	Endothall-d6	93.4	P	30 - 160
EPA 8321B	Endothall-d6	93.4	P	30 - 160
EPA 8321B	Glyphosate 13C 15N	73.4	P	30 - 160
EPA 8321B	Glyphosate 13C 15N	73.4	P	30 - 160
EPA 8321B	Ibuprofen-d3	92.6	P	30 - 160
EPA 8321B	Primidone-d5	89.8	P	30 - 160
EPA 8321B	Sucralose-d6	102	P	30 - 160
EPA 8321B	Sucralose-d6	102	P	30 - 160

Quality Assurance Report Calibration Verification

Reference Method: EPA 180.1 Rev. 2.0

Run ID: A90854

Included Lab Sample IDs: 2079861

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Turbidity	99.0	100	P/P	95 - 105

Reference Method: SM 2120 B

Run ID: A90857

Included Lab Sample IDs: 2079861

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Color (true)	103	103	P/P	90 - 115

Reference Method: EPA 365.1 Rev. 2.0 dissolved

Run ID: A90859

Included Lab Sample IDs: 2079863

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
O-Phosphate-P	99.0	98.7	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A90917

Included Lab Sample IDs: 2079870

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
AMPA	128	105	P/P	60 - 160
Glufosinate	117	112	P/P	60 - 160
Glyphosate	115	109	P/P	60 - 160

Reference Method: EPA 8321B

Run ID: A90953

Included Lab Sample IDs: 2079870

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
2,4-D	78.3	96.6	P/P	50 - 150
Acetaminophen	114	101	P/P	60 - 160
Bentazon	101	85.0	P/P	50 - 160
Carbamazepine	109	92.2	P/P	60 - 150
Diuron	102	104	P/P	60 - 150
Fenuron	104	107	P/P	60 - 150
Fluridone	97.5	104	P/P	60 - 160
Hydrocodone	102	96.9	P/P	60 - 150
Ibuprofen	107	108	P/P	50 - 160
Imazapyr	102	91.5	P/P	50 - 150
Imidacloprid	109	92.6	P/P	60 - 150
Linuron	100	108	P/P	60 - 150
MCPP	94.8	90.9	P/P	50 - 150
Naproxen	133	82.8	P/P	50 - 160
Primidone	101	113	P/P	60 - 150
Pyraclostrobin	96.3	96.1	P/P	60 - 150
Triclopyr	97.9	98.8	P/P	50 - 150

Quality Assurance Report Calibration Verification

Reference Method: EPA 300.0 Rev. 2.1

Run ID: A90961

Included Lab Sample IDs: 2079861

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Chloride	103	104	P/P	90 - 110
Sulfate	103	103	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A90964

Included Lab Sample IDs: 2079870

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acesulfame K	126	144	P/P	60 - 160
Endothall	103	120	P/P	60 - 160

Reference Method: EPA 200.7 Rev. 4.4

Run ID: A90983

Included Lab Sample IDs: 2079866

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Barium	99.7	99.2	P/P	90 - 110
Calcium	100	101	P/P	90 - 110
Iron	102	102	P/P	90 - 110
Magnesium	103	103	P/P	90 - 110
Potassium	98.7	99.2	P/P	90 - 110
Sodium	101	101	P/P	90 - 110
Zinc	101	101	P/P	90 - 110

Reference Method: EPA 8321B

Run ID: A90985

Included Lab Sample IDs: 2079870

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Sucralose	98.3	99.7	P/P	60 - 160

Reference Method: SM 5310 B-00

Run ID: A91030

Included Lab Sample IDs: 2079862

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Organic Carbon	91.8	90.9	P/P	90 - 110

Reference Method: EPA 365.1 Rev. 2.0

Run ID: A91034

Included Lab Sample IDs: 2079862

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total-P	102	101	P/P	90 - 110

Reference Method: EPA 353.2 Rev. 2.0

Run ID: A91039

Included Lab Sample IDs: 2079862

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
NO2NO3-N	98.5	98.0	P/P	90 - 110

Quality Assurance Report Calibration Verification

Reference Method: EPA 8270D
Run ID: A91053
Included Lab Sample IDs: 2079867

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Acetochlor	102		P	80 - 120
Alachlor	105		P	80 - 120
Ametryn	104		P	80 - 120
Atrazine	99.3		P	80 - 120
Atrazine Desethyl	86.9		P	80 - 120
Azinphos Methyl	96.9		P	80 - 120
Bromacil	101		P	80 - 120
Butylate	97.0		P	80 - 120
Chlorpyrifos Ethyl	99.0		P	80 - 120
Chlorpyrifos Methyl	97.9		P	80 - 120
Cyanazine	86.5		P	80 - 120
Demeton	80.2		P	80 - 120
Diazinon	101		P	80 - 120
Dimethenamid	103		P	80 - 120
Disulfoton	96.7		P	80 - 120
Dithiopyr	104		P	80 - 120
EPTC	101		P	80 - 120
Ethion	95.9		P	80 - 120
Ethoprop	97.8		P	80 - 120
Fenamiphos	95.6		P	80 - 120
Fipronil	101		P	80 - 120
Fipronil Desulfinyl	103		P	80 - 120
Fipronil Sulfide	96.6		P	80 - 120
Fipronil Sulfone	96.4		P	80 - 120
Fonofos	101		P	80 - 120
Hexazinone	99.1		P	80 - 120
Malathion	96.5		P	80 - 120
Metalaxyl	107		P	80 - 120
Metolachlor	107		P	80 - 120
Metribuzin	73.0*		F	80 - 120
Mevinphos	98.2		P	80 - 120
Molinate	94.9		P	80 - 120
Norflurazon	103		P	80 - 120
Oxadiazon	106		P	80 - 120
Parathion Ethyl	95.4		P	80 - 120
Parathion Methyl	96.2		P	80 - 120
Pendimethalin	97.0		P	80 - 120
Phorate	95.6		P	80 - 120
Prodiamine	99.7		P	80 - 120
Prometon	102		P	80 - 120
Prometryn	105		P	80 - 120
Simazine	99.9		P	80 - 120
Tebuconazole	103		P	80 - 120
Terbufos	94.7		P	80 - 120
Terbuthylazine	96.2		P	80 - 120

Reference Method: EPA 350.1 Rev. 2.0
Run ID: A91070
Included Lab Sample IDs: 2079862

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
-----------	---------	---------	------------	----------------

Quality Assurance Report Calibration Verification

Reference Method: EPA 350.1 Rev. 2.0

Run ID: A91070

Included Lab Sample IDs: 2079862

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Ammonia-N	102	102	P/P	90 - 110

Reference Method: SM 2320 B-97

Run ID: A91081

Included Lab Sample IDs: 2079861

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Total Alkalinity	102	98.9	P/P	90 - 110

Reference Method: SM 4500 F-C-97

Run ID: A91081

Included Lab Sample IDs: 2079861

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Fluoride	101	102	P/P	90 - 110

Reference Method: EPA 200.8 Rev. 5.4

Run ID: A91083

Included Lab Sample IDs: 2079866

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Aluminum	97.4	94.6	P/P	90 - 110
Antimony	101	104	P/P	90 - 110
Arsenic	103	104	P/P	90 - 110
Boron	95.9	93.5	P/P	90 - 110
Cadmium	99.1	102	P/P	90 - 110
Chromium	99.6	104	P/P	90 - 110
Copper	102	101	P/P	90 - 110
Lead	91.0	93.0	P/P	90 - 110
Nickel	102	102	P/P	90 - 110
Selenium	102	96.0	P/P	90 - 110
Silver	96.4	98.7	P/P	90 - 110
Thallium	98.3	100	P/P	90 - 110

Reference Method: EPA 351.2 Rev. 2.0

Run ID: A91156

Included Lab Sample IDs: 2079862

Component	% Rec.1	% Rec.2	Pass/Fail*	Control Limits
Kjeldahl Nitrogen	94.9	99.6	P/P	90 - 110

* Pass/Fail determinations are made for each bracketing calibration verification check.

Control limits for initial calibration checks may be different from those for continuing checks, depending on method requirements.

Where they are different, both control limits are provided.

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery		MS % Recovery			LCS	Precision SMP	MS
EPA 180.1 Rev. 2.0	Turbidity							2.03	
EPA 200.7 Rev. 4.4	Barium	97.4		98.1	94.1	94.3			0.190
	Calcium	103		106	99.2				1.19
	Iron	105		106	106	104			1.76
	Magnesium	102		110	104				3.09
	Potassium	98.9		102	105				1.61
	Sodium	101		103	97.2				0.409
	Zinc	99.1		99.8	98.4	97.8			0.605
EPA 200.8 Rev. 5.4	Aluminum	98.8		96.5	97.4	96.0			1.41
	Antimony	100		101	105	102			2.34
	Arsenic	105		105	110	110			0.444
	Boron	99.9		99.4	95.0	92.0			2.17
	Cadmium	102		102	105	103			1.98
	Chromium	95.2		98.4	95.6	96.1			0.552
	Copper	103		104	99.8	99.1			0.683
	Lead	93.3		93.6	94.7	93.4			1.35
	Nickel	103		105	103	103			0.769
	Selenium	102		105	106	104			1.06
	Silver	97.8		97.3	96.4	95.7			0.800
	Thallium	103		106	107	107			0.630
EPA 300.0 Rev. 2.1	Chloride	101		100	102			0.149	
	Sulfate	101		101	101			0.313	
EPA 350.1 Rev. 2.0	Ammonia-N	99.2		101	101				0.606
EPA 351.2 Rev. 2.0	Kjeldahl Nitrogen	93.7		102	109				4.11
EPA 353.2 Rev. 2.0	NO2NO3-N	98.5		97.0	96.5				0.265
EPA 365.1 Rev. 2.0	Total-P	98.4		93.2	96.8				2.03
EPA 365.1 Rev. 2.0 dissolved	O-Phosphate-P	102		98.5	97.7				0.758
EPA 8270D	Acetochlor	104	101	93.2	94.2		3.46		1.11
	Alachlor	102	99.7	89.9	89.6		2.74		0.334
	Ametryn	47.4	75.9	92.4	94.3		46.1		1.55
	Atrazine	96.6	97.2				0.615		1.89
	Atrazine Desethyl	52.1	49.3	63.2	58.8		5.45		5.13
	Azinphos Methyl	101	96.4	94.5	90.1		4.94		4.78
	Bromacil	62.2	43.8				34.7		4.83
	Butylate	58.1	58.5	46.5	47.6		0.548		2.38
	Chlorpyrifos Ethyl	98.7	97.0	97.4	98.2		1.69		0.884
	Chlorpyrifos Methyl	90.9	84.9	92.9	91.1		6.83		1.94
	Cyanazine	72.2	70.5	108	97.0		2.41		10.9
	Demeton	61.0	65.0	85.6	82.4		6.40		3.78
	Diazinon	98.2	94.8	98.9	98.1		3.46		0.864
	Dimethenamid	103	99.2	93.0	91.7		3.42		1.46
	Disulfoton	84.5	81.5	90.9	84.6		3.61		7.18
	Dithiopyr	107	104	95.9	96.5		2.59		0.549
	EPTC	61.0	58.3	48.7	51.9		4.42		6.41
	Ethion	103	104	101	98.2		1.22		2.36
	Ethoprop	88.1	84.3	91.4	90.1		4.42		1.10
	Fenamiphos	32.9	15.2	89.0	92.4		74.0		3.79
	Fipronil	103	91.4	80.1	75.2		12.0		5.70
	Fipronil Desulfinyl	101	94.3	68.7	66.3		6.75		2.99
	Fipronil Sulfide	102	96.2	71.4	65.1		5.39		7.15
	Fipronil Sulfone	97.7	86.9	52.7	45.4		11.8		8.46
	Fonofos	82.4	82.7	93.1	91.2		0.370		2.08
	Hexazinone	48.4	16.9	100	172		96.3		46.0
	Malathion	101	97.5	95.6	92.3		3.35		3.47

Quality Assurance Report Summary

Ref. Method	Analyte	LCS % Recovery		MS % Recovery		Precision	
						LCS	MS
						SMP	
EPA 8270D	Metalaxyl	13.7	9.41	90.4	82.6	37.0	8.69
	Metolachlor	104	100	90.3	92.5	3.58	1.40
	Metribuzin	73.1	72.4			0.906	7.82
	Mevinphos	51.2	26.7	77.1	83.1	63.1	7.50
	Molinate	67.5	70.4	65.9	66.6	4.11	1.09
	Norflurazon	92.6	81.4	77.6	72.3	12.9	7.07
	Oxadiazon	110	109	94.8	94.8	1.35	0.0093
	Parathion Ethyl	90.2	89.3	95.5	92.5	1.04	3.23
	Parathion Methyl	91.2	89.4	99.7	96.5	2.08	3.21
	Pendimethalin	103	109	120	119	6.04	1.32
	Phorate	73.7	72.0	82.3	79.2	2.36	3.83
	Prodiamine	115	114	124	123	0.668	0.994
	Prometon	22.6	27.6	93.7	121	20.0	25.4
	Prometryn	59.8	88.9	95.0	92.9	39.2	2.21
	Simazine	101	92.6			8.61	0.137
	Tebuconazole	56.4	14.6	78.9	75.2	118	4.00
	Terbufos	85.6	83.3	99.5	92.6	2.69	7.11
	Terbuthylazine	100	97.6	96.7	94.8	2.59	2.03
EPA 8321B	2,4-D	86.2		98.0	81.8		16.6
	Acesulfame K	110		187	184		1.51
	Acetaminophen	83.1		80.9	79.6		1.65
	AMPA	120		134	131		2.13
	Bentazon	83.4		56.9	52.0		5.47
	Carbamazepine	81.0		92.7	85.8		7.29
	Diuron	82.1		72.6	71.6		1.36
	Endothall	118		97.9	96.2		1.79
	Fenuron	93.8		116	111		3.79
	Fluridone	120		117	122		2.62
	Glufosinate	128		130	128		1.06
	Glyphosate	125		118	117		0.940
	Hydrocodone	110		107	102		4.57
	Ibuprofen	83.3		87.2	78.2		10.9
	Imazapyr	85.5		92.8	85.9		4.83
	Imidacloprid	97.9		154	122		19.3
	Linuron	75.2		79.6	81.1		1.78
	MCPP	97.9		107	99.0		7.34
	Naproxen	76.6		62.2	66.5		6.69
	Primidone	95.6		89.6	90.7		1.16
	Pyraclostrobin	70.0		65.5	68.2		4.04
	Sucralose	98.7		102	104		2.24
	Triclopyr	75.1		75.4	62.5		18.6
SM 2120 B	Color (true)	104				0.517	
SM 2320 B-97	Total Alkalinity	102				0.961	
SM 2540 C-97	TDS					0.962	
SM 4500 F-C-97	Fluoride	96.9		96.5	97.2		0.467
SM 5310 B-00	Organic Carbon	90.8		88.8	87.6		0.899

Reference Method Descriptions

Method / DoH Cert #
EPA 180.1 Rev. 2.0 /
E31780

Description
Turbidity in aqueous matrices

Associated Samples
2079861

Reference Method Descriptions

Method / DoH Cert #	Description	Associated Samples
EPA 200.7 Rev. 4.4 / E31780	Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects	2079866
EPA 200.8 Rev. 5.4 / E31780	Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects	2079866
EPA 300.0 Rev. 2.1 / E31780	Chloride in aqueous matrices	2079861
EPA 300.0 Rev. 2.1 / E31780	Sulfate in aqueous matrices	2079861
EPA 350.1 Rev. 2.0 / E31780	Ammonia in aqueous matrices as mg N/L	2079862
EPA 351.2 Rev. 2.0 / E31780	Total Kjeldahl Nitrogen in aqueous matrices	2079862
EPA 353.2 Rev. 2.0 / E31780	Nitrite/Nitrate in aqueous matrices as mg N/L	2079862
EPA 365.1 Rev. 2.0 / E31780	Total Phosphorus in aqueous matrices as mg P/L	2079862
EPA 365.1 Rev. 2.0 dissolved / E31780	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L	2079863
EPA 8270D / E31780	Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS	2079867
EPA 8321B / E31780	Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS	2079870
EPA 8321B / E31780	Water soluble organic compounds by HPLC/MS/MS	2079870
SM 2120 B / E31780	True Color measured at 450 nm	2079861
SM 2320 B-97 / E31780	Alkalinity in aqueous matrices as mg CaCO3/L	2079861
SM 2540 C-97 / E31780	Total Dissolved Solids in aqueous matrices	2079861
SM 2540 D-97 / E31780	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample	2079861
SM 4500 F-C-97 / E31780	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)	2079861
SM 5310 B-00 / E31780	Nonpurgeable Organic Carbon in aqueous matrices	2079862

Preparation and Analysis Log

Ref. Method	Received Date	Prep Date/Time	Prepared By	Analysis Date/Time	Analyzed By	Associated Samples
EPA 180.1 Rev. 2.0	04/19/2019			04/19/2019 15:55	Adrian Shelby	2079861
EPA 200.7 Rev. 4.4	04/19/2019	04/23/2019 15:00	Elliott D. Healy	04/24/2019 18:11	Betina Topolski	2079866
EPA 200.8 Rev. 5.4	04/19/2019	04/23/2019 15:00	Elliott D. Healy	04/30/2019 00:33	Martin Acosta	2079866
EPA 300.0 Rev. 2.1	04/19/2019			04/25/2019 08:44	Lipi Saha	2079861
EPA 350.1 Rev. 2.0	04/19/2019			04/26/2019 10:51	Ping Hua	2079862
EPA 351.2 Rev. 2.0	04/19/2019	04/30/2019 12:15	Adrian Shelby	05/02/2019 13:42	Joseph Suarez	2079862
EPA 353.2 Rev. 2.0	04/19/2019			04/26/2019 11:52	Beverly Y. Sanders	2079862
EPA 365.1 Rev. 2.0	04/19/2019	04/24/2019 13:50	Sima Feizi	04/26/2019 12:28	Rosalyn Ballman	2079862
EPA 365.1 Rev. 2.0 dissolved	04/19/2019			04/19/2019 17:26	Julia Storbeck	2079863
EPA 8270D	04/19/2019	04/19/2019 13:00	Fe-Val Siddell	04/23/2019 19:58	Vandana T. Nagar	2079867
EPA 8321B	04/19/2019	04/22/2019 10:30	Rebecca Ware	04/22/2019 15:41	Rebecca Ware	2079870
	04/19/2019	04/22/2019 10:30	Rebecca Ware	04/23/2019 12:35	Rebecca Ware	2079870
	04/19/2019	04/22/2019 10:30	Rebecca Ware	04/24/2019 23:37	Rebecca Ware	2079870
	04/19/2019	04/22/2019 14:00	Hoor Shaik	04/24/2019 09:46	Juyoung Kim	2079870
SM 2120 B	04/19/2019			04/19/2019 16:07	Mariam Hanna	2079861
SM 2320 B-97	04/19/2019			04/29/2019 21:58	Dale L. Simmons	2079861
SM 2540 C-97	04/19/2019			04/24/2019 15:30	Yijie Li	2079861
SM 2540 D-97	04/19/2019			04/24/2019 15:30	Yijie Li	2079861
SM 4500 F-C-97	04/19/2019			04/29/2019 21:58	Dale L. Simmons	2079861
SM 5310 B-00	04/19/2019			04/25/2019 10:25	Julia Storbeck	2079862