

Date of Request: 25-MAR-2019
 Created By: PARRISH_J On: 25-MAR-2019
 Modified By: JASROTIA_P On: 22-APR-2019
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Sampling Event: Suwannee North

Send Coolers To:

Phone: 904-807-3300
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Program Module Number:
 Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 22-APR-2019
 Biology Request Reviewed By: JASROTIA_P On: 22-APR-2019
 Sampling Kit Required: YES Ship on: 07-MAY-2019
 Sampling Kit Shipped: YES On: 08-MAY-2019
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 13-MAY-2019
 Received By: KLUG_K On: 16-MAY-2019

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Nutrients, Metals, Bacteria, markers, tracers, pesticides
 Group B: Nutrients, Bacteria, markers, tracers
 Group C: Nutrients
 Group D: Nutrients, Metals, Pesticides

NE-ALS-ECQ

Packing Notes:

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		

Bottle Group A (Water) With 2 Samples:

Bottle Type: BG-1L Number of Bottles: 6 Preserved With: ICE
 W-PSNP-TQ Template: DEFAULT (EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

*Dimethenamid
 *Dithiopyr
 *Fipronil Desulfinyl
 *Oxadiazon
 *Prodiamine
 *Tebuconazole
 Acetochlor
 Alachlor
 Ametryn
 Atrazine
 Atrazine Desethyl
 Azinphos Methyl
 Bromacil
 Butylate
 Chlorpyrifos Ethyl
 Chlorpyrifos Methyl
 Cyanazine
 Demeton
 Diazinon
 Disulfoton
 EPTC
 Ethion
 Ethoprop
 Fenamiphos
 Fipronil
 Fipronil Sulfide
 Fipronil Sulfone
 Fonofos
 Hexazinone
 Malathion
 Metalaxyl
 Metolachlor
 Metribuzin
 Mevinphos
 Molinate
 Norflurazon
 Parathion Ethyl
 Parathion Methyl
 Pendimethalin
 Phorate
 Prometon
 Prometryn
 Simazine
 Terbufos
 Terbutylazine

Bottle Type: BP-1L Number of Bottles: 2 Preserved With: ICE
 CHLSUITE-W Template: DEFAULT (SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Chlorophyll-a, Corrected
 Chlorophyll-a, Uncorrected
 Phaeophytin-a

Bottle Type: P-250ML-WI-THI Number of Bottles: 2 Preserved With: ICE
 NE-ALS-ECQ Template: DEFAULT (SM 9223 B Quanti-Tray) E. coli by Colilert/QT by ALS in Jacksonville
 Escherichia Coli-Quanti-Tray

Bottle Type: QPCR-P-500ML Number of Bottles: 2 Preserved With: ICE
 PCR-FILTER Template: DEFAULT (SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
 *HF183 - Human Source Marker

Bottle Type: BG-500ML Number of Bottles: 2 Preserved With: CH₂ClCOOH Pre-Preserved
 W-CARB-AA Template: DEFAULT (EPA 8321B) Carbamates in water matrices by HPLC/MS/MS

Bottle Group A (Water) With 2 Samples:

Bottle Type: BG-500ML Number of Bottles: 2 Preserved With: CH₂ClCOOH Pre-Preserved
 W-CARB-AA Template: DEFAULT (EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
 3-Hydroxycarbofuran
 Aldicarb
 Aldicarb Sulfone
 Aldicarb Sulfoxide
 Carbaryl
 Carbofuran
 Methiocarb
 Methomyl
 Oxamyl
 Propoxur

Bottle Type: BG-500ML Number of Bottles: 6 Preserved With: ICE
 W-CT-Cl-R Template: DEFAULT (EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Chlordane
 Toxaphene

W-PCL-SQ-R Template: DEFAULT (EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM

*Bifenthrin
 *Cis-Nonachlor
 *Ethalfluralin
 *Hexachlorobenzene
 *Trans-Nonachlor

Aldrin
 Alpha-BHC
 Alpha-Chlordane
 Beta-BHC
 Carbophenothion
 Chlorothalonil
 Cypermethrin
 DDD-p,p'
 DDE-p,p'
 DDT-p,p'
 Delta-BHC
 Dicofol
 Dieldrin
 Endosulfan I
 Endosulfan II
 Endosulfan Sulfate
 Endrin
 Endrin Aldehyde
 Endrin Ketone
 Gamma-BHC
 Gamma-Chlordane
 Heptachlor
 Heptachlor Epoxide
 Methoxychlor
 Mirex
 Permethrin
 Trifluralin

Bottle Type: BG-500ML Number of Bottles: 2 Preserved With: ICE
 W-E8321-DI Template: DEFAULT (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

*Acesulfame K
 *AMPA
 *Endothall
 *Glufosinate
 *Glyphosate
 *Sucralose

W-E8321-MS Template: DEFAULT (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
 *Acetaminophen
 *Carbamazepine

Bottle Group A (Water) With 2 Samples:

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Fluridone *Hydrocodone *Ibuprofen *Imazapyr *Naproxen *Primidone *Pyraclostrobin *Triclopyr 2,4-D Bentazon Diuron Fenuron Imidacloprid Linuron MCPP		

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium Calcium Iron Magnesium Potassium Sodium Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron Aluminum Antimony Arsenic Cadmium Chromium Copper Lead Nickel Selenium Silver Thallium		

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by ALS in Jacksonville
Escherichia Coli-Quanti-Tray		
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-FILTER	Template: DEFAULT	(SOP-PCR-4.0) Preparation of Samples by Filtration and held for qPCR Analysis
*HF183 - Human Source Marker		
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Acesulfame K		
*AMPA		
*Endothall		
*Glufosinate		
*Glyphosate		
*Sucralose		
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Acetaminophen		
*Carbamazepine		
*Fluridone		
*Hydrocodone		
*Ibuprofen		
*Imazapyr		
*Naproxen		
*Primidone		
*Pyraclostrobin		
*Triclopyr		
2,4-D		
Bentazon		
Diuron		
Fenuron		
Imidacloprid		
Linuron		
MCPP		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
3-Hydroxycarbofuran		
Aldicarb		
Aldicarb Sulfone		
Aldicarb Sulfoxide		
Carbaryl		
Carbofuran		
Methiocarb		
Methomyl		
Oxamyl		
Propoxur		
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
Chlordane		
Toxaphene		
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM
*Bifenthrin		
*Cis-Nonachlor		
*Ethalfuralin		
*Hexachlorobenzene		
*Trans-Nonachlor		
Aldrin		
Alpha-BHC		
Alpha-Chlordane		
Beta-BHC		
Carbophenothion		
Chlorothalonil		
Cypermethrin		
DDD-p,p'		
DDE-p,p'		
DDT-p,p'		
Delta-BHC		
Dicofol		
Dieldrin		
Endosulfan I		
Endosulfan II		
Endosulfan Sulfate		
Endrin		
Endrin Aldehyde		
Endrin Ketone		
Gamma-BHC		
Gamma-Chlordane		
Heptachlor		
Heptachlor Epoxide		
Methoxychlor		
Mirex		
Permethrin		
Trifluralin		
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Acesulfame K		

Bottle Group D (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*AMPA		
*Endothall		
*Glufosinate		
*Glyphosate		
*Sucralose		
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Acetaminophen		
*Carbamazepine		
*Fluridone		
*Hydrocodone		
*Ibuprofen		
*Imazapyr		
*Naproxen		
*Primidone		
*Pyraclostrobin		
*Triclopyr		
2,4-D		
Bentazon		
Diuron		
Fenuron		
Imidacloprid		
Linuron		
MCPP		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron		
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-125ML Number of Bottles: 1 Preserved With: FILTER-ICE
 W-PO4-F Template: DEFAULT (EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
 O-Phosphate-P

Bottle Type: BG-1L Number of Bottles: 2 Preserved With: ICE
 W-PSNP-TQ Template: DEFAULT (EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

*Dimethenamid
 *Dithiopyr
 *Fipronil Desulfinyl
 *Oxadiazon
 *Prodiamine
 *Tebuconazole
 Acetochlor
 Alachlor
 Ametryn
 Atrazine
 Atrazine Desethyl
 Azinphos Methyl
 Bromacil
 Butylate
 Chlorpyrifos Ethyl
 Chlorpyrifos Methyl
 Cyanazine
 Demeton
 Diazinon
 Disulfoton
 EPTC
 Ethion
 Ethoprop
 Fenamiphos
 Fipronil
 Fipronil Sulfide
 Fipronil Sulfone
 Fonofos
 Hexazinone
 Malathion
 Metalaxyl
 Metolachlor
 Metribuzin
 Mevinphos
 Molinate
 Norflurazon
 Parathion Ethyl
 Parathion Methyl
 Pendimethalin
 Phorate
 Prometon
 Prometryn
 Simazine
 Terbufos
 Terbutylazine

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.