

Log-in Checklist

RQ-2019-07-22-06

Login Station ID: #4

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 07/24/19 @ 9:50

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
					Yes	No	Yes	No	
2.0°C		HNO ₃	Formalin	14		X			4751 8781 5156
1.6°C				17		X			4751 8781 5134
1.3°C				14		X			4751 8781 5145

* HNO3 and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ✓ No ⊗

m 07/24/19

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No X If yes, is it intact? Yes No

**Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No

**Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ✓ No Init: Tyler P.

Chlorine detected? (One container checked per Field ID) Yes No X Init: Tyler P.

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: Tyler P.

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA X Init: Tyler P.

Coolers Unpacked/Checked by: Tyler Reynolds Date: 07/24/19 NCRs (Y/N)? N

Event ID: ICW Boat NCR #

NE-DIST-2019-07-24-02 (SMP)

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_04_2018 EXP:04/29/2020
pH Test Strips 0 – 6 Lot #	213316AV EXP:05/15/2020
pH Paper 0 – 3 Lot #	
pH Paper 0 – 13 Lot #	215517 EXP: 06/01/2020
Chlorine Test Strips Lot #	8261 EXP: 07/30/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

ICW Boat

Customer: NE-DIST

Project ID: SMP

Requester: Jeremy M. Parrish

Field Report Prepared By:

Collected By: K. Appleby + J. Parrish

Sampling Agency: FDEP NE ROL

WIN ID/Field ID:	 27010114	ICW @ CM 15 DUVAL CO	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms
☐ Comp ☒ Grab Collection (comp begin or grab) Date 7/23/2019 Time 1100		Eastern Central Composite end Date Time	
Matrix (type, e.g., Salt, Fresh, etc) Salt		Diss. Oxygen mg/L 5.22 % sat Total Res. Chlorine (mg/L)	
Temp (C) 30.1		pH 7.62	
Sample Depth 0.3		Sp. Conductance (umho/cm) 37907 ft m	
Salinity (ppt) 23.92		Comments	
☐ Comp ☒ Grab Collection (comp begin or grab) Date 7/23/2019 Time 1045		Eastern Central Composite end Date Time	
Matrix (type, e.g., Salt, Fresh, etc) Salt		Diss. Oxygen mg/L 5.82 % sat Total Res. Chlorine (mg/L)	
Temp (C) 29.5		pH 7.79	
Sample Depth 0.3		Sp. Conductance (umho/cm) 36545 ft m	
Salinity (ppt) 22.99		Comments	
☐ Comp ☒ Grab Collection (comp begin or grab) Date 7/23/2019 Time 910		Eastern Central Composite end Date Time	
Matrix (type, e.g., Salt, Fresh, etc) Salt		Diss. Oxygen mg/L 4.27 % sat Total Res. Chlorine (mg/L)	
Temp (C) 30.5		pH 7.21	
Sample Depth 0.3		Sp. Conductance (umho/cm) 36522 ft m	
Salinity (ppt) 22.9		Comments	
WIN ID	 G2NE1178	Field ID	
G2NE1178DUP		Open creek 200 meters above mouth duplicate	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms
☐ Comp ☒ Grab Collection (comp begin or grab) Date 7/23/2019 Time 915		Eastern Central Composite end Date Time	
Matrix (type, e.g., Salt, Fresh, etc) Salt		Diss. Oxygen mg/L % sat Total Res. Chlorine (mg/L)	
Temp (C)		pH	
Sample Depth		Sp. Conductance (umho/cm) ft m	
Salinity (ppt)		Comments	

Relinquished By: K. Appleby	Date/Time 7/23/2019 1530	Shipping Method FDEX	Number of Coolers Shipped: 3	Received By: Tyler Reynolds	Date/Time 07/24/19 @ 9:50
--------------------------------	-----------------------------	-------------------------	---------------------------------	--------------------------------	------------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	ALKALINITY						
	TURBIDITY						
	W-BR-IC						
	W-F						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	CHLSUITE-W						
Group: A	Bottle Type:	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2 → sent to ALS
	NE-ALS-ENQ						
Group: A	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	PCR-HF183						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab	2
	W-CARB-AA						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab	6
	W-CT-CI-R						
	W-PCL-SQ-R						
Group: A	Bottle Type:	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	W-E8321-DI						
	W-E8321-MS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	2
	W-ICP						
	W-ICPMS						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	2
	W-PO4-F						
Group: A	Bottle Type:	BG-1L	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab	

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: NE-DIST

Project ID: SMP


Requester: Jeremy M. Parrish

Field Report Prepared By: K. Appleby

Collected By: K. Appleby + J. Parrish

Sampling Agency: FDEP NE ROL

Field ID:



FB072319

Location:

Open creek 200 meters above mouth

Latitude

☐ dd

Longitude

☐ dms

WIN ID/Field ID:



G2NE1186

Open creek 0.5 mi upstream of Mouth

Latitude

☐ dd

Longitude

☐ dms

Location

Field ID

WIN/STORET #

Latitude

☐ dd

Longitude

☐ dms

Location

Field ID

WIN/STORET #

Latitude

☐ dd

Longitude

☐ dms

Relinquished By:

Date/Time

Shipping Method

Number of Coolers Shipped:

Received By:

Date/Time

K. Appleby

7/23/2019 1530

FDEX

3

Tyler Reynolds

07/24/19 @ 9:50

Field ID: FB072319	☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	Bottle Group(s) (See pg 2)
	☒ Grab	Date 7/23/2019 Time 9:25	Central	Date	
	Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☒ mg/L	Total Res. Chlorine	
	Temp (C) 30.5	pH 7.21	☐ % sat	(mg/L)	
Location: Open creek 200 meters above mouth	☐ dd	Salinity (ppt) 22.9	Comments		C
	☐ dms				
	☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	
	☒ Grab	Date 7/23/2019 Time 9:55	Central	Date	
WIN ID/Field ID: G2NE1186		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☒ mg/L	Total Res. Chlorine
		Temp (C) 30.1	pH 7.11	☐ % sat	(mg/L)
		Sample Depth 0.3	☐ ft	Sp. Conductance	B
			☒ m	(umho/cm) 35449	
Open creek 0.5 mi upstream of Mouth	☐ dd	Salinity (ppt) 22.32	Comments		
	☐ dms				
	☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	
	☐ Grab	Date	Central	Date	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L	Total Res. Chlorine
		Temp (C)	pH	☐ % sat	(mg/L)
		Sample Depth	☐ ft	Sp. Conductance	
			☐ m	(umho/cm)	
WIN/STORET #	☐ dd	Salinity (ppt)	Comments		
	☐ dms				
	☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	
	☐ Grab	Date	Central	Date	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L	Total Res. Chlorine
		Temp (C)	pH	☐ % sat	(mg/L)
		Sample Depth	☐ ft	Sp. Conductance	
			☐ m	(umho/cm)	
WIN/STORET #	☐ dd	Salinity (ppt)	Comments		
	☐ dms				
	☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	
	☐ Grab	Date	Central	Date	
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L	Total Res. Chlorine
		Temp (C)	pH	☐ % sat	(mg/L)
		Sample Depth	☐ ft	Sp. Conductance	
			☐ m	(umho/cm)	
WIN/STORET #	☐ dd	Salinity (ppt)	Comments		
	☐ dms				
	☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	
	☐ Grab	Date	Central	Date	

Group: A	Bottle Type: ALKALINITY TURBIDITY W-BR-IC W-F W-TSS	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type: CHLSUTE-W	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type: NE-ALS-ENQ	P-250ML-WI-THI	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type: PCR-HF183	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type: W-CARB-AA	BG-500ML	# of Bottles: 2	Preservative:	CH2CICOOH Pre-Preserved	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type: W-CT-Cl-R W-PCL-SQ-R	BG-500ML	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type: W-ICP W-ICPMS	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab _____
Group: A	Bottle Type:	BG-1L	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____

Group: A	Bottle Type: W-PSNP-TQ	BG-1L	# of Bottles: 6	Preservative:	ICE	Enter Number of Bottles Sent to Lab	6
Group: B	Bottle Type: ALKALINITY TURBIDITY W-BR-IC W-F W-TSS	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: CHLSUITE-W	BP-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: NE-ALS-ENQ	P-250ML-WI-THI	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1 → Sent to ALS
Group: B	Bottle Type: PCR-HF183	QPCR-P-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: W-ICP W-ICPMS	P-500ML	# of Bottles: 1	Preservative:	HNO3	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
Group: B	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: ALKALINITY TURBIDITY W-BR-IC	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	+

Group: C	Bottle Type: W-F W-TSS	P-1L	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: W-CARB-AA	BG-500ML	# of Bottles: 1	Preservative: CH2ClCOOH Pre-Preserved	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: W-CT-Cl-R W-PCL-SQ-R	BG-500ML	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	* 2
Group: C	Bottle Type: W-E8321-DI W-E8321-MS	BG-500ML	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: W-ICP W-ICPMS	P-500ML	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: W-PO4-F	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: W-PSNP-TQ	BG-1L	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	* 2
Group: D	Bottle Type: NE-ALS-ENQ	P-250ML-WI-THI	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	2 → sent to ALS



9143 Phillips Highway, Suite 200. Jacksonville, FL 32256

Phone (904) 739-2277 / 800-695-7222 x06 / FAX (904) 739-2011

www.alsglobal.com

Page _____ of _____

[illegible]

Chain of Custody

SMF-9

3/14/2016

Cooler Packing Worksheet for Request: RQ-2019-07-22-06

ICW Boat

Ship Cooler On: 7/12/2019

Customer/Project: NE-DIST/SMP

Assigned To: KLUG_K

Requester: Jeremy M. Parrish

Priority: 3

904-256-1693
8800 Baymeadows Way West
Suite 100
Jacksonville, FL 32256
Attn: Jeremy Parrish

Please return
packing list with
sample submittal
forms.

Comments:

No preservatives needed.

Group A: (Surf.-Salt)Nutrients, Metals, pesticides, markers, bacteria

Group B: (Suf.-Salt)Nutrients, Metals, markers, tracers, bacteria

Group C:(Blank) Nutrients, Metals, pesticides

Group D: (Surf-Salt) Bacteria

Packing Notes:

Requested Analyses:

Bottle Group: A

of Sites: 2

Container ID: P-1L

Qty: 2 Preservation: ICE

Lot # 00073854

Description: Plastic Bottle 1L

Analysis

ALKALINITY

TURBIDITY

W-BR-IC

W-F

W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO₃/L

Turbidity in aqueous matrices

Bromide in aqueous matrices

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 2 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WI-THI Qty: 2 Preservation: ICE

* Lot # 6K20

Description: 250 ml Sterilized with tablet

* Out of P-250ML-WI-THI bottles

Analysis

NE-ALS-ENQ

Description

Enterococci by Enterolert/QT by ALS in Jacksonville

Container ID: QPCR-P-500ML

Qty: 2 Preservation: ICE

Lot # 00073849

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-HF183

Description

Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Container ID: BG-500ML

Qty: 2 Preservation: CH2ClCOOH Pre-Preserved

Lot # 00073513

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML

Qty: 6 Preservation: ICE

Lot # 00074346

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CT-CI-R

W-PCL-SQ-R

Description

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Organochlorine pesticides in water matrices by GC/MS-SIM

Container ID: BG-500ML

Qty: 2 Preservation: ICE

Lot # 00074203

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 2 Preservation: HNO3

Lot # 00074433

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

Description

W-ICP
W-ICPMS

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 2 Preservation: ICE And H2SO4

Lot # 00074433

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3
W-NO2NO3
W-S-A-TP
W-TKN
W-TOC

Description

Ammonia in aqueous matrices as mg N/L
Nitrite/Nitrate in aqueous matrices as mg N/L
Total Phosphorus in aqueous matrices as mg P/L
Total Kjeldahl Nitrogen in aqueous matrices
Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 2 Preservation: FILTER-ICE

Lot # 00073860

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Container ID: BG-1L

Qty: 6 Preservation: ICE

Lot # 00073598

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

Description

Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group: B

of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 00073854

Description: Plastic Bottle 1L

Analysis

ALKALINITY
TURBIDITY
W-BR-IC
W-F
W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L
Turbidity in aqueous matrices
Bromide in aqueous matrices
Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BP-1L

Qty: 1 Preservation: ICE

Lot # 1248230

Description: Brown Plastic Bottle 1L

Analysis

CHLSUITE-W

Description

Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Container ID: P-250ML-WI-THI

Qty: 1 Preservation: ICE

* Lot # 6620

Description: 250 ml Sterilized with tablet

Analysis

NE-ALS-ENQ

Description

Enterococci by Enterolert/QT by ALS in Jacksonville

Container ID: QPCR-P-500ML

Qty: 1 Preservation: ICE

Lot # 00073849

Description: 500ml Sterile Nalgene

Affix PCR Instruction Label to container

Analysis

PCR-HF183

Description

Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00074203

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI

W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 1 Preservation: HNO3

Lot # 00074433

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP

W-ICPMS

Description

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 1 Preservation: ICE And H2SO4

Lot # 0007483

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3

W-NO2NO3

W-S-A-TP

W-TKN

W-TOC

Description

Ammonia in aqueous matrices as mg N/L

Nitrite/Nitrate in aqueous matrices as mg N/L

Total Phosphorus in aqueous matrices as mg P/L

Total Kjeldahl Nitrogen in aqueous matrices

Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00073850

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group: C

of Sites: 1

Container ID: P-1L

Qty: 1 Preservation: ICE

Lot # 00073854

Description: Plastic Bottle 1L

Analysis

ALKALINITY

TURBIDITY

W-BR-IC

W-F

W-TSS

Description

Alkalinity in aqueous matrices as mg CaCO3/L

Turbidity in aqueous matrices

Bromide in aqueous matrices

Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)

Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Container ID: BG-500ML

Qty: 1 Preservation: CH2ClCOOH Pre-Preserved Lot # 00073613

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-CARB-AA

Description

Carbamates in water matrices by HPLC/MS/MS

Container ID: BG-500ML

Qty: 2 Preservation: ICE

Lot # 00074203

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

Description

W-CT-CI-R
W-PCL-SQ-R

Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
Organochlorine pesticides in water matrices by GC/MS-SIM

Container ID: BG-500ML

Qty: 1 Preservation: ICE

Lot # 00074203

Description: Brown Glass Bottle 500ML

Affix BLUE dot to container.

Analysis

W-E8321-DI
W-E8321-MS

Description

Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Container ID: P-500ML

Qty: 1 Preservation: HNO3

Lot # 00074433

Description: Plastic Bottle 500 mL

Affix RED nitric acid dot to container.

Analysis

W-ICP
W-ICPMS

Description

Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Container ID: P-500ML

Qty: 1 Preservation: ICE And H2SO4

Lot # 00074433

Description: Plastic Bottle 500 mL

Affix YELLOW sulfuric acid dot to container.

Analysis

W-NH3
W-NO2NO3
W-S-A-TP
W-TKN
W-TOC

Description

Ammonia in aqueous matrices as mg N/L
Nitrite/Nitrate in aqueous matrices as mg N/L
Total Phosphorus in aqueous matrices as mg P/L
Total Kjeldahl Nitrogen in aqueous matrices
Nonpurgeable Organic Carbon in aqueous matrices

Container ID: P-125ML

Qty: 1 Preservation: FILTER-ICE

Lot # 00073250

Description: Plastic Bottle 125 mL

Analysis

W-PO4-F

Description

Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Container ID: BG-1L

Qty: 2 Preservation: ICE

Lot # 00073598

Description: Brown Glass Bottle 1L

Affix BLUE dot to container.

Analysis

W-PSNP-TQ

Description

Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group: D

of Sites: 2

Container ID: P-250ML-WI-THI

Qty: 2

Preservation: ICE

* Lot # 6K70

Description: 250 ml Sterilized with tablet

Analysis

NE-ALS-ENQ

Description

Enterococci by Enterolert/QT by ALS in Jacksonville

Cooler Packed By: KK

Number of Coolers: 4

Date: 7.9.19

Kit must also include:

- ☒ Field Sheets
- ☒ Temperature Control Bottle
- ☒ FedEx Bills, if applicable
- ☒ Plastic Bags/Zip Ties
- ☐ Acid Labels (sets of 24)

If Preservation Included:

ID <u>MCAA Buffer soln</u>	Exp <u>11.1.20</u>	Lot # <u>98739</u>
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____
ID _____	Exp _____	Lot # _____

PLEASE RETURN ALL COOLERS FOR RQ-2019-07-22-06

Date of Request: 05-JUN-2019
 Created By: PARRISH_J On: 05-JUN-2019
 Modified By: WATTS_J On: 08-JUL-2019
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Sampling Event: ICW Boat

Send Coolers To:

Phone: 904-256-1693
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Program Module Number:

Priority: 3
 Event Status: S
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 08-JUL-2019
 Biology Request Reviewed By: JASROTIA_P On: 03-JUL-2019
 Sampling Kit Required: YES Ship on: 12-JUL-2019
 Sampling Kit Shipped: YES On: 10-JUL-2019
 Sampling Kit Packed By: KLUG_K
 Preservatives Needed: NO
 Date to Receive Samples: 22-JUL-2019
 Received By:

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: (Surf.-Salt)Nutrients, Metals, pesticides, markers, bacteria
 Group B: (Suf.-Salt)Nutrients, Metals, markers, tracers, bacteria
 Group C:(Blank) Nutrients, Metals, pesticides
 Group D: (Surf-Salt) Bacteria

Packing Notes:**Bottle Group A (Water) With 2 Samples:**

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 6	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville
Bottle Type: QPCR-P-500ML	Number of Bottles: 2	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: CH2CICOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
Bottle Type: BG-500ML	Number of Bottles: 6	Preserved With: ICE
W-CT-CI-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Bottle Group A (Water) With 2 Samples:

Bottle Type: BG-500ML	Number of Bottles: 6	Preserved With: ICE
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM
Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Iron		
Manganese		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Iron		
Manganese		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-CT-Cl-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

W-PCL-SQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM
------------	-------------------	--

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template:	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Iron
Manganese
Zinc

W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
---------	-----------	---

Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
Bottle Type: BG-1L	Number of Bottles: 2	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS

Bottle Group D (Water) With 2 Samples:

Bottle Type: P-250ML-WI-THI	Number of Bottles: 2	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.