

Date of Request: 13-SEP-2019
 Created By: PARRISH_J On: 13-SEP-2019
 Modified By: JASROTIA_P On: 17-SEP-2019
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Sampling Event: ICW Boat

Send Coolers To:

Phone: 904-256-1693
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Program Module Number:
 Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 17-SEP-2019
 Biology Request Reviewed By: JASROTIA_P On: 17-SEP-2019
 Sampling Kit Required: YES Ship on: 27-SEP-2019
 Sampling Kit Shipped: YES On: 25-SEP-2019
 Sampling Kit Packed By: RODRIGUE_G
 Preservatives Needed: NO
 Date to Receive Samples: 07-OCT-2019
 Received By: KLUG_K On: 11-OCT-2019

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Nutrients, Metals, Markers, Bacteria, pesticides
 NE-ALS-ENQ
 Packing Notes:

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices
Bromide		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		

Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		

Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
*Dimethenamid		
*Dithiopyr		
*Fipronil Desulfinyl		
*Oxadiazon		
*Prodiamine		
*Tebuconazole		
Acetochlor		

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ	Template: DEFAULT	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS
Alachlor		
Ametryn		
Atrazine		
Atrazine Desethyl		
Azinphos Methyl		
Bromacil		
Butylate		
Chlorpyrifos Ethyl		
Chlorpyrifos Methyl		
Cyanazine		
Demeton		
Diazinon		
Disulfoton		
EPTC		
Ethion		
Ethoprop		
Fenamiphos		
Fipronil		
Fipronil Sulfide		
Fipronil Sulfone		
Fonofos		
Hexazinone		
Malathion		
Metaxyl		
Metolachlor		
Metribuzin		
Mevinphos		
Molinate		
Norflurazon		
Parathion Ethyl		
Parathion Methyl		
Pendimethalin		
Phorate		
Prometon		
Prometryn		
Simazine		
Terbufos		
Terbutylazine		
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		
Bottle Type: P-250ML-WI-THI	Number of Bottles: 1	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville
ENTEROCOCCI-ENTEROLERT		
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
*HF183-qPCR		
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH2ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
3-Hydroxycarbofuran		
Aldicarb		
Aldicarb Sulfone		
Aldicarb Sulfoxide		
Carbaryl		
Carbofuran		

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML Number of Bottles: 1 Preserved With: CH₂ClCOOH Pre-Preserved
 W-CARB-AA Template: DEFAULT (EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
 Methiocarb
 Methomyl
 Oxamyl
 Propoxur

Bottle Type: BG-500ML Number of Bottles: 4 Preserved With: ICE
 W-CT-CI-R Template: DEFAULT (EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization

Chlordane
 Toxaphene

W-PCL-SQ-R Template: DEFAULT (EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM

*Bifenthrin
 *Cis-Nonachlor
 *Ethalfuralin
 *Trans-Nonachlor
 Aldrin
 Alpha-BHC
 Alpha-Chlordane
 Beta-BHC
 Carbophenothion
 Chlorothalonil
 Cypermethrin
 DDD-p,p'
 DDE-p,p'
 DDT-p,p'
 Delta-BHC
 Dicofof
 Dieldrin
 Endosulfan I
 Endosulfan II
 Endosulfan Sulfate
 Endrin
 Endrin Aldehyde
 Endrin Ketone
 Gamma-BHC
 Gamma-Chlordane
 Heptachlor
 Heptachlor Epoxide
 Hexachlorobenzene
 Methoxychlor
 Mirex
 Permethrin
 Trifluralin

Bottle Type: BG-500ML Number of Bottles: 1 Preserved With: ICE
 W-E8321-DI Template: DEFAULT (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

*Acesulfame K
 *AMPA
 *Endothall
 *Glufosinate
 *Glyphosate
 *Sucralose

W-E8321-MS Template: DEFAULT (EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

*Acetaminophen
 *Acetamiprid
 *Afidopyropen
 *Benzovindiflupyr
 *Carbamazepine
 *Clothianidin
 *Dinotefuran
 *Fluridone

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Hydrocodone *Ibuprofen *Imazapyr *Mandestrobin *Naproxen *Primidone *Pyraclostrobin *Thiamethoxam *Tolfenpyrad *Triclopyr 2,4-D Bentazon Diuron Fenuron Imidacloprid Linuron MCPP		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Iron Manganese Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum Antimony Arsenic Cadmium Chromium Copper Lead Nickel Selenium Silver Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.