

Date of Request: 27-SEP-2019
 Created By: PARRISH_J On: 27-SEP-2019
 Modified By: JASROTIA_P On: 10-OCT-2019
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Sampling Event: Suwannee North

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Program Module Number:
 Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 09-OCT-2019
 Biology Request Reviewed By: JASROTIA_P On: 10-OCT-2019
 Sampling Kit Required: YES Ship on: 18-OCT-2019
 Sampling Kit Shipped: YES On: 14-OCT-2019
 Sampling Kit Packed By: REYNOLDS_T
 Preservatives Needed: NO
 Date to Receive Samples: 28-OCT-2019
 Received By: REYNOLDS_T On: 30-OCT-2019

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: (Surf-Fresh)Nutrients, Metals, markers, tracers, pesticides, bacteria
 Group B: (Surf-Fresh)Nutrients, markers, tracers, bacteria
 Group C: (Surf-Fresh)Nutrients
 Group D: Blank Nutrients, Tracers

NE-ALS-ECQ
 Packing Notes:

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO ₃ /L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		
Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-1L	Number of Bottles: 4	Preserved With: ICE
W-PSNP-TQ Template:	(EPA 8270E) Organonitrogen and phosphorus pesticides in water matrices by GC/MS/MS	
*Dimethenamid *Dithiopyr *Fipronil Desulfinyl *Oxadiazon *Prodiamine *Tebuconazole Acetochlor Alachlor Ametryn Atrazine Atrazine Desethyl Azinphos Methyl Bromacil Butylate Chlorpyrifos Ethyl Chlorpyrifos Methyl Cyanazine Demeton Diazinon Disulfoton EPTC Ethion Ethoprop Fenamiphos Fipronil Fipronil Sulfide Fipronil Sulfone Fonofos Hexazinone Malathion Metalaxyl Metolachlor Metribuzin Mevinphos Molinate Norflurazon Parathion Ethyl Parathion Methyl Pendimethalin Phorate Prometon Prometryn Simazine Terbufos Terbutylazine		
Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry	
Chlorophyll-a, Corrected Chlorophyll-a, Uncorrected Phaeophytin-a		
Bottle Type: P-120ML-WC-THI	Number of Bottles: 2	Preserved With: ICE
NE-ALS-ECQ Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by ALS in Jacksonville	
Escherichia Coli-Quanti-Tray		
Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-BACR Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction	
*BacR-qPCR		

Bottle Group A (Water) With 1 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 1	Preserved With: ICE
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
*DG3-qPCR		
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
*HF183-qPCR		
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: CH ₂ ClCOOH Pre-Preserved
W-CARB-AA	Template: DEFAULT	(EPA 8321B) Carbamates in water matrices by HPLC/MS/MS
3-Hydroxycarbofuran		
Aldicarb		
Aldicarb Sulfone		
Aldicarb Sulfoxide		
Carbaryl		
Carbofuran		
Methiocarb		
Methomyl		
Oxamyl		
Propoxur		
Bottle Type: BG-500ML	Number of Bottles: 4	Preserved With: ICE
W-CT-Cl-R	Template: DEFAULT	(EPA 8276) Organochlorine pesticides in water matrices by GC/MS with Negative Chemical Ionization
Chlordane		
Toxaphene		
W-PCL-SQ-R	Template: DEFAULT	(EPA 8270E) Organochlorine pesticides in water matrices by GC/MS-SIM
*Bifenthrin		
*Cis-Nonachlor		
*Ethalfuralin		
*Trans-Nonachlor		
Aldrin		
Alpha-BHC		
Alpha-Chlordane		
Beta-BHC		
Carbophenothion		
Chlorothalonil		
Cypermethrin		
DDD-p,p'		
DDE-p,p'		
DDT-p,p'		
Delta-BHC		
Dicofol		
Dieldrin		
Endosulfan I		
Endosulfan II		
Endosulfan Sulfate		
Endrin		
Endrin Aldehyde		
Endrin Ketone		
Gamma-BHC		
Gamma-Chlordane		
Heptachlor		
Heptachlor Epoxide		
Hexachlorobenzene		
Methoxychlor		
Mirex		
Permethrin		
Trifluralin		
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Acesulfame K		
*AMPA		

Bottle Group A (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Endothall		
*Glufosinate		
*Glyphosate		
*Sucralose		
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Acetaminophen		
*Acetamiprid		
*Afidopyropen		
*Benzovindiflupyr		
*Carbamazepine		
*Clothianidin		
*Dinotefuran		
*Fluridone		
*Hydrocodone		
*Ibuprofen		
*Imazapyr		
*Mandestrobin		
*Naproxen		
*Primidone		
*Pyraclostrobin		
*Thiamethoxam		
*Tolfenpyrad		
*Triclopyr		
2,4-D		
Bentazon		
Diuron		
Fenuron		
Imidacloprid		
Linuron		
MCPP		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO3
W-ICP	Template:	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Barium		
Calcium		
Iron		
Magnesium		
Potassium		
Sodium		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
*Boron		
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		

Bottle Group A (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		

Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		

Bottle Type: P-120ML-WC-THI	Number of Bottles: 4	Preserved With: ICE
NE-ALS-ECQ	Template: DEFAULT	(SM 9223 B Quanti-Tray) E. coli by Colilert/QT by ALS in Jacksonville
Escherichia Coli-Quanti-Tray		

Bottle Type: QPCR-P-500ML	Number of Bottles: 2	Preserved With: ICE
PCR-BACR	Template: DEFAULT	(SOP-PCR-1.4) Detection and quantification of Ruminant specific Bacteroidetes BacR genetic marker with quantitative polymerase chain reaction
*BacR-qPCR		
PCR-DG3	Template: DEFAULT	(SOP-PCR-1.5) Detection and quantification of canine-specific DG3 Bacteroides genetic marker with quantitative polymerase chain reaction
*DG3-qPCR		
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction
*HF183-qPCR		

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Acesulfame K		
*AMPA		
*Endothall		
*Glufosinate		
*Glyphosate		
*Sucralose		
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Acetaminophen		
*Acetamiprid		
*Afidopyropen		
*Benzovindiflupyr		
*Carbamazepine		
*Clothianidin		

Bottle Group B (Water) With 2 Samples:

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
*Dinotefuran		
*Fluridone		
*Hydrocodone		
*Ibuprofen		
*Imazapyr		
*Mandestrobin		
*Naproxen		
*Primidone		
*Pyraclostrobin		
*Thiamethoxam		
*Tolfenpyrad		
*Triclopyr		
2,4-D		
Bentazon		
Diuron		
Fenuron		
Imidacloprid		
Linuron		
MCP		

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		

Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
Total Alkalinity		
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
Turbidity		
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
Chloride		
W-COLOR	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
Fluoride		
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
Sulfate		
W-TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
TDS		
W-TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
TSS		

Bottle Type: BP-1L	Number of Bottles: 1	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Chlorophyll-a, Corrected		
Chlorophyll-a, Uncorrected		
Phaeophytin-a		

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3 Ammonia-N	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3 NO2NO3-N	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP Total-P	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN Kjeldahl Nitrogen	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC Organic Carbon	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F O-Phosphate-P	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group D (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY Total Alkalinity	Template: DEFAULT	(SM 2320 B-2011) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY Turbidity	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC Chloride	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR Color (true)	Template: DEFAULT	(SM 2120 B-2011) True Color measured at 450 nm (not valid for NPDES monitoring)
W-F Fluoride	Template: DEFAULT	(SM 4500 F-C-2011) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC Sulfate	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS TDS	Template: DEFAULT	(SM 2540 C-2011) Total Dissolved Solids in aqueous matrices
W-TSS TSS	Template: DEFAULT	(SM 2540 D-2011) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI *Acesulfame K *AMPA *Endothall *Glufosinate *Glyphosate *Sucralose	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS *Acetaminophen *Acetamiprid *Afidopyropen *Benzovindiflupyr *Carbamazepine *Clothianidin *Dinotefuran *Fluridone *Hydrocodone *Ibuprofen *Imazapyr *Mandestrobin *Naproxen *Primidone *Pyraclostrobin *Thiamethoxam *Tolfenpyrad *Triclopyr	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Group D (Water) With 1 Samples:

Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
2,4-D		
Bentazon		
Diuron		
Fenuron		
Imidacloprid		
Linuron		
MCPP		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
Ammonia-N		
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
NO2NO3-N		
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
Total-P		
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
Kjeldahl Nitrogen		
W-TOC	Template: DEFAULT	(SM 5310 B-2011) Nonpurgeable Organic Carbon in aqueous matrices
Organic Carbon		
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L
O-Phosphate-P		

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.