

Log-in Checklist

RQ- 2019-11-11-14

Login Station ID: #5

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 11/ 21 /19 @ 10:15

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
1.7				19		✓			1278 4009 0139
1.8				15 (10)		✓			1278 4009 0128

* HNO₃ and Formalin persevered samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes ✓ No

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No ✓ If yes, is it intact? Yes No
 **Caps on tight? Yes ✓ No **Containers intact? Yes ✓ No
 **Sufficient Sample Volume: Yes ✓ No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes ✓ No Init: KK

Chlorine detected? (One container checked per Field ID) Yes No ✓ Init: KK

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes ✓ No NA Init: KK

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No NA ✓ Init: KK

Coolers Unpacked/Checked by: KK Date: 11/ 21 /19 NCRs (Y/N)? N

Event ID: LSJR Downtown Boat
NE-DIST-2019-11-21-02 (SMP)
Date Received: 21-NOV-2019 10:15
 NCR #

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC_07_2018 EXP:12/28/19
pH Test Strips 0 – 6 Lot #	
pH Paper 0 – 3 Lot #	220416A EXP:7/30/20
pH Paper 0 – 13 Lot #	215517 EXP:6/1/20
Chlorine Test Strips Lot #	091417V EXP:9/2021

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No X

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Florida Department of Environmental Protection

Central Laboratory Submittal Form

Customer: NE-DIST

Requester: Jeremy M. Parrish

Field Report Prepared By: K. Appleby

Project ID: SMP

Collected By: Kim Appleby + Brian Davis

Sampling Agency: FDEP NE ROL

Location	WIN ID/Field ID:  G2NE1152	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 11/20/19 Time 1035	Eastern Central	Composite end Date — Time —	Bottle Group(s) (See pg 2)
Field ID		Matrix (type, e.g., Salt, Fresh, etc) Salt	Diss. Oxygen 7.29	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L) —	A
WIN/STOR	Arlington River at Carlton oaks	Temp (C) 16.1	pH 7.35	Sample Depth 0.3	Sp. Conductance (umho/cm) 12410	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 7.15	Comments	
Location	WIN ID/Field ID:  20030679	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 11/20/19 Time 1055	Eastern Central	Composite end Date — Time —	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc) Salt	Diss. Oxygen 7.20	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L) —	A
WIN/ST	LITTLE POTTSBURG CREEK AT ATLANTIC BLVD	Temp (C) 15.9	pH 7.31	Sample Depth 0.3	Sp. Conductance (umho/cm) 14156	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 8.13	Comments	
Location	WIN ID/Field ID:  20030072	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 11/20/19 Time 955	Eastern Central	Composite end Date — Time —	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc) Salt	Diss. Oxygen 6.39	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L) —	B
WIN/STORET #	BIG POTTSBURG CR ATL BLVD	Temp (C) 15.4	pH 7.15	Sample Depth 0.3	Sp. Conductance (umho/cm) 5836	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 3.18	Comments	
Location	Location: BIG POTTSBURG CR ATL BLVD	☐ Comp ☒ Grab	Collection (comp begin or grab) Date 11/20/19 Time 1005	Eastern Central	Composite end Date — Time —	Bottle Group(s)
Field ID		Matrix (type, e.g., Salt, Fresh, etc)	Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L) —	L
WIN/STOR	FIELD ID:  FB 01102019	Temp (C)	pH	Sample Depth	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments	

Relinquished By: K. Appleby	Date/Time 11/20/19 1536	Shipping Method Fed Ex	Number of Coolers Shipped: 2	Received By: KK	Date/Time 11-21-19 1015
--------------------------------	----------------------------	---------------------------	---------------------------------	--------------------	----------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>2</u>
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>2</u>
	CHLSUITE-W					
Group: A	Bottle Type:	P-120ML-WC-THI	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>4 → Sent ALS</u>
	NE-ALS-ENQ					
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab <u>2</u>
	W-ICP W-ICPMS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab <u>2</u>
	W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab <u>2</u>
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	ALKALINITY TURBIDITY W-BR-IC W-F W-TSS					
Group: B	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab _____
	CHLSUITE-W					
Group: B	Bottle Type:	P-120ML-WC-THI	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>4 → Sent to ALS</u>
	NE-ALS-ENQ					
Group: B	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab <u>—</u>

Florida Department of Environmental Protection

Central Laboratory Submittal Form

LSJR Downtown Boat

last revised Jan 25, 2018

Customer: NE-DIST

Requester: Jeremy M. Parrish

Field Report Prepared By: K. Appleby

Project ID: SMP

Collected By: Kim Appleby + Brian Davis

Sampling Agency: FDEP NE ROL

Local	Field ID: 20030072 DUP		☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	Bottle	
Field	Location: BIG POTTSBURG CR ATL BLVD		☒ Grab	Date 11/20/19 Time 1000	Central	Date Time	Group(s)	
WIN/	WIN ID: 20030072		Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	Total Res. Chlorine	3	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Temp (C)	pH	Sample Depth		Sp. Conductance
			Salinity (ppt)		Comments			
Location			☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	Bottle	
Field ID			☐ Grab	Date Time	Central	Date Time	Group(s)	
WIN/STORET #			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	Total Res. Chlorine		
			Temp (C)		pH	Sample Depth		Sp. Conductance
Latitude			☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Comments		
Location			☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	Bottle	
Field ID			☐ Grab	Date Time	Central	Date Time	Group(s)	
WIN/STORET #			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	Total Res. Chlorine		
			Temp (C)		pH	Sample Depth		Sp. Conductance
Latitude			☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Comments		
Location			☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	Bottle	
Field ID			☐ Grab	Date Time	Central	Date Time	Group(s)	
WIN/STORET #			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	Total Res. Chlorine		
			Temp (C)		pH	Sample Depth		Sp. Conductance
Latitude			☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Comments		
Location			☐ Comp	Collection (comp begin or grab)	Eastern	Composite end	Bottle	
Field ID			☐ Grab	Date Time	Central	Date Time	Group(s)	
WIN/STORET #			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	Total Res. Chlorine		
			Temp (C)		pH	Sample Depth		Sp. Conductance
Latitude			☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Comments		

Relinquished By:	Date/Time	Shipping Method	Number of Coolers Shipped:	Received By:	Date/Time
K. Appleby	11/20/19 1530	Fed Ex	2	KK	11.21.19 / 1015

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ALKALINITY					
	TURBIDITY					
	W-BR-IC					
	W-F					
	W-TSS					
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	CHLSUITE-W					
Group: A	Bottle Type:	P-120ML-WC-THI	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	NE-ALS-ENQ					
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	HNO3	Enter Number of Bottles Sent to Lab
	W-ICP					
	W-ICPMS					
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab
	W-NH3					
	W-NO2NO3					
	W-S-A-TP					
	W-TKN					
	W-TOC					
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab
	W-PO4-F					
Group: B	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	ALKALINITY					
	TURBIDITY					
	W-BR-IC					
	W-F					
	W-TSS					
Group: B	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	CHLSUITE-W					
Group: B	Bottle Type:	P-120ML-WC-THI	# of Bottles: 4	Preservative:	ICE	Enter Number of Bottles Sent to Lab
	NE-ALS-ENQ					
Group: B	Bottle Type:	QPCR-P-500ML	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab

Group: B	Bottle Type: QPCR-P-500ML PCR-HF183	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: BG-500ML W-E8321-DI W-E8321-MS	# of Bottles: 2	Preservative: ICE	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: P-500ML W-ICP W-ICPMS	# of Bottles: 2	Preservative: HNO3	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN W-TOC	# of Bottles: 2	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
Group: B	Bottle Type: P-125ML W-PO4-F	# of Bottles: 2	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	2
Group: C	Bottle Type: P-1L ALKALINITY TURBIDITY W-BR-IC W-F W-TSS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: BG-500ML W-E8321-DI W-E8321-MS	# of Bottles: 1	Preservative: ICE	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: P-500ML W-ICP W-ICPMS	# of Bottles: 1	Preservative: HNO3	Enter Number of Bottles Sent to Lab	1
Group: C	Bottle Type: P-500ML W-NH3 W-NO2NO3 W-S-A-TP W-TKN	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	1

Group: C	Bottle Type:	P-500ML	# of Bottles: 1	Preservative: ICE And H2SO4	Enter Number of Bottles Sent to Lab	<u>1</u>
----------	--------------	---------	-----------------	-----------------------------	-------------------------------------	----------

W-TOC

Group: C	Bottle Type:	P-125ML	# of Bottles: 1	Preservative: FILTER-ICE	Enter Number of Bottles Sent to Lab	<u>1</u>
----------	--------------	---------	-----------------	--------------------------	-------------------------------------	----------

W-PO4-F



9143 Philips Highway, Suite 200 Jacksonville, FL 32256 / Ph(904) 739-2277 / FAX (904) 739-2011

ALS Contact

Page _____ of _____

[illegible]

Date of Request: 04-OCT-2019
 Created By: PARRISH_J On: 04-OCT-2019
 Modified By: JASROTIA_P On: 22-OCT-2019
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Sampling Event: LSJR Downtown Boat

Send Coolers To:

Phone: 904-256-1700
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Program Module Number:

Priority: 3

Event Status: S

Criminal Investigation: NO

Chemistry Request Reviewed By: WATTS_J On: 21-OCT-2019

Biology Request Reviewed By: JASROTIA_P On: 22-OCT-2019

Sampling Kit Required: YES Ship on: 01-NOV-2019

Sampling Kit Shipped: YES On: 29-OCT-2019

Sampling Kit Packed By: SHAIK_A

Preservatives Needed: YES

Date to Receive Samples: 11-NOV-2019

Received By:

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Report Type: Final Only

FTP Data: NO

QC Report: YES

Date Log: NO

Authorization Log: NO

Comments:

Group A: (Surf-Salt)
 Nutrients, Metals, Tracers, Bacteria

Group B: (Surf.Salt) Nutrients, Metals, Markers, Tracers, Bacteria

Group C: field blank- Nuts, Metals

NE-ALS-ENQ

Packing Notes:

1 - case of sulfuric acid/2 sets of labels

1 - case of nitric acid/2 sets of labels

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-120ML-WC-THI	Number of Bottles: 4	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville
Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO ₃
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Iron
 Manganese
 Zinc

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects

Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 2 Samples:

Bottle Type: QPCR-P-500ML	Number of Bottles: 2	Preserved With: ICE
PCR-HF183	Template: DEFAULT	(SOP-PCR-1.0) Detection and quantification of human-specific HF183 Bacteroides genetic marker with quantitative polymerase chain reaction

Bottle Type: BG-500ML	Number of Bottles: 2	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: HNO3
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects

Iron
Manganese
Zinc

W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
---------	-----------	---

Aluminum
Antimony
Arsenic
Cadmium
Chromium
Copper
Lead
Nickel
Selenium
Silver
Thallium

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices

Bottle Group B (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry
Bottle Type: P-120ML-WC-THI	Number of Bottles: 4	Preserved With: ICE
NE-ALS-ENQ	Template: DEFAULT	(ASTM D650399) Enterococci by Enterolert/QT by ALS in Jacksonville

Bottle Group C (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO ₃ /L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-BR-IC	Template: DEFAULT	(EPA 300.0) Bromide in aqueous matrices
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: BG-500ML	Number of Bottles: 1	Preserved With: ICE
W-E8321-DI	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
W-E8321-MS	Template: DEFAULT	(EPA 8321B) Pesticides, herbicides, and other chemicals in water matrices by HPLC/MS/MS
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: HNO ₃
W-ICP	Template: S-METALS	(EPA 200.7 Rev. 4.4) Total Recoverable Metals analysis using ICP emission spectroscopy for aqueous samples supporting Clean Water Act Projects
Iron		
Manganese		
Zinc		
W-ICPMS	Template:	(EPA 200.8 Rev. 5.4) Total Recoverable Metals analysis using ICP-MS for aqueous samples supporting Clean Water Act Projects
Aluminum		
Antimony		
Arsenic		
Cadmium		
Chromium		
Copper		
Lead		
Nickel		
Selenium		
Silver		
Thallium		
Bottle Type: P-500ML	Number of Bottles: 1	Preserved With: ICE And H ₂ SO ₄
W-NH ₃	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO ₂ NO ₃	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML	Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO ₄ -F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

* - The laboratory is not NELAP certified for this analyte/method, or certification is not applicable.