

Log-in Checklist

RQ- 2019 - 12-16-15

Login Station ID: # 3

Shipping Method: FedEx | UPS | HD | Greyhound

Date/Time of Receipt: 12/17/2019 / 10:25

Cooler Temperature*	Samples Frozen	* All Samples in Cooler Preserved with		Number of Sample Containers in Cooler	Evidence Tape				Tracking # Damaged waybills only
					Present?		*Intact?		
	YES	HNO ₃	Formalin		Yes	No	Yes	No	
2-8C				8		X			1278 4009 6516

* HNO₃ and Formalin preserved samples do **NOT** have a temperature requirement. For all others, if the temperature of a cooler is above 6.0 °C (or above 10.0 °C for W-1-4-DIOX and microbiology), or if Evidence Seal is damaged. Identify the containers in the affected cooler(s) on back of this form. **DOH coolers can exceed 2.0 °C above the standard temperature (6.0 or 10.0 °C) without login confirmation from customer for samples requiring ice preservation. An NCR still is required.**

**Chain of Custody/ Field Sheet(s) Included? Yes X No

Micro-Biology Overflow Chain of Custody/ Field Sheet(s) Included? Yes No X

****Note:** If "No" is checked below, fill out the back of this form (Field ID, Test IDs, etc.) and generate an NCR.

CONTAINER CHECK

**Evidence Tape on Bottles? Yes No X If yes, is it intact? Yes No

**Caps on tight? Yes X No **Containers intact? Yes X No

**Sufficient Sample Volume: Yes X No

CHLORINE CHECK REQUIRED? (Blue dot on container) Yes No ✓ Init: ABS

Chlorine detected? (One container checked per Field ID) Yes No Init: ABS

If "YES", list affected Field IDs and Test IDs below.

Field ID	List TestID(s) where Chlorine was Detected, an NCR is required.

PRESERVATION CHECK (EXCLUDING SAMPLES SENT TO OVERFLOW LABS, "OV-")

**Acid Preserved Samples: pH ≤ 2.0? Yes X No NA Init: ABS

**W-1-4-DIOX (Green dot on container) preserved to pH < 4.0? Yes No X NA Init: ABS

Coolers Unpacked/Checked by: ABS Date: 12-17-2019 NCRs (Y/N)?

Event ID: Interlachen 2 NCR #
NE-DIST-2019-12-17-01 (SMP)

Log-in Checklist

Samples with Incorrect pH Preservation

Field ID	Bottle Test ID(s)	pH	Action Taken

Samples in Coolers with Incorrect Preservation or Damaged Evidence Tape

Cooler ID	Field ID	Bottle Test ID(s)

Bottles Not Intact

Field ID	Bottle Test ID(s)	Loose Cap	Damaged Cap		Damaged Container		Evidence Tape Not Intact
			CK	BR	CK	BR	

Samples with Insufficient Volume for Analyses

Field ID	Bottle Test ID(s)	Action Taken

Additional Comments:

Infrared Thermometer ID:	REC 03 2018 EXP:04/29/2020
pH Test Strips 0 – 6 Lot #	213316AV EXP:05/15/2020
pH Paper 0 – 3 Lot #	220416A EXP:07/30/2020
pH Paper 0 – 13 Lot #	215517 exp:jun 1 2020
Chlorine Test Strips Lot #	8212 2021 / 05

ENCORE SAMPLES

S-VOC-MS samples in Encores must be frozen within 48 hours of collection.

Were Encore samples received? Yes _____ No **X**

Date and time placed in freezer _____

Were all samples placed in freezer within 48 hours of collection? Yes _____ If No _____

no, were samples shipped on dry ice? Yes _____ No _____

FOR CLEAN LAB USE ONLY – Total Mercury Preservation Check (W-HG-AF; W-HG-AF-F):

Samples preserved within 48 hours? Yes _____ No _____

Date and time samples preserved: _____

Interlachen 2

Customer: NE-DIST

Project ID: SMP


Requester: Jeremy M. Parrish

Field Report Prepared By: K. McDonald

Collected By: K. McDonald, B. Davis

Sampling Agency: FL DEP DEAR

Loc:	WIN / Field ID:		☐ Comp ☒ Grab	Collection (comp begin or grab) Date 12/16/19 Time 1105	Eastern Central	Composite end Date Time	Bottle Group(s) (See pg 2)	
Field	Church Lake Center		Matrix (type, e.g., Salt, Fresh, etc) Fresh		Diss. Oxygen 8.68	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN			Temp (C) 18.6	pH 6.85	Sample Depth 0.3	☐ ft ☒ m	Sp. Conductance (umho/cm) 39.4	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 0.02	Comments			A
WIN ID/Field ID:			☐ Comp ☒ Grab	Collection (comp begin or grab) Date 12/16/19 Time 1205	Eastern Central	Composite end Date Time	Bottle Group(s)	
Gillis Pond Center		Matrix (type, e.g., Salt, Fresh, etc) Fresh		Diss. Oxygen 7.52	☒ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	A	
		Temp (C) 17.9	pH 4.11	Sample Depth 0.3	☐ ft ☒ m	Sp. Conductance (umho/cm) 69.4		
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt) 0.03	Comments			
Location			☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time	Eastern Central	Composite end Date Time	Bottle Group(s)	
Field ID			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/STORET #			Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			
Location			☐ Comp ☐ Grab	Collection (comp begin or grab) Date Time	Eastern Central	Composite end Date Time	Bottle Group(s)	
Field ID			Matrix (type, e.g., Salt, Fresh, etc)		Diss. Oxygen	☐ mg/L ☐ % sat	Total Res. Chlorine (mg/L)	
WIN/STORET #			Temp (C)	pH	Sample Depth	☐ ft ☐ m	Sp. Conductance (umho/cm)	
Latitude	☐ dd ☐ dms	Longitude	☐ dd ☐ dms	Salinity (ppt)	Comments			

Relinquished By: 	Date/Time: 12/16/19 1630	Shipping Method: Fedex	Number of Coolers Shipped: 1	Received By: 	Date/Time: 12-17-19/11035
---	--------------------------	------------------------	------------------------------	--	---------------------------

Group: A	Bottle Type:	P-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: A	Bottle Type:	BP-1L	# of Bottles: 2	Preservative:	ICE	Enter Number of Bottles Sent to Lab	2
	CHLSUITE-W						
Group: A	Bottle Type:	P-500ML	# of Bottles: 2	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	2
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						
Group: A	Bottle Type:	P-125ML	# of Bottles: 2	Preservative:	FILTER-ICE	Enter Number of Bottles Sent to Lab	2
	W-PO4-F						
Group: B	Bottle Type:	P-1L	# of Bottles: 1	Preservative:	ICE	Enter Number of Bottles Sent to Lab	0
	ALKALINITY						
	TURBIDITY						
	W-CL-IC						
	W-COLOR						
	W-F						
	W-SO4-IC						
	W-TDS						
	W-TSS						
Group: B	Bottle Type:	P-500ML	# of Bottles: 1	Preservative:	ICE And H2SO4	Enter Number of Bottles Sent to Lab	0
	W-NH3						
	W-NO2NO3						
	W-S-A-TP						
	W-TKN						
	W-TOC						

Group: B

Bottle Type:

P-125ML

of Bottles: 1

Preservative:

FILTER-ICE

Enter Number of Bottles Sent to Lab

Ø

W-PO4-F

Date of Request: 15-NOV-2019
 Created By: PARRISH_J On: 15-NOV-2019
 Modified By: JASROTIA_P On: 26-NOV-2019
 Customer: NE-DIST
 Project: SMP
 Division: Division of Environmental Assessment and Restoration
 District: Northeast District
 Sampling Event: Interlachen 2

Send Coolers To:

Phone: 904-807-3300
 8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Program Module Number:

Priority: 3
 Event Status: R
 Criminal Investigation: NO
 Chemistry Request Reviewed By: WATTS_J On: 26-NOV-2019
 Biology Request Reviewed By: JASROTIA_P On: 26-NOV-2019
 Sampling Kit Required: NO Ship on:
 Sampling Kit Shipped:
 Sampling Kit Packed By:
 Preservatives Needed: NO
 Date to Receive Samples: 16-DEC-2019
 Received By: SHAIK_A On: 17-DEC-2019

Send Final Report To:

8800 Baymeadows Way West
 Suite 100
 Jacksonville, FL 32256
 Attn: Jeremy Parrish

Report Type: Final Only
 FTP Data: NO
 QC Report: YES
 Date Log: NO
 Authorization Log: NO

Comments: Group A: Nutrients

Packing Notes:
 None

Bottle Group A (Water) With 2 Samples:

Bottle Type: P-1L	Number of Bottles: 2	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0) Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B) True Color measured at 450 nm
Color (true)		
W-F	Template: DEFAULT	(SM 4500 F-C-97) Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1) Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97) Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97) Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample

Bottle Type: BP-1L	Number of Bottles: 2	Preserved With: ICE
CHLSUITE-W	Template: DEFAULT	(SM 10200 H (mod.)) Phytoplankton chlorophyll-a corrected, uncorrected, and phaeophytin by spectrophotometry

Bottle Type: P-500ML	Number of Bottles: 2	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0) Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0) Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0) Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00) Nonpurgeable Organic Carbon in aqueous matrices

Bottle Type: P-125ML	Number of Bottles: 2	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0) Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L	Number of Bottles: 1	Preserved With: ICE
ALKALINITY	Template: DEFAULT	(SM 2320 B-97) Alkalinity in aqueous matrices as mg CaCO3/L

Bottle Group B (Water) With 1 Samples:

Bottle Type: P-1L		Number of Bottles: 1	Preserved With: ICE
TURBIDITY	Template: DEFAULT	(EPA 180.1 Rev. 2.0)	Turbidity in aqueous matrices
W-CL-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Chloride in aqueous matrices
W-COLOR	Template: DEFAULT	(SM 2120 B)	True Color measured at 450 nm
Color (true)			
W-F	Template: DEFAULT	(SM 4500 F-C-97)	Fluoride in aqueous matrices, without distillation (not valid for NPDES monitoring)
W-SO4-IC	Template: DEFAULT	(EPA 300.0 Rev. 2.1)	Sulfate in aqueous matrices
W-TDS	Template: DEFAULT	(SM 2540 C-97)	Total Dissolved Solids in aqueous matrices
W-TSS	Template: DEFAULT	(SM 2540 D-97)	Total Suspended Solids in aqueous matrices using a maximum of 250 mL of sample
Bottle Type: P-500ML		Number of Bottles: 1	Preserved With: ICE And H2SO4
W-NH3	Template: DEFAULT	(EPA 350.1 Rev. 2.0)	Ammonia in aqueous matrices as mg N/L
W-NO2NO3	Template: DEFAULT	(EPA 353.2 Rev. 2.0)	Nitrite/Nitrate in aqueous matrices as mg N/L
W-S-A-TP	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Total Phosphorus in aqueous matrices as mg P/L
W-TKN	Template: DEFAULT	(EPA 351.2 Rev. 2.0)	Total Kjeldahl Nitrogen in aqueous matrices
W-TOC	Template: DEFAULT	(SM 5310 B-00)	Nonpurgeable Organic Carbon in aqueous matrices
Bottle Type: P-125ML		Number of Bottles: 1	Preserved With: FILTER-ICE
W-PO4-F	Template: DEFAULT	(EPA 365.1 Rev. 2.0)	Ortho-phosphate, dissolved, in filtered, aqueous matrices as mg P/L